

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [LYPERTEK](#) /

› [LYPERTEK PurePlay Z3 2.0 True Wireless Earbuds User Manual](#)

## LYPERTEK PUREPLAYZ3-BLACK

# LYPERTEK PurePlay Z3 2.0 True Wireless Earbuds User Manual

Model: PUREPLAYZ3-BLACK

## PRODUCT OVERVIEW

The LYPERTEK PurePlay Z3 2.0 True Wireless Earbuds offer an advanced audio experience with upgraded features. These earbuds are designed for immersive sound, extended playtime, and seamless connectivity, making them suitable for daily use and active lifestyles.



Image: LYPERTEK PurePlay Z3 2.0 True Wireless Earbuds shown with their fabric-covered charging case. The earbuds are black with metallic accents, and the case is open, revealing the charging cradles and LED indicators.

## Key Features

- **Advanced Wireless Sound:** Features an upgraded chipset with Bluetooth 5.2, wireless charging, and Hear Through mode. Equipped with professionally tuned Graphene drivers for clean, balanced, and powerful audio.
- **PureControl App & LDX Audio:** Access a 7-band EQ, LDX Audio mode, Hear Through mode, button customization, and Find My Earbuds via the dedicated PureControl app for iOS and Android.
- **Extended Listening:** Provides 10 hours of playtime on a single charge, with the included fabric charging case extending total playtime to 80 hours.
- **Bluetooth 5.2:** Utilizes the latest Qualcomm chipset with aptX and ACC high-quality audio codecs for a stable wireless connection and extended range.
- **Easy Control & Hear Through Mode:** Features physical buttons to prevent accidental presses, allowing control of music, calls, and voice assistance. Hear Through mode enables awareness of surroundings without removing earbuds.
- **IPX7 Waterproof:** Designed to withstand splashes, rain, and sweat, making them suitable for various activities.



Image: Close-up of a LYPERTEK PurePlay Z3 2.0 earbud highlighting its IPX7 waterproof design and control features. Text indicates

"Waterproof design provides protection from rain and sweat" and "Control music, calls, volume and voice assistants. PureControl app support for EQ, LDX and more."

## GETTING STARTED: SETUP

---

### What's in the Box

Your LYPERTEK PurePlay Z3 2.0 package includes the following items:

- LYPERTEK PurePlay Z3 2.0 True Wireless Earbuds (Left and Right)
- Charging Case
- USB Type-C cable
- Quick Start Manual
- S Silicone Tips
- M Silicone Tips
- L Silicone Tips
- Flexifit Foam Tips (M size)



WHAT IS INSIDE?



# PUREPLAY Z3



PUREPLAY Z3  
True Wireless Stereo Earphones - 1pair  
Charging Case - 1pc  
S, M, L Silicone Tips - 1pair per size  
FLEXFIT Foam Tips  
USB Type-C cable - 1pc  
Quick Start Manual - 1pc

CHARGE TIME: 1.5H  
TALK TIME: 5H  
STANDBY TIME: 100H  
DYNAMIC TURBO MODE: 1.5H  
CHARGING CASE: 2.5H  
JEWEL CASE: 100H  
WIRELESS CHARGE: 1.5H

Image: The retail packaging for the LYPERTEK PurePlay Z3 2.0, showing the earbuds and charging case on the front, with icons on the side indicating included accessories.

## Initial Charging

Before first use, it is recommended to fully charge both the earbuds and the charging case. The charging case provides up to 7 additional charges for the earbuds, extending total playtime to 80 hours.

1. Place both earbuds into the charging case, ensuring they are properly seated in their respective cradles. The LED indicators on the earbuds will light up to confirm charging.
2. Connect the USB Type-C cable to the charging port on the back of the case and the other end to a USB power source (e.g., wall adapter, computer USB port).
3. Alternatively, place the charging case on a compatible wireless charging pad for wireless charging.
4. The LED indicators on the charging case will show the charging status. A full charge for the case takes approximately 10 hours.



Image: A close-up view of the USB Type-C charging port located on the side of the LYPERTEK PurePlay Z3 2.0 charging case, embedded within its fabric texture.



## FAST AND WIRELESS CHARGING

The high quality fabric charging case now supports **Wireless Charging** and **Fast Charge** via USB Type-C.

## STAY AWARE

The new **Hear Through Mode** allows you to hear your surroundings without having to remove the earphones.



Image: The LYPERTEK PurePlay Z3 2.0 charging case placed on a wireless charging pad, illustrating its wireless charging capability. Text highlights "FAST AND WIRELESS CHARGING" and "STAY AWARE" (Hear Through Mode).

## Bluetooth Pairing

The PurePlay Z3 2.0 earbuds utilize Bluetooth 5.2 for a stable and efficient connection.

1. Ensure the earbuds are charged and inside the charging case.
2. Open the charging case. The earbuds will automatically enter pairing mode.
3. On your device (smartphone, tablet, laptop), go to Bluetooth settings and enable Bluetooth.
4. Search for available devices. Select "LYPERTEK PurePlay Z3 2.0" from the list.
5. Once connected, a confirmation sound will play, and the earbuds' indicator lights will change.

The earbuds will automatically reconnect to the last paired device when removed from the case, if Bluetooth is enabled on the device.



## 10+70: MUSIC NON STOP

**10 hours** playtime on a single charge plus **7 times** charging via the charging case extending the full playtime to **80 hours**.

## RELIABLE PERFORMANCE

Equipped with the latest Qualcomm QCC3040 **Bluetooth 5.2** chipset with **aptX** and **AAC** for a rock solid connection and **HD audio** transmission.



Image: An illustration highlighting the 80-hour battery life and Bluetooth 5.2 connectivity of the LYPERTEK PurePlay Z3 2.0. The image shows the earbuds in their charging case and a close-up of an earbud's internal components.

## OPERATING YOUR EARBUDS

### Basic Controls

The PurePlay Z3 2.0 earbuds feature physical buttons for precise control without accidental touches. Refer to the Quick Start Manual for a detailed button function map. Common controls include:

- **Play/Pause:** Single press on either earbud.
- **Next Track:** Double press on the right earbud.
- **Previous Track:** Double press on the left earbud.
- **Volume Up:** Triple press on the right earbud.
- **Volume Down:** Triple press on the left earbud.
- **Answer/End Call:** Single press on either earbud during an incoming call.
- **Reject Call:** Press and hold on either earbud during an incoming call.
- **Activate Voice Assistant:** Press and hold on either earbud (e.g., Siri, Google Assistant).

### PureControl App Features

Enhance your experience by downloading the PureControl app, available for iOS and Android devices. The app unlocks advanced functionalities:

- **7-Band Equalizer (EQ):** Customize your audio profile to match your preferences.
- **LDX Audio Mode:** Activate a specially developed audio profile for an enhanced listening experience.
- **Hear Through Mode:** Adjust the level of ambient sound you hear, allowing you to stay aware of your surroundings without removing the earbuds.

- **Button Customization:** Reassign button functions to suit your workflow.
- **Find My Earbuds:** Locate misplaced earbuds within Bluetooth range.
- **Firmware Updates:** Keep your earbuds updated with the latest features and improvements.



## AWARD WINNING SOUND

Expertly tuned **Graphene drivers** provide a crisp and dynamic sound with plenty of **punch** and **energy**.

## YOU ARE IN CONTROL

Access the **7 band EQ**, enable the **LDX audio mode**, edit button layouts and more via Lypertek's **PureControl App** for iOS and Android.



Image: A graphic illustrating the "AWARD WINNING SOUND" of the LYPERTEK PurePlay Z3 2.0 and the "YOU ARE IN CONTROL" aspect of the PureControl app, showing multiple phone screens with the app's interface, including EQ and LDX Audio settings.

## MAINTENANCE AND CARE

### Cleaning Your Earbuds

Regular cleaning helps maintain sound quality and hygiene.

- Gently wipe the earbuds and charging case with a soft, dry, lint-free cloth.
- For ear tips, remove them from the earbuds and clean with a mild soap solution if necessary, then rinse thoroughly and allow to air dry completely before reattaching.
- Use a dry cotton swab or a small, soft brush to carefully remove any earwax or debris from the earbud nozzles and charging contacts.
- Avoid using abrasive materials, solvents, or harsh chemicals.

### Storage

Always store your earbuds in their charging case when not in use to protect them from damage and keep them charged.

### Water Resistance (IPX7)

The PurePlay Z3 2.0 earbuds are rated IPX7, meaning they are protected against immersion in water up to 1 meter for up to 30 minutes. This makes them resistant to sweat and rain. However, they are not designed for swimming or prolonged submersion. Ensure the earbuds are completely dry before placing them back into the charging case to prevent damage.

to the charging contacts.

## TROUBLESHOOTING

---

If you encounter issues with your LYPERTEK PurePlay Z3 2.0 earbuds, try the following solutions:

Problem	Possible Solution
Earbuds not pairing/connecting.	<p>Ensure earbuds are charged and in the case.</p> <p>Turn off and on Bluetooth on your device.</p> <p>Forget/remove "LYPERTEK PurePlay Z3 2.0" from your device's Bluetooth list and re-pair.</p> <p>Try pairing with another device to check if the issue is with the earbuds or your device.</p>
No sound or low volume.	<p>Check volume levels on both earbuds and your connected device.</p> <p>Ensure earbuds are properly seated in your ears.</p> <p>Clean earbud nozzles and ear tips for any obstructions.</p> <p>Try resetting the earbuds (refer to the Quick Start Manual for specific reset instructions).</p>
Charging issues.	<p>Ensure the USB-C cable is securely connected to both the case and the power source.</p> <p>Try a different USB-C cable or power adapter.</p> <p>Clean the charging contacts on both the earbuds and inside the case.</p> <p>If using wireless charging, ensure the case is correctly positioned on the charging pad.</p>
App not connecting or functioning correctly.	<p>Ensure your earbuds are connected to your device via Bluetooth.</p> <p>Close and reopen the PureControl app.</p> <p>Check for app updates in your device's app store.</p> <p>Restart your device.</p>

For more detailed troubleshooting or advanced reset procedures, please consult the official LYPERTEK support resources or the full Quick Start Manual.

## SPECIFICATIONS

---

Feature	Detail
Model Name	PUREPLAYZ3-BLACK
Connectivity Technology	Wireless, Bluetooth 5.2
Wireless Communication Technology	Bluetooth
Bluetooth Version	5.2

Feature	Detail
Bluetooth Range	10 Meters
Audio Driver Type	Dynamic Driver
Audio Driver Size	6 Millimeters
Frequency Response	20 Hz - 20 kHz
Battery Life (Earbuds)	10 Hours
Total Playtime with Case	Up to 80 Hours (10 hours + 70 hours from case)
Charging Time (Case)	10 Hours
Water Resistance Level	IPX7 (Waterproof)
Control Type	Voice Control, App
Material	Plastic
Item Weight (Earbud)	5 Grams
Product Dimensions	4.53 x 1.77 x 4.21 inches
Compatible Devices	Cellphones, Laptops, Desktops, Tablets
Included Components	Charging Case, USB Type-C cable, Quick Start Manual, S/M/L Silicone Tips, Flexifit Foam Tips (M size)

## WARRANTY AND SUPPORT

---

### Product Warranty

LYPERTEK products typically come with a limited manufacturer's warranty covering defects in materials and workmanship. The specific terms and duration of the warranty may vary by region and retailer. Please retain your proof of purchase for warranty claims.

For detailed warranty information, please visit the official LYPERTEK website or contact their customer support.

### Customer Support

If you require further assistance, have questions not covered in this manual, or need technical support, please contact LYPERTEK customer service through their official website. You may find FAQs, additional manuals, and contact forms there.

*Note: No official product videos from the seller were available for embedding in this manual.*

