

Fuse The Side Kick

Fuse Reel The Side Kick Collapsible Charger Organizer Instruction Manual

1. INTRODUCTION

The Fuse Reel The Side Kick is a collapsible charger organizer designed to streamline cable management for your MacBook and PC charging cords. It provides a compact and organized solution for both travel and daily use, preventing tangled cables and protecting your charger.



Image 1.1: The Side Kick attached to a charger, demonstrating compact cable organization.



Image 1.2: The Side Kick making a charger compact for travel.

2. COMPATIBILITY

The Side Kick is compatible with a wide range of chargers, including Apple Chargers (60W, 61W/67W USB-C, 70W, 85W, 87W/96W USB-C, 140W Magsafe) and various PC chargers. It is designed to fit charging bricks larger than 2.5 x 2.5 inches (65 x 65 mm).

Important: Not recommended for charging bricks smaller than 2.5 x 2.5 inches (65 x 65 mm).

SIZING GUIDE

The Side Kick fits any charger larger than 2.5"

**DOES
FIT**



**DOES
NOT
FIT**




Image 2.1: Visual guide for charger compatibility based on size.


3. SETUP AND INSTALLATION

Follow these steps to attach The Side Kick to your compatible charger:

- Clean Surface:** Ensure the surface of your charger brick is clean and dry before application.
- Attach Adhesive:** Peel off the protective backing from the adhesive pad on The Side Kick.
- Position:** Carefully align The Side Kick with one side of your charger brick. Ensure the 'PUSH' button is facing outwards.
- Secure:** Press firmly to secure The Side Kick to the charger. Allow the adhesive to set for a few minutes before use.




Image 3.1: The Side Kick's pop-out mechanism for cable winding.




1. STICK IT



2. POP IT




3. WIND IT



TO REMOVE:

Do not pull face-plate!
Simply pry from base.



WE RECOMMEND:


Before winding.
Give your cable some slack.

Image 3.2: Step-by-step visual guide for attaching and winding the cable.

4. OPERATING INSTRUCTIONS

Once attached, The Side Kick simplifies cable management:

- 1. Extend for Winding:** Gently press the 'PUSH' button on The Side Kick to extend the winding mechanism.
- 2. Wind Cable:** Begin winding your charging cable around the extended mechanism. The Side Kick replaces traditional adapter clips and allows for quick winding.
- 3. Secure Cable Ends:** Utilize the integrated 'Snotch' cable latch to secure the ends of your cable, preventing unraveling and damage.
- 4. Adjust Cable Length:** The design allows you to adjust the exposed cable length, using only what you need.
- 5. Retract for Storage:** Once the cable is wound, gently push the mechanism back into its collapsed position for compact storage.



ADJUST TO YOUR SETUP.

Adjust your cables so you're only using what you need.

Image 4.1: Adjusting cable length for optimal setup.

5. FEATURES

- **Collapsible Design:** The Side Kick collapses to a slim 5mm when not in use, ensuring minimal bulk.
- **'Snotch' Cable Latch:** A trademarked and patented cable latch keeps your cable organized and protected from damage.
- **Quick Winding:** Enables rapid winding of your charging cable in under 5 seconds.



ALMOST TOO SLIM.

The Side Kick collapses to just
5mm while not in use

THE SNOTCH.

You read that right.
Trademarked and patented,
the 'Snotch' cable latch keeps
your cable organized and
damage-free.



Image 5.1: The Side Kick's collapsible design and 'Snotch' cable latch.

6. MAINTENANCE

To ensure the longevity and optimal performance of your Side Kick:

- **Cleaning:** Wipe the device with a soft, dry cloth to remove dust or debris. Avoid harsh chemicals.
- **Adhesive Care:** If the adhesive loses its stickiness over time, use the provided extra adhesive pad for re-attachment.
- **Storage:** Store in a cool, dry place away from direct sunlight or extreme temperatures.

7. TROUBLESHOOTING

If you encounter any issues with your Side Kick, consider the following:

- **Adhesive Not Sticking:** Ensure the charger surface is clean and dry. Apply firm pressure during initial attachment. Use the spare adhesive if needed.
- **Cable Not Winding Smoothly:** Check for any kinks or twists in the cable before winding. Ensure the winding mechanism is fully extended.

- **Incompatible Charger:** Verify that your charger brick meets the size requirements (larger than 2.5 x 2.5 inches).

8. SPECIFICATIONS

- **Brand:** Fuse
- **Model Number:** FUSE-SK-WHT
- **Item Weight:** 0.95 ounces
- **Product Dimensions:** 2.7 x 2.7 x 0.4 inches
- **Color:** White
- **Material:** Plastic Aluminium
- **Special Feature:** Travel
- **Included Components:** Adhesive

9. WARRANTY AND SUPPORT

The Fuse Reel The Side Kick is backed by the manufacturer's warranty. For specific warranty details, product support, or any inquiries, please refer to the official Fuse Reel website or contact their customer service directly. Keep your purchase receipt for warranty claims.