SHIMANO RD-M8100-SGS, RD-M8120-SGS

SHIMANO XT RD-M8100-SGS / RD-M8120-SGS Rear Derailleur Instruction Manual

Models: RD-M8100-SGS, RD-M8120-SGS

Safety Information | Package Contents | Setup & Installation | Operation | Maintenance | Troubleshooting | Specifications | Warranty & Support

1. Safety Information

Always read and understand all instructions before installation and use. Failure to follow these instructions could result in serious injury or damage to the product. Keep this manual for future reference.

- Ensure all components are compatible with your bicycle system.
- Use appropriate tools for installation and adjustment.
- Tighten all bolts to the manufacturer's specified torque values. Overtightening or undertightening can lead to component failure.
- Regularly inspect the derailleur for signs of wear, damage, or loose connections.
- If you are unsure about any installation or adjustment procedure, consult a professional bicycle mechanic.

2. Package Contents

The package for your SHIMANO XT Rear Derailleur typically includes the following:

- One (1) SHIMANO XT Rear Derailleur (RD-M8100-SGS or RD-M8120-SGS)

Note: Additional components such as cables, housing, or mounting hardware may be sold separately.

3. Setup & Installation

Proper installation is crucial for optimal performance and safety. It is highly recommended to refer to the official SHIMANO dealer's manual for detailed, step-by-step installation instructions, which can be found on the SHIMANO technical

documentation website.

3.1. Pre-Installation Check

- **Compatibility:** Ensure your frame, cassette, chain, and shifter are compatible with a SHIMANO 12-speed system. The RD-M8100-SGS is designed for 1x12 systems, while the RD-M8120-SGS is for 2x12 systems.
- **Derailleur Hanger:** Verify that your derailleur hanger is straight and undamaged. A bent hanger is a common cause of poor shifting.

3.2. Mounting the Derailleur

Attach the rear derailleur to the derailleur hanger on your bicycle frame. Ensure it is securely fastened according to SHIMANO's torque specifications.



Image 1: SHIMANO XT RD-M8100-SGS Rear Derailleur. This image shows the complete derailleur assembly, highlighting its robust construction and the SHIMANO XT branding.

3.3. Chain Installation and Length Adjustment

Install the appropriate 12-speed chain. Correct chain length is critical for proper shifting and to prevent damage. Refer to the SHIMANO manual for precise chain length calculation methods based on your drivetrain configuration.

3.4. Cable Routing and Connection

Route the shift cable and housing correctly. Ensure there are no sharp bends or kinks in the housing that could impede cable movement. Connect the cable to the derailleur and secure it.

3.5. Limit Screw Adjustment (H and L)

Adjust the High (H) and Low (L) limit screws to prevent the chain from shifting beyond the smallest and largest cogs, respectively. This protects the chain from falling off the cassette and prevents damage to the spokes or frame.

3.6. B-Tension Adjustment

The B-tension screw adjusts the distance between the upper guide pulley and the cassette cogs. Proper B-tension is essential for smooth shifting across the entire cassette. Follow SHIMANO's guidelines for setting the correct B-tension for your specific cassette size.

3.7. Index Adjustment

Fine-tune the shifting by adjusting the barrel adjuster on the shifter or derailleur (if present). Shift through all gears to ensure crisp and accurate shifts in both directions.

4. Operating Instructions

The SHIMANO XT rear derailleur is designed for smooth and stable shifting performance in various riding conditions.

- **Shifting:** Use your shifter to change gears. Apply consistent pressure to the pedals while shifting for the smoothest transitions. Avoid shifting under heavy load if possible.
- **SHADOW RD+ Clutch:** This derailleur features SHADOW RD+ technology, which includes a clutch mechanism to reduce chain slap and improve chain retention, especially on rough terrain. The clutch can typically be engaged or disengaged via a small lever on the derailleur body. Ensure it is engaged for riding to benefit from its chain stabilizing properties.
- **Large Pulley Wheels:** The large 13-tooth pulley wheels contribute to efficient power transfer and smooth chain movement.

5. Maintenance

Regular maintenance will prolong the life and ensure the optimal performance of your SHIMANO XT rear derailleur.

- **Cleaning:** After each ride, especially in wet or dirty conditions, clean the derailleur body, pulley wheels, and cage with a mild degreaser and brush. Rinse thoroughly and dry.
- **Lubrication:** Apply a small amount of bicycle-specific lubricant to the pivot points of the derailleur and the pulley wheel bearings periodically. Avoid over-lubricating, which can attract dirt.
- **Cable & Housing:** Inspect shift cables and housing for fraying, kinks, or corrosion. Replace them if necessary to maintain crisp shifting.
- **Pulley Wheels:** Check pulley wheels for wear. Worn pulley teeth can lead to poor shifting and chain noise. Replace them when signs of significant wear are visible.
- **Derailleur Hanger:** Periodically check the derailleur hanger for alignment. Even minor bends can affect shifting performance.
- **Clutch Mechanism:** If your derailleur has a SHADOW RD+ clutch, ensure it is functioning correctly. Refer to the SHIMANO manual for specific clutch maintenance procedures.

6. Troubleshooting

Here are some common issues and their potential solutions:

Problem	Possible Cause	Solution
Poor or Slow Shifting	◦ Incorrect cable tension ◦ Bent derailleur hanger ◦ Worn or dirty cable/housing ◦ Incorrect B-tension adjustment ◦ Worn chain or cassette	◦ Adjust index (cable tension) using barrel adjuster. ◦ Check and straighten/replace derailleur hanger. ◦ Clean or replace cable and housing. ◦ Re-adjust B-tension screw. ◦ Inspect and replace worn drivetrain components.
Chain Rubs or Falls Off	◦ Incorrect limit screw adjustment ◦ Bent derailleur hanger	◦ Adjust H and L limit screws. ◦ Check and straighten/replace derailleur hanger.
Excessive Chain Slap/Noise	◦ SHADOW RD+ clutch disengaged ◦ Worn chain or pulley wheels ◦ Incorrect chain length	◦ Engage the SHADOW RD+ clutch. ◦ Inspect and replace worn components. ◦ Verify correct chain length.

For more complex issues, consult a professional bicycle mechanic or refer to the official SHIMANO technical documentation.

7. Specifications

Feature	Detail
Brand	SHIMANO
Model Numbers	RD-M8100-SGS (1x12), RD-M8120-SGS (2x12)
Gearing	12-Speed
Cage Length	SGS (Long Cage)
Material	Aluminum
Capacity (RD-M8100-SGS)	41t (for 1x12 systems)
Cassette Range (RD-M8100-SGS)	10-51t (for 1x12 systems)
Capacity (RD-M8120-SGS)	35t (for 2x12 systems)
Cassette Range (RD-M8120-SGS)	10-45t (for 2x12 systems)
Pulley Teeth	13T
Technology	SHADOW RD+

Item Weight	Approximately 9.92 ounces (281g)
UPC	192790897097
Manufacturer Part Number	IRDM8100GS

8. Warranty & Support

8.1. Warranty Information

This SHIMANO product is covered by a **Limited Warranty**. For specific details regarding warranty coverage, duration, and claims procedures, please refer to the official SHIMANO warranty policy available on their website or contact your authorized SHIMANO dealer.
Note: The warranty typically covers manufacturing defects and material flaws under normal use. It does not cover damage due to improper installation, misuse, neglect, accidents, or normal wear and tear.

8.2. Customer Support

For technical assistance, installation guidance, or any questions not covered in this manual, please contact your local authorized SHIMANO dealer or visit the official SHIMANO website for support resources and contact information.
SHIMANO Official Website: bike.shimano.com

© 2026 SHIMANO. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question