

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Costzon](#) /
- › [Costzon Inflatable Water Slide with 480W Air Blower Instruction Manual](#)

Costzon 01213

Costzon Inflatable Water Slide with 480W Air Blower Instruction Manual

Model: 01213

1. PRODUCT OVERVIEW

The Costzon Inflatable Water Slide is designed for outdoor recreational use, providing a fun and engaging experience for children. This unit features a climbing wall, a curved water slide, and a splash pool area. It is constructed from durable Oxford materials and includes a 480W air blower for continuous inflation.




Image 1.1: Overview of the Costzon Inflatable Water Slide.

2. SAFETY INFORMATION

Prioritize safety during setup and use. Adhere to the following guidelines:

- **Material Durability:** Constructed from heavy-duty puncture-proof 420D Oxford materials, with an 840D Oxford bouncing area for enhanced durability.
- **Weight Limits:** Maximum weight on the inflatable part is 200 lbs. Suitable for 3-4 children playing together. Individual weight limit is 66 lbs.
- **Safety Features:** Features heightened and extended handrails on slides, an inflatable buffer steps zone at the bottom of the climbing wall, and a breathable mesh wall at the top of the climbing wall for protection and visibility.
- **Ground Stakes:** Use provided ground stakes to ensure stability and firmness during use.
- **Supervision:** Adult supervision is required at all times when children are using the water slide.
- **Age Range:** Recommended for ages 36 months to 10 years.



Recommended Age:
3-10 years old



Accommodate
up to 3-4 kids



Individual Weight
Limit: 66 lbs



Total Weight
Limit: 200 lbs

Image 2.1: Safety guidelines including age and weight recommendations.



3. PACKAGE CONTENTS

Verify that all components are present in the package before beginning setup:

- 1 x Inflatable Water Slide
- 1 x 480W Air Blower
- 1 x Water Hose
- 6 x Ground Stakes
- 1 x Repair Kit
- 1 x Carrying Bag



Image 3.1: Contents included in the product package.

4. SETUP INSTRUCTIONS

Follow these steps for quick and proper inflation of your water slide:

1. Unroll the water slide: Take the inflatable water slide out of its carrying bag and spread it out flat in your desired outdoor location. Ensure the area is clear of sharp objects.
2. Connect the air blower: Attach the 480W air blower to the inflation tube of the water slide. Ensure a secure connection.
3. Inflate the slide: Plug in the air blower and turn it on. The water slide will inflate rapidly. Keep the blower running continuously during use.
4. Secure with ground stakes: Once fully inflated, use the provided ground stakes to anchor the water slide firmly to the ground.
5. Connect the water hose: Attach a standard garden hose to the water spray system on the water slide. Use the hook and loop fasteners to keep the water pipe in place.
6. Fill the splash pool: Turn on the water supply to fill the splash pool area. Adjust water flow to keep the sliding surface continuously wet.



Image 4.1: Visual guide for setting up the water slide.

Your browser does not support the video tag.

Video 4.1: Detailed setup and inflation guide for the water slide.

5. OPERATING THE WATER SLIDE

The inflatable water slide offers multiple play areas for children:

- **Climbing Wall:** Children can climb the challenging inflatable rock wall, using the heavy-duty grips.
- **Water Slide:** After climbing, children can enjoy the curved water slide, which has heightened handrails for safety. Ensure the slide surface is wet for optimal use.
- **Splash Pool:** The slide leads into a wide splash pool for water play.

The water slide can be used wet or dry, offering versatility for different weather conditions.

ENDLESS HOURS OF FUN



Climb Wall



Splash Pool



Water Slide



Image 5.1: Features of the water slide: climbing wall, splash pool, and water slide.



DRY



Add much fun in hot summer!



WET

Image 5.2: The water slide can be used for both wet and dry play.

Your browser does not support the video tag.

Video 5.1: Demonstration of children enjoying the water slide features.

6. MAINTENANCE AND STORAGE

Proper maintenance and storage will extend the life of your inflatable water slide:

- **Drying After Use:** After use, ensure all water is drained from the splash pool. Open the small vent on the other side of the inflatable to allow any internal water to escape. Reconnect the blower and run it again to thoroughly dry the interior of the water slide. This prevents mold and mildew.
- **Cleaning:** If dirt or debris accumulates, clean the surface with a mild soap solution and water. Rinse thoroughly and ensure it is completely dry before storage.
- **Storage:** Once completely dry, deflate the water slide and fold it neatly. Store it in the provided carrying bag in a cool, dry place away from direct sunlight and extreme temperatures.
- **Repair Kit:** Use the included repair kit for minor punctures or tears.

7. SPECIFICATIONS

Feature	Detail
Model Number	01213
Product Dimensions (L x W x H)	156"L x 118"W x 100"H (13'L x 10'W x 8'H)
Item Weight	38.5 Pounds
Material	420D Oxford (main), 840D Oxford (bouncing area), Mesh
Air Blower	480W (included)
Recommended Age	36 months - 10 years
Maximum Weight Recommendation	300 Pounds (total on inflatable part)
Number of Players	Up to 4 children
Individual Weight Limit	66 Pounds



Image 7.1: Product dimensions and measurements.

8. TROUBLESHOOTING

If you encounter issues with your water slide, consider the following:

- **Incomplete Inflation:** Ensure the air blower is continuously running and securely attached. Check for any large tears or openings in the fabric. Small air leaks from seams are normal as the blower maintains constant air pressure.
- **Water Drainage:** If water remains inside the inflatable after use, ensure the small vent is open and the blower is run for a sufficient period to dry the interior.
- **Stability Issues:** Verify that all ground stakes are properly inserted and the water slide is placed on a flat, level surface.

9. WARRANTY AND SUPPORT

Costzon products typically come with a manufacturer's warranty. For specific warranty details and support, please refer to the documentation included with your purchase or contact Costzon customer service directly. In case of missing instructions, refer to the visual guides provided on the product page or contact support for assistance.

For further inquiries or assistance, please visit the official Costzon store or contact their customer support.

[Visit the Costzon Store](#)