

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [BEAUTURAL](#) /

› [BEAUTURAL Steam Iron for Clothes with Precision Thermostat Dial, Ceramic Coated Soleplate, 3-Way Auto-Off, Self-Cleaning, Anti-Calcium, Anti-Drip Blue - Instruction Manual](#)

BEAUTURAL Steam Iron

BEAUTURAL Steam Iron Instruction Manual

Model: Steam Iron

IMPORTANT SAFETY INFORMATION

WARNING: This appliance is not intended for use by dependents and children. All use by dependents should be supervised by a responsible, capable adult.

Always unplug the iron from the electrical outlet when filling with water, emptying, or when not in use. Do not leave the iron unattended while it is connected to the power supply.

Do not immerse the iron, power cord, or plug in water or other liquids.

PRODUCT OVERVIEW

The BEAUTURAL Steam Iron is designed for efficient and safe garment care. It features a ceramic coated soleplate for smooth gliding, a precision thermostat dial, and a 3-way automatic shut-off system for enhanced safety.



Figure 1: Overview of the BEAUTURAL Steam Iron.

Key Features:

- **Ceramic Coated Soleplate:** Non-stick surface for smooth gliding and durability.
- **Precision Thermostat Dial:** Easily select the correct temperature for various fabric types.
- **3-Way Automatic Shut-Off:** Enhances safety by turning off the iron when left idle.
- **Self-Cleaning Function:** Helps maintain optimal performance and extends iron lifespan.
- **Anti-Drip System:** Prevents water leakage at low temperatures.
- **Anti-Calcium System:** Reduces mineral build-up for consistent steam output.

SETUP AND FIRST USE

Before First Use:

1. Remove any labels or protective film from the soleplate.
2. It is normal for a slight odor or smoke to occur during the first few uses as manufacturing residues burn off. This is harmless and will disappear quickly.

Filling the Water Tank:

- Ensure the iron is unplugged from the power outlet.
- Set the steam control to the "Dry Ironing" position (no steam).
- Open the water tank cover.
- Using the provided measuring cup, carefully pour tap water into the water tank up to the "MAX" fill line. Do not overfill.
- Close the water tank cover securely.



Figure 2: Filling the water tank of the steam iron.

OPERATING INSTRUCTIONS

Setting the Temperature:

1. Plug the iron into a suitable electrical outlet.
2. Turn the precision thermostat dial to the desired temperature setting based on the fabric type. Refer to the fabric guide on the dial or garment care labels.
3. The indicator light will illuminate, indicating the iron is heating. It will turn off when the set temperature is reached.

Steam Ironing:

- Ensure the water tank is filled.
- Set the temperature dial to a steam-appropriate setting (usually between "Wool" and "Linen/Cotton"). Steam will not be produced at lower temperatures to prevent dripping.
- Once the indicator light turns off, indicating the iron is hot enough, adjust the steam control to the desired steam level.
- Begin ironing.

Burst of Steam Function:

- For stubborn wrinkles, press the "Steam Burst" button. A powerful burst of steam will be released.
- Wait a few seconds between bursts to allow the steam chamber to reheat.

Vertical Steam:

- The burst of steam function can also be used for vertical steaming of hanging garments, drapes, or upholstery.
- Hold the iron vertically, about 1-2 inches away from the fabric, and press the "Steam Burst" button.

3-WAY AUTOMATIC SHUT OFF

8

Minutes Vertically



30

Seconds Horizontally



30

Seconds Tipped over



Figure 3: Using the vertical steam function.

Dry Ironing:

- Set the steam control to the "Dry Ironing" position.
- Select the desired temperature using the thermostat dial.
- Once the indicator light turns off, the iron is ready for dry ironing.

Automatic Shut-Off:

For safety, the iron will automatically turn off if left idle:

- After 30 seconds if left horizontally or tipped over.
- After 8 minutes if left vertically on its heel rest.

To reactivate the iron, simply move it. The indicator light will illuminate again as it reheat to the set temperature.

SPECIFICATION



Weight 2.5lbs



Power Cord 8ft



11.8oz(350ml)




Figure 4: Understanding the 3-way automatic shut-off feature.

MAINTENANCE AND CARE

Self-Cleaning Function:

The self-cleaning function helps remove mineral deposits and impurities from the steam chamber. Perform this function regularly, especially if you notice reduced steam output or white flakes.

1. Fill the water tank to the "MAX" line.
2. Plug in the iron and set the temperature dial to "MAX".
3. Once the indicator light turns off, unplug the iron.
4. Hold the iron horizontally over a sink.
5. Press and hold the "Self Clean" button. Hot water and steam will be expelled from the soleplate, flushing out impurities.
6. Gently shake the iron back and forth until the water tank is empty.
7. Plug the iron back in and heat it to dry the soleplate.
8. Unplug and store once cooled.

Cleaning the Soleplate:

- Ensure the iron is unplugged and completely cool.
- Wipe the soleplate with a damp cloth and a non-abrasive liquid cleaner if necessary.
- Do not use abrasive scouring pads or metal cleaners as they can damage the ceramic coating.

DURABLE CERAMIC COATED SOLEPLATE

Glides smoothly over all fabric and easy to clean




Figure 5: The durable ceramic coated soleplate.

Storage:

- Always unplug the iron and allow it to cool completely before storing.
- Empty any remaining water from the tank.
- Wrap the power cord neatly around the cord wrap area (if available) or secure it with a tie.
- Store the iron upright on its heel rest to prevent damage to the soleplate.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Iron does not heat up.	Not plugged in; power outlet faulty; auto shut-off activated.	Check power connection; try another outlet; move the iron to reactivate.

Problem	Possible Cause	Solution
No steam or insufficient steam.	Water tank empty; temperature too low; steam vents clogged.	Fill water tank; set temperature to steam-appropriate setting; perform self-cleaning.
Water leaking from soleplate.	Temperature too low for steam; water tank overfilled; steam control not set correctly.	Increase temperature; do not overfill; ensure steam control is off for dry ironing or set correctly for steam.
White flakes or residue on clothes.	Mineral build-up in water tank/steam chamber.	Perform self-cleaning function. Use distilled water if tap water is very hard.

SPECIFICATIONS

Feature	Detail
Brand	BEAUTURAL
Model Name	Steam Iron
Special Features	Auto Shutoff, Corded, Non-Stick, Self-Cleaning
Color	Blue
Product Dimensions	11.4" L x 4.72" W
Item Weight	2.52 pounds
Base Material	Ceramic
Included Components	Water Measuring Cup

WARRANTY AND SUPPORT

This BEAUTURAL Steam Iron comes with a Manufacturer Warranty. Please refer to the warranty documentation included with your purchase for specific terms and conditions.

For product support, troubleshooting assistance, or warranty claims, please contact BEAUTURAL customer service. You can often find contact information on the official BEAUTURAL website or through the retailer where you purchased the product.

Visit the official [BEAUTURAL Store on Amazon](#) for more information and products.

© 2024 BEAUTURAL. All rights reserved.

Related Documents - Steam Iron

	<p>BEAUTURAL Travel Steam Iron - Instruction Manual and User Guide</p> <p>Comprehensive guide for the BEAUTURAL Travel Steam Iron (Model MR08US05), covering safety, operation, cleaning, and maintenance for optimal performance.</p>
---	--

	<p>Beatural Steam Iron Instruction Manual: Features, Operation, and Safety</p> <p>Comprehensive instruction manual for the Beatural Steam Iron (Model 724UK-0001, 724EU-0001). Learn about safety features, how to use, care, cleaning, specifications, and troubleshooting.</p>
	<p>BEAUTURAL Steam Iron: User Manual and Operating Guide</p> <p>Official instruction manual for the BEAUTURAL Steam Iron (Models 724UK-0001, 724EU-0001). Learn about safety, operation, steam functions, cleaning, and maintenance from 1byone Products Inc.</p>
	<p>BEAUTURAL Steam Iron (YPZ-801) - Instruction Manual</p> <p>This comprehensive instruction manual for the BEAUTURAL Steam Iron (model YPZ-801) provides essential safety information, detailed operating instructions, and maintenance tips from manufacturer 1byone. Learn to effectively use steam functions, set precise temperatures for various fabrics, and care for your appliance for optimal garment results.</p>
	<p>BEAUTURAL 1800W Steam Iron Instruction Manual</p> <p>Comprehensive instruction manual for the BEAUTURAL 1800W Steam Iron, covering safety instructions, getting started, how to use, steam settings, troubleshooting, and specifications. Learn about polarized plugs, tamper-resistant screws, and maintenance for your household steam iron.</p>
	<p>Beatural Steam Iron Instruction Manual and Safety Guide</p> <p>Comprehensive instruction manual for the Beatural Steam Iron (Model 1-MR08US03), covering safety, usage, features, maintenance, troubleshooting, and specifications.</p>