

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [VOGOE](#) /

> [VOGOE ES300 Electric Shaver for Women Instruction Manual](#)

VOGOE ES300

VOGOE ES300 Electric Shaver for Women Instruction Manual

Model: ES300 | Brand: VOGOE

INTRODUCTION

The VOGOE ES300 Electric Shaver is designed for effective and comfortable hair removal on various body areas. It features a 3D floating blade system, self-sharpening stainless steel blades, and a powerful rotary motor for a close shave. This device supports both wet and dry use and is equipped with a durable rechargeable battery for portable operation.



Image: VOGOE ES300 Electric Shaver with its retail packaging, highlighting key features.

SAFETY INFORMATION

- Always use the brush to clean away hair and rinse the shaving head under running water.
- The white cap contains the charging port; prevent water from entering this area.
- If underarm hair is excessively long, it is recommended to trim it short with other tools before using the shaver to avoid skin pulling, redness, or swelling.
- Do not disassemble internal blade parts.
- Do not use the device while it is charging.
- Ensure the charging port is dry before connecting the charging cable.



Image: Visual representation of important safety guidelines, including avoiding disassembly, not using while charging, and keeping the charging port dry.

PACKAGE CONTENTS

Please check the package to ensure all items are present:


- VOGOE ES300 Electric Shaver
- USB Type-C Charging Cable
- Cleaning Brush
- User Manual
- 1 AA battery (pre-installed or included)


SETUP

Charging the Device

Before first use, fully charge the shaver. The VOGOE ES300 uses a 550mAh lithium-ion battery.

1. Locate the Type-C charging port on the device. Ensure the port is dry.
2. Connect the provided USB Type-C cable to the shaver and a suitable USB power adapter (not included).
3. A full charge takes approximately 1.5 hours. A 5-minute quick charge provides enough power for one use.
4. The power indicator light will show charging status (e.g., red for charging, green for fully charged).





DOUBLE-RING KNIFE NET

INCREASE THE CONTACT AREA BY 50%, MAKE SHAVE MORE CLEANER AND FASTER

TYPE-C FAST CHARGING

LONG-LASTING BATTERY LIFE, CARRY IT WITH YOU, TRAVEL WORRY-FREE



IPX6 WATERPROOF

RINSE DIRECTLY, DRY AND WET DOUBLE SHAVE, EASY TO CLEAN

Image: Close-up of the Type-C charging port and the shaver connected to a charging cable.

OPERATING INSTRUCTIONS

Power On/Off

Press the single power button located on the front of the shaver to turn it on or off. The indicator light will illuminate when the device is active.



Image: Close-up of the power button with an illuminated ring.

Wet and Dry Use

The VOGOE ES300 is designed for both wet and dry shaving, offering flexibility based on your preference.

- **Wet Shaving:** For a more comfortable experience, use the shaver with water, foam, or gel. This can help soften hair and reduce friction.
- **Dry Shaving:** For quick touch-ups or when water is not available, the shaver can be used directly on dry skin.



Image: Depiction of the shaver being used for both wet shaving in a bath and dry shaving on a couch.

Shaving Technique

For optimal results and to prevent irritation, follow these guidelines:

1. **Preparation:** For best results, especially on sensitive areas, consider warming and softening the skin with a hot towel before shaving.
2. **Application:** Gently press the shaver against your skin.
3. **Motion:** Move the shaver in small, circular motions. Avoid straight-line strokes, as circular motions are more effective for capturing hair and providing a smooth finish.
4. **Coverage:** The 3D floating blades and double-ring knife net are designed to adapt to body contours and cover more area efficiently.




Image: Steps for pre-shave preparation using a hot towel and demonstrating the recommended circular shaving motion.



Image: Illustrates the correct circular shaving motion versus an incorrect straight-line motion for optimal results.



Image: Diagram illustrating how the shaver's design allows it to cover a larger area during use.

Applicable Body Areas

The VOGOE ES300 is suitable for hair removal on various parts of the body:

- Arms
- Legs
- Bikini Line
- Face (e.g., upper lip, chin)
- Underarms (ensure hair is trimmed short if necessary)





Image: Visual guide showing the shaver being used on the face, arms, bikini area, and legs.

Cleaning the Shaver

Regular cleaning ensures optimal performance and hygiene.

1. Turn off the shaver.
2. The blade cover is attached magnetically for easy removal. Gently detach the shaving head.
3. Use the provided cleaning brush to remove any trapped hair from the blades and the shaver body.
4. Rinse the shaving head directly under running water. The device has an IPX6 waterproof rating, allowing for easy rinsing.
5. Ensure the shaving head is completely dry before reattaching it to the shaver body.
6. Do not immerse the entire shaver body in water, especially the charging port area.





DOUBLE-RING KNIFE NET

INCREASE THE CONTACT AREA BY 50%, MAKE SHAVE MORE CLEANER AND FASTER

TYPE-C FAST CHARGING

LONG-LASTING BATTERY LIFE, CARRY IT WITH YOU, TRAVEL WORRY-FREE



IPX6 WATERPROOF

RINSE DIRECTLY, DRY AND WET DOUBLE SHAVE, EASY TO CLEAN

Image: Demonstrates rinsing the detachable shaving head under running water for cleaning.



Image: Exploded view showing the individual components of the shaver head for detailed cleaning and understanding.

Blade Care

The VOGOE ES300 features self-sharpening blades, which maintain their sharpness with regular use. This eliminates the need for frequent blade replacement.

SHARPER EVERY TIME

Self-Sharpener blade innovation




Image: Diagram showing the self-sharpening process of the blades, maintaining sharpness over time.

TROUBLESHOOTING

- **Shaver not turning on:** Ensure the device is fully charged. If the battery is low, connect it to the charger.
- **Poor shaving performance:**
 - Clean the shaving head thoroughly to remove any accumulated hair or debris.
 - Ensure you are using the correct circular shaving motion.
 - If shaving long hair, especially in sensitive areas like underarms, trim the hair shorter before using the shaver to prevent pulling.
- **Skin irritation:**
 - Ensure the shaving head is clean.
 - Try wet shaving with foam or gel for increased comfort.
 - Avoid excessive pressure on the skin.
- **Charging issues:**
 - Verify the charging cable is securely connected to both the shaver and the power source.
 - Ensure the charging port is dry before connecting the cable.
 - Try a different USB power adapter or cable.

SPECIFICATIONS

Model Number	ES300
Brand	VOGOE
Power Source	Battery Powered
Battery Type	Lithium-ion (550mAh)
Charging Time	Approx. 1.5 hours for full charge, 5 minutes for one use
Waterproof Rating	IPX6 (Rinsable head)
Product Dimensions	6.1 x 4.31 x 2.76 inches

Item Weight	5.29 ounces (approx. 145 grams)
Wattage	5 watts
Included Components	Battery (included)

EASY TO OPERATE WITH ONE HAND

Comfortable feel, compact design, elegant and portable




Image: Diagram illustrating the dimensions of the shaver and its main components, including the single button and charging port.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official VOGOE website. Keep your purchase receipt as proof of purchase. You can also visit the [VOGOE Store on Amazon](#) for more product information and support.