

Calphalon 2099742

Calphalon ActiveSense 1200-Watt Countertop Blender with Blend-n-Go Cup

Model: 2099742

INTRODUCTION

This manual provides essential instructions for the safe and efficient operation, maintenance, and care of your Calphalon ActiveSense 1200-Watt Countertop Blender. Please read all instructions thoroughly before first use and retain this manual for future reference.

The Calphalon ActiveSense Blender is designed to deliver precisely blended results using ActiveSense technology, which automatically adjusts blade speed, direction, and blend timing. It includes a 2-liter blending jar and a 24-ounce Blend-n-Go smoothie cup for versatile use.

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before operating the blender.
- Do not immerse the motor base in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been dropped or damaged in any manner.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter or touch hot surfaces.
- Keep hands and utensils out of container while blending to prevent the possibility of severe injury to persons or damage to the blender. A scraper may be used but must be used only when the blender is not running.
- Blades are sharp. Handle with care.
- Always operate blender with lid in place.
- Do not blend hot liquids.

COMPONENTS OVERVIEW

Your Calphalon ActiveSense Blender includes the following components:

- Motor Base
- Tritan Blending Jar (2 Liters)
- Lid for Blending Jar
- Blade Assembly
- 24-Oz Blend-n-Go Cup
- Blend-n-Go Cup Lid



Image: Calphalon ActiveSense Blender with its main components. The large blending jar is shown with various fruits, and the smaller Blend-n-Go cup contains a blended smoothie, ready for portable use.

SETUP AND FIRST USE

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging materials for storage or future

transport.

2. **Cleaning:** Before first use, wash the blending jar, lid, blade assembly, Blend-n-Go cup, and its lid in warm, soapy water. Rinse thoroughly and dry. The blending jar, Blend-n-Go cup, and their lids are dishwasher safe. The blade assembly can also be disassembled for thorough cleaning.
3. **Motor Base:** Wipe the motor base with a damp cloth. Do not immerse the motor base in water.
4. **Assembly (Blending Jar):**
 - Place the blade assembly onto the motor base.
 - Ensure the rubber gasket on the blade assembly is properly seated to prevent leaks. (*Refer to Troubleshooting if leaks occur.*)
 - Place the blending jar onto the motor base, aligning it correctly.
 - Add ingredients to the blending jar. Do not exceed the maximum fill line.
 - Securely place the lid on the blending jar.
5. **Assembly (Blend-n-Go Cup):**
 - Add ingredients directly into the Blend-n-Go cup.
 - Attach the blade assembly to the Blend-n-Go cup by twisting it securely.
 - Invert the cup and place it onto the motor base, aligning it correctly.
6. **Power Connection:** Plug the blender into a standard 110-volt electrical outlet.

OPERATING INSTRUCTIONS

Digital Interface and Controls

The blender features a digital interface for intuitive control. The main controls include:

- **Food Mode:** Select from 5 preset food settings: Smoothie, Salsa, Milkshake, Frozen Drink, and Juice.
- **Thickness:** Adjust consistency for thick or thin results.
- **Speed Settings:** High, Medium, Low.
- **Power:** Turns the blender on/off.
- **Pulse:** Provides short bursts of blending power.
- **Start/Pause:** Initiates or pauses the blending cycle.



Image: A detailed view of the blender's digital interface, highlighting the various food mode presets and thickness selection options for customized blending.

Using ActiveSense Technology

ActiveSense technology automatically senses the load of ingredients and adjusts blade speed, direction, and blend timing to achieve optimal results. This ensures consistent blending without constant monitoring.



Image: The Calphalon ActiveSense Blender in operation, demonstrating its ability to create perfectly blended frozen drinks, emphasizing the automatic adjustment feature.

Blending Process

1. Ensure the blending jar or Blend-n-Go cup is properly assembled and secured on the motor base.
2. Add your desired ingredients. For best results, add liquids first, then soft ingredients, followed by leafy greens, and finally ice or frozen ingredients.
3. Select your desired Food Mode (e.g., Smoothie, Salsa) and Thickness setting (Thick or Thin).
4. Press the Start button. The blender will begin its cycle, automatically adjusting as needed.
5. The "Add Liquid" indicator may appear if more liquid is needed to achieve the desired consistency. If this occurs, add liquid and press Start to resume.
6. Once the cycle is complete, the blender will stop automatically.
7. Unplug the blender before removing the jar or cup.




Image: The blender's digital display showing the "Add Liquid" indicator, prompting the user to add more liquid for optimal blending consistency.

Using the Blend-n-Go Cup

The 24-ounce Blend-n-Go cup allows for convenient blending and portability.

1. Add ingredients directly into the Blend-n-Go cup.
2. Attach the blade assembly to the cup by twisting it firmly until secure.
3. Invert the cup and place it onto the motor base, ensuring it locks into position.
4. Select your desired blending mode and start the cycle.
5. Once blending is complete, remove the cup from the base, detach the blade assembly, and replace it with the Blend-n-Go cup lid for transport.



Image: A user holding the 24-ounce Blend-n-Go cup, demonstrating its portability after blending a green smoothie.

MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the life of your blender.

- **Always unplug the blender before cleaning.**
- **Blending Jar and Blend-n-Go Cup:** These components, along with their lids, are dishwasher safe. For manual cleaning, wash in warm, soapy water, rinse, and dry thoroughly.
- **Blade Assembly:** The blade assembly can be disassembled for thorough cleaning. Exercise caution as blades are sharp. Wash with warm, soapy water, rinse, and dry. Ensure the rubber gasket is clean and properly re-seated after cleaning to prevent leaks.
- **Motor Base:** Wipe the motor base with a damp cloth. Do not immerse in water or spray with liquids.
- **Storage:** Store the blender in a clean, dry place.

TROUBLESHOOTING

If you encounter issues with your Calphalon ActiveSense Blender, refer to the following common problems and solutions:

- **Blender does not turn on:**
 - Ensure the power cord is securely plugged into a working electrical outlet.
 - Verify that the blending jar or Blend-n-Go cup is correctly assembled and seated on the motor base. The blender has safety features that prevent operation if not properly assembled.
- **Blender is leaking:**
 - Check the blade assembly. The rubber gasket must be properly seated and flush with the base of the blade assembly. If it is dislodged, carefully re-seat it.
 - Ensure the blade assembly is tightly screwed onto the blending jar or Blend-n-Go cup.
 - Do not overfill the blending jar or cup beyond the maximum fill line.
- **Ingredients are not blending properly / "Add Liquid" indicator appears:**
 - The "Add Liquid" indicator suggests that the mixture is too thick. Add more liquid (water, milk, juice, etc.) to the ingredients.
 - Ensure ingredients are cut into appropriate sizes.
 - For thick mixtures, use the Pulse function to break down larger pieces before running a full cycle.
 - The ActiveSense technology will attempt to adjust, but very dense mixtures may require manual intervention.
- **Blender stops during operation:**
 - The blender may have overheated. Unplug the unit and allow it to cool down for at least 10-15 minutes before attempting to use it again.
 - Check for any obstructions that might be jamming the blades.

SPECIFICATIONS

Brand	Calphalon
Model Number	2099742
Power Source	Electric
Motor Wattage	1200 Watts
Voltage	110 Volts
Capacity (Blending Jar)	2 Liters
Capacity (Blend-n-Go Cup)	24 Ounces
Product Dimensions	12.13"D x 10.13"W x 15.88"H
Item Weight	9.4 pounds
Blade Material	Stainless Steel
Controls Type	Digital
Special Feature	Programmable, ActiveSense Technology
Material Type Free	BPA Free

WARRANTY INFORMATION





This Calphalon ActiveSense Blender is covered by a **Limited Warranty**. For specific details regarding warranty coverage, duration, and terms, please refer to the warranty card included with your product or visit the official Calphalon website. Keep your purchase receipt as proof of purchase for warranty claims.

CUSTOMER SUPPORT

For further assistance, product registration, or to purchase replacement parts, please visit the official Calphalon website or contact their customer service department. Contact information can typically be found on the product packaging or the Calphalon website.
Online Support: www.calphalon.com/support (Example link, actual link may vary)

© 2024 Calphalon. All rights reserved.


Related Documents - 2099742

	<p>Calphalon Auto Speed Blender Instruction Manual (Model BLCLMB1)</p> <p>Comprehensive instruction manual for the Calphalon Auto Speed Blender, Model BLCLMB1. Includes important safety precautions, detailed usage guides for pre-programmed and manual settings, cleaning and maintenance procedures, troubleshooting tips, and warranty information.</p>
	<p>Calphalon Quartz Heat Countertop Oven User Manual</p> <p>User manual for the Calphalon Quartz Heat Countertop Oven, providing safety instructions, cleaning and maintenance guidelines, product diagram, and operating instructions.</p>
	<p>Calphalon Performance Air Fry Countertop Oven Instruction Manual</p> <p>Instruction manual for the Calphalon Performance Air Fry Countertop Oven, Model TSCLTRDG1-AFS-026. Includes important safeguards, product diagram, usage instructions, cooking functions details, cleaning and maintenance, troubleshooting, and warranty information.</p>
	<p>Calphalon Cool Touch Countertop Oven Instruction Manual (TSCLTVCT2)</p> <p>Comprehensive instruction manual for the Calphalon Cool Touch Countertop Oven (Model TSCLTVCT2), covering setup, operation, functions, cleaning, maintenance, and troubleshooting.</p>



[Calphalon 14-Cup Programmable Coffeemaker Instruction Manual](#)

Comprehensive instruction manual for the Calphalon 14-Cup Programmable Coffeemaker (Model BVCL-JJ100-A). Learn about important safety precautions, setup, brewing, cleaning, maintenance, and warranty information.



[Calphalon 14 Cup Programmable Coffeemaker Instruction Manual](#)

Comprehensive instruction manual for the Calphalon 14 Cup Programmable Coffeemaker, detailing important safeguards, setup, operation, cleaning, decalcifying, and warranty information.