

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [SupplySource](#) /

› SupplySource AC Adapter User Manual for GOOLOO GP180 Jump Starter

SupplySource GP180

SupplySource AC Adapter User Manual for GOOLOO GP180 Jump Starter

Model: GP180 Compatible AC Adapter

INTRODUCTION

This manual provides essential instructions for the safe and effective use of your SupplySource AC Adapter, designed for compatibility with the GOOLOO 700A GP180 GPower180 Peak Car Jump Starter Power Bank PSU.

Please read this manual thoroughly before using the product and retain it for future reference.

SAFETY INFORMATION

Your SupplySource AC Adapter is manufactured with high-quality materials and incorporates multiple safety features to protect against:

- **Incorrect Voltage (IV)**
- **Short Circuit (SC)**
- **Internal Overheating (IO)**

The charger is certified with CE and FCC standards, ensuring compliance with safety regulations.

BUILT IN WITH SAFETY ELECTRONICS



Over Charge Protection



Over Voltage Protection



Short-circuit Protection



Over Current Protection



Over Temp Protection



24 Months Warranty



Image Description: A black AC adapter is shown alongside a list of its built-in safety electronics. These include protections against overcharge, over voltage, short-circuit, over current, and over temperature. A '24 Months Warranty' icon is also displayed.

Important Safety Notices:

- Ensure the DC output and tip size of the AC adapter match the requirements of your device before connecting.
- When using the adapter for extended periods, ensure adequate ventilation and humidity control. Avoid placing it on heat-sensitive surfaces or materials.
- Do not disassemble or modify the adapter.
- Keep out of reach of children.

PACKAGE CONTENTS

- 1 x SupplySource AC Adapter

SETUP

1. **Verify Compatibility:** Before connecting, confirm that the DC output voltage and connector tip size of this SupplySource AC Adapter are compatible with your GOOLOO 700A GP180 GPower180 Jump

Starter. Refer to your jump starter's manual for specific power requirements.

2. **Inspect Adapter:** Visually inspect the AC adapter and its cable for any signs of damage. Do not use if damaged.
3. **Connect to Device:** Insert the barrel connector of the AC adapter firmly into the charging port of your GOOLOO GP180 Jump Starter.
4. **Connect to Power Outlet:** Plug the AC adapter into a standard 100-240V AC wall outlet.
5. **Charging Indication:** Your jump starter should indicate that it is receiving power or charging. Refer to your jump starter's manual for specific charging indicators.



Image Description: A black AC adapter is shown with its power cord neatly coiled and secured by a black hook-and-loop strap. The adapter features a standard US two-prong plug.

This AC adapter is designed to provide power for charging compatible devices. Once connected as described in the Setup section, the adapter will supply power to your GOOLOO GP180 Jump Starter.

- Ensure the adapter is securely plugged into both the wall outlet and the device.
- Monitor your device's charging status as per its own instructions.
- Disconnect the adapter from the wall outlet and the device once charging is complete or if the device is not in use.

MAINTENANCE

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or aerosols.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures. When storing, coil the cable neatly without sharp bends or kinks.
- **Ventilation:** Ensure the adapter has adequate ventilation during use. Do not cover it or place it in an enclosed space that could lead to overheating.
- **Cable Care:** Avoid pulling the cable forcefully or bending it sharply, especially near the connectors, to prevent internal damage.

TROUBLESHOOTING

If you encounter issues with your AC adapter, please refer to the following common solutions:

- **Device Not Charging:**
 - Ensure the adapter is securely plugged into both the wall outlet and the device.
 - Verify the wall outlet is functional by testing it with another device.
 - Confirm the adapter's DC output and tip size are correct for your device.
 - Check the adapter cable and connectors for any visible damage.
- **Adapter Overheating:**
 - Disconnect the adapter immediately.
 - Ensure it is placed in a well-ventilated area, not covered by anything.
 - If overheating persists, discontinue use and contact support.

SPECIFICATIONS

Feature	Detail
Model Compatibility	GOOLOO GP180
Brand	SupplySource
Input Voltage Range	100-240V AC
Input Frequency	50-60Hz
Connector Type	Barrel Connector
Compatible Devices	GOOLOO 700A GP180 GPower180 Peak Car Jump Starter Power Bank PSU

Certifications	CE, FCC
Materials	Metal, Plastic
Cable Length	Approximately 4 feet (1.2 meters)



Image Description: A side-by-side comparison showing the compact size of the AC adapter when held in a hand, and a measurement indicating the cable length is 4 feet (L: 4 Ft).

WARRANTY AND SUPPORT

This SupplySource product is typically backed by a warranty. Please refer to the product packaging or your purchase documentation for specific warranty terms and duration. For technical support or warranty claims, please contact your retailer or the manufacturer directly.

Manufacturer: SupplySource

Date First Available: July 16, 2019

