

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Ninestars](#) /

› [Ninestars AMZ-SOT-50-3 Step-on Trashcan User Manual](#)

Ninestars AMZ-SOT-50-3

Ninestars AMZ-SOT-50-3 Step-on Trashcan User Manual

Model: AMZ-SOT-50-3

INTRODUCTION

Thank you for choosing the Ninestars AMZ-SOT-50-3 Step-on Trashcan. This 13-gallon (50L) semi-round trash can is constructed from fingerprint-resistant stainless steel and features a convenient step-on pedal for hands-free operation. This manual provides essential information for the proper setup, operation, maintenance, and troubleshooting of your new trash can.





Image: The Ninestars AMZ-SOT-50-3 13-gallon stainless steel step-on trash can.

PRODUCT FEATURES

- **High-Quality Materials:** Constructed from commercial-grade T430 fingerprint-resistant stainless steel for durability and a clean appearance.
- **Hands-Free Operation:** Features a sturdy steel foot pedal for easy lid opening, allowing for hygienic waste disposal.
- **Soft-Close Lid:** The lid closes smoothly and softly, minimizing noise and preventing sudden slams.
- **Large Capacity:** With a 13-gallon (50L) capacity and a wide opening, it is suitable for kitchens and larger households.
- **Stay-Open Lid Function:** The lid can be manually pushed up to a 90-degree angle to remain open, facilitating larger tasks or easy trash bag removal.
- **Removable Inner Bucket:** Includes a removable inner bucket for convenient cleaning and secure trash bag placement.
- **Non-Skid Base:** Equipped with a non-skid base to prevent movement and protect flooring.

NINESTARS®

Half Moon Design, Full Size Function

SOT-50-3
13.2 Gallon/50 Liters
Step On Trash Can



Image: The semi-round design of the trash can, highlighting its functional shape.

NINESTARS®



Step On
Trash Can



Durable
Handle



13.2 Gallon
50 Liters



2 Year
Guarantee



Image: Close-up of the durable step-on pedal and soft-close lid mechanism.

SETUP

- Unpack:** Carefully remove all components from the packaging. Ensure all parts are present: the outer stainless steel can, the inner plastic bucket, and the lid assembly.
- Position:** Place the trash can on a flat, stable surface in your desired location. The semi-round shape is designed to fit flush against a wall or cabinet.
- Insert Inner Bucket:** Place the black plastic inner bucket inside the stainless steel outer can. Ensure it sits securely at the bottom.
- Attach Trash Bag:** Drape a standard 13-gallon trash bag over the rim of the inner bucket. Tuck the edges of the bag neatly into the designated slots or under the rim of the inner bucket to secure it and prevent it from showing when the lid is closed.
- Close Lid:** Gently lower the lid onto the can. It should align properly with the outer can.

Durable Step On Pedal



Durable Pedal



Soft Close Lid

Image: The trash can with its lid open, revealing the removable inner bucket ready for a trash bag.

OPERATING INSTRUCTIONS

1. **Opening the Lid (Hands-Free):** Gently press down on the foot pedal located at the base of the front of the trash can. The lid will open smoothly. Release the pedal to allow the lid to close softly.
2. **Using the Stay-Open Feature:** For tasks requiring the lid to remain open for an extended period, manually push the lid upwards until it reaches a 90-degree angle. It will stay in this position. To close, gently push the lid downwards.
3. **Disposing of Waste:** Place waste into the inner bucket. Ensure not to overfill the can, as this may prevent the lid from closing properly.
4. **Removing a Full Trash Bag:** When the trash bag is full, use the stay-open feature to keep the lid open. Lift the inner bucket by its handle (if applicable) or carefully pull the trash bag out. Tie the bag securely before disposal.

5. **Replacing a Trash Bag:** After removing the full bag, place a new 13-gallon trash bag into the inner bucket, securing its edges as described in the Setup section.

Your browser does not support the video tag.

Video: Demonstration of the step-on pedal and soft-close lid functionality of the Ninestars trash can.

Your browser does not support the video tag.

Video: Demonstration of removing and replacing the inner bucket and trash bag.

MAINTENANCE AND CARE

- **Cleaning the Exterior:** The stainless steel exterior is fingerprint-resistant. Wipe with a soft, damp cloth and a mild stainless steel cleaner if necessary. Avoid abrasive cleaners or scrubbers that could scratch the finish.
- **Cleaning the Inner Bucket:** The removable inner bucket can be washed with soap and water. Rinse thoroughly and dry completely before placing it back into the outer can.
- **Lid Mechanism:** Periodically check the lid's hinge and pedal mechanism for any debris or obstructions. Keep these areas clean to ensure smooth operation.
- **Odor Control:** To minimize odors, ensure trash bags are tied securely and replaced regularly. The lid is designed to help contain odors when closed.



Image: The trash can featuring a convenient handle on the back for easy relocation and cleaning.

TROUBLESHOOTING

Lid not closing smoothly:

Check the hinge mechanism for any obstructions or debris. Ensure the inner bucket and trash bag are not interfering with the lid's path. The soft-close mechanism may require occasional cleaning or lubrication if it becomes stiff.

Lid not opening fully with pedal:

Inspect the pedal mechanism for any blockages. Ensure the can is placed on a level surface and the pedal is not obstructed by surrounding objects.

Unpleasant odors persist:

Ensure trash bags are securely tied and replaced frequently. Clean the inner bucket thoroughly. Consider using odor-absorbing products inside the can if odors persist.

Can slides on floor:

Verify that the non-skid base is clean and intact. Ensure the can is placed on a dry, level surface. Avoid placing it on

very slick or uneven flooring.

SPECIFICATIONS

Feature	Detail
Brand	Ninestars
Model Number	AMZ-SOT-50-3
Capacity	13 Gallons (50 Liters)
Color	Stainless Steel
Opening Mechanism	Step-On Pedal
Material	T430 Stainless Steel
Product Dimensions	19.09"L x 14.48"W x 25.2"H
Item Weight	11 pounds (5 Kilograms)
Special Features	Leakproof, Removable Bucket, Smudge Resistant, Stain Resistant, Sturdy, Soft-Close Lid, Non-Skid Base
Recommended Use	Indoor, Kitchen

Specs

NINESTARS®



Image: Detailed dimensions of the Ninestars 13-gallon semi-round step-on trash can.

WARRANTY AND SUPPORT

This Ninestars trash can is covered by a **2-year manufacturer's warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

For technical support, warranty service, or replacement parts, please contact Ninestars customer service through their official website or the retailer where the product was purchased.



Image: Icon indicating a 2-year product guarantee.