

Backyard Discovery 1605022D

Backyard Discovery Beach Front Cedar Wood Swing Set Instruction Manual

Model: 1605022D

Brand: Backyard Discovery

PRODUCT OVERVIEW

The Backyard Discovery Beach Front Cedar Wood Swing Set is an outdoor playset designed for children aged 36 months to 10 years. It features a raised play deck with a canopy, a wave slide, monkey bars, a rock wall ladder, belt swings, a trapeze, and a shaded sandbox area with a snack bar. This playset is constructed from 100% cedar wood, known for its durability and natural resistance to decay.




Image: An overview of the Backyard Discovery Beach Front Cedar Wood Swing Set, showing children utilizing the various play features including swings, slide, and elevated deck.

SETUP AND ASSEMBLY

This swing set is designed for home assembly. Components are pre-cut, pre-drilled, and pre-stained to facilitate the process. For detailed, step-by-step instructions, it is recommended to use the interactive BILT app, which provides guided assembly. While the BILT app is a valuable resource, the included written instructions should also be consulted for accuracy, as hardware numbers or pre-drilled holes may occasionally vary between digital and printed guides.

- **Preparation:** Before beginning assembly, organize all parts by their part numbers. This step significantly reduces assembly time.
- **Tools:** Power tools and other standard hand tools are required for assembly. Ensure all necessary tools are available before starting.
- **Team Lift:** Due to the size and weight of certain components, a "Team Lift" is required for safe handling and installation. Do not attempt to lift heavy sections alone.
- **Wood Characteristics:** Cedar wood, while durable, can be soft. Minor splitting may occur during assembly, particularly on decorative or non-structural pieces. This typically does not affect the overall sturdiness.
- **Grounding Stakes:** Holes for grounding stakes may not be pre-drilled, allowing for flexible placement based on your specific installation needs.



BEACH FRONT SWING SET




Image: Technical drawing illustrating the top and front view dimensions of the Beach Front Swing Set, including the recommended safe play zone.

OPERATING INSTRUCTIONS AND SAFETY GUIDELINES

The Beach Front Swing Set offers multiple play areas for children. It is designed to accommodate up to 8 children simultaneously and meets or exceeds ASTM standards (code F1148-22) for residential use only.

- **Elevated Play Deck:** The raised fort area features a colorful canopy roof, a ship's wheel, and a toy telescope. Children can engage in imaginative play in this elevated space.
- **Wave Slide:** An 8-foot wave slide provides a quick descent from the play deck. Ensure the landing area is clear before use.
- **Rock Wall Ladder:** Equipped with 6 climbing holds, this feature allows for safe ascent to the play deck. It also functions as a ladder for easier access.
- **Monkey Bars:** These provide a challenging activity that helps develop upper body strength and coordination.

- **Swings and Trapeze:** The set includes two classic belt swings and one trapeze. Ensure children are seated properly and hold on securely while swinging. Quick-link attachments allow for easy removal and storage of swings.
- **Lower Play Space:** A shaded sandbox area is located beneath the play deck. This space is ideal for creative sensory play (sand not included). A built-in snack bar window with picnic bench seating offers a designated area for breaks.

General Safety Precautions:

- Adult supervision is required at all times when children are using the playset.
- Ensure adequate clear space around the playset, as indicated in the safe play zone dimensions.
- Regularly inspect all components for wear, damage, or loose connections.
- Do not allow children to wear loose clothing, scarves, or items that could get caught on the equipment.
- This playset is for residential use only.



Image: A boy demonstrating the use of the monkey bars.



Image: Two children, one descending the wave slide and another climbing the rock wall.



Image: Children enjoying the belt swings and trapeze.



Image: Children on the elevated play deck, interacting with the steering wheel and telescope.

MAINTENANCE

Proper maintenance ensures the longevity and safety of your Backyard Discovery swing set.

- **Wood Care:** The playset is made from cedar wood, which is naturally resistant to decay. However, it is recommended to apply a water sealant annually to protect the wood from weathering and maintain its appearance. Note that stain saturation and color may vary over time.
- **Hardware Inspection:** Periodically check all nuts, bolts, and screws for tightness. Tighten any loose hardware to prevent structural instability.
- **Component Check:** Inspect all plastic and metal components, including swings, chains, slides, and climbing holds, for cracks, rust, or excessive wear. Replace any damaged parts immediately.
- **Grounding:** Ensure grounding stakes remain firmly in place to secure the playset.
- **Cleaning:** Clean the playset regularly with mild soap and water. Avoid harsh chemicals that could damage the wood or plastic.

TROUBLESHOOTING

This section addresses common concerns that may arise during the ownership of your swing set.

- **Wood Splitting:** Minor splits in the cedar wood can occur, especially during assembly or due to natural weathering. If a split appears on a structural component and compromises safety, contact customer support for guidance. Small, non-structural splits are generally cosmetic and do not affect integrity.
- **Loose Components:** If any parts feel loose after assembly or during use, re-tighten all associated hardware. Regular inspections can prevent this issue.
- **Missing or Damaged Parts:** In the event of missing hardware or damaged components upon delivery, refer to the contact information in the Support section to request replacements.
- **Creaking Sounds:** Some creaking may be audible, particularly when adults are on the play deck. This is often normal for wooden structures under load. Ensure all connections are tight and the playset is level. If creaking is excessive or accompanied by visible instability, discontinue use and inspect thoroughly.

SPECIFICATIONS

| Feature | Detail |
|--------------------------------|------------------------------------------------------------|
| Brand | Backyard Discovery |
| Model Number | 1605022D |
| Product Dimensions (D x W x H) | 173" x 169" x 118" |
| Frame Material | 100% Cedar Wood |
| Finish Type | Unfinished (Stained) |
| Item Weight | 77 pounds |
| Recommended Age | 36 months - 10 years |
| Safety Standards | Meets or exceeds ASTM standards (code F1148-22) |
| UPC | 752113605022 |
| What's in the Box | Hardware components, wood components, Accessory components |

WARRANTY INFORMATION

The Backyard Discovery Beach Front Cedar Wood Swing Set comes with an industry-leading **5-year warranty**. This warranty provides peace of mind regarding the quality and durability of the product. For specific terms, conditions, and to register your product, please refer to the warranty documentation included with your purchase or visit the official Backyard Discovery website.






SUPPORT AND CONTACT


For further assistance, technical support, or to order replacement parts, please utilize the following resources:

- **BILT App:** Download the interactive BILT app for 3D guided assembly instructions and troubleshooting tips.

- **Manufacturer Website:** Visit the official Backyard Discovery website for FAQs, product registration, and customer service contact details.
- **Customer Service:** Refer to the contact information provided in your product packaging for direct customer support.

Related Documents - 1605022D

| | |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>Assembly Instructions Product Dimensions 48" L x 36" W x 22" H</p> | <p>Naomi Home Kids Cedar Sandbox Assembly Instructions</p> <p>Detailed assembly instructions for the Naomi Home Kids Cedar Sandbox, including parts list, hardware, safety warnings, and step-by-step guidance. Learn how to build your sandbox safely and efficiently.</p> |
|  <p>KidKraft RIVER CANYON SWING SET</p> | <p>KidKraft River Canyon Swing Set: Installation and Operating Instructions</p> <p>Comprehensive guide for the KidKraft River Canyon Swing Set (Model F29910), covering installation, operation, safety, and maintenance. Ensure safe outdoor play for children aged 3-10.</p> |
|  <p>Assembly Instructions Product Dimensions 48" L x 36" W x 22" H</p> | <p>PetsCosset Wooden Sandbox Assembly Instructions & Care Guide</p> <p>Detailed assembly instructions and care guide for the PetsCosset Wooden Sandbox with Lid, featuring 2 foldable bench seats. Learn how to build and maintain your child's playset safely.</p> |
|  <p>avenlur Sycamore by Avenlur</p> | <p>Avenlur Sycamore Playset Assembly and Safety Manual</p> <p>Comprehensive assembly instructions, safety guidelines, and maintenance recommendations for the Avenlur Sycamore Playset. Learn how to safely install and care for your backyard playset.</p> |
|  <p>Installation, Maintenance, & User Manual Obstacle Course Swing Set Model SS9</p> | <p>SwingSesh SS9 Obstacle Course Swing Set: Installation, Maintenance, and User Manual</p> <p>Comprehensive guide for the SwingSesh SS9 Obstacle Course Swing Set, covering installation, maintenance, safety precautions, and user guidelines for safe and enjoyable play for users aged 12 and above. Includes detailed assembly steps, parts identification, and maintenance schedules.</p> |



Documents - Backyard Discovery – 1605022D



[\[pdf\] User Manual](#)

Paula Spanish Instruction Manuals Backyard Discovery INS 1605022D BEACH FRONT SP 05 23
backyarddiscovery sirv |||

Beach Front Columpios de Madera Modelo n. **1605022D** Manual del Propietario e
Instrucciones de Montaje FABRICADO POR: Backyard Discovery 3305 Airport Drive
Pittsburg, KS 66762 800-856-4445 GOCONFIGURE Ponemos todo a su disposicin
SERVICIOS DE INSTALACIN DISPONIBLES * Necesita ayuda Deje que nuest...
lang:es score:57 filesize: 10.44 M page count: 74 document date: 2024-01-08



[\[pdf\]](#) Instructions

Paula French Instruction Manuals Backyard Discovery INS 1605022D BEACH FRONT FR 05 23
backyarddiscovery sirv |||

Front de mer Modle no **1605022D** Balanoire en bois Manuel du proprietaire et
instructions de montage FABRIQU PAR : Backyard Discovery 3305 Airport Drive
Pittsburg, KS 66762 800-856-4445 GOCONFIGURE Tout mettre en ordre pour vous
dure de montage moyenne 2 personnes SERVICES D INSTALLATION DISPONIB...
lang:fr score:56 filesize: 10.96 M page count: 75 document date: 2024-01-08



[\[pdf\] User Manual Owner's Manual Installation Guide Instructions](#)

1605022B BEACH FRONT AI idw wsmalley English Instruction Manuals Backyard Discovery INS
1605022D ENG 05 23 backyarddiscovery sirv |||

Beach Front Wooden Swing Set Model # **1605022D** Owner s Manual Assembly
Instructions MANUFACTURED BY: Backyard Discovery 3305 Airport Drive Pittsburg,
KS 66762 800-856-4445 average 2 person assembly time assembly time may vary
based on skill level For the most up to date assembly manual, to regi...
lang:en score:54 filesize: 10.19 M page count: 75 document date: 2023-05-05



[pdf] Instructions Dimension Guide

Paula French Instruction Manuals INS 1605022D BEACH FRONT FR 07 28 23 backyarddiscovery sirv |||

Front de mer Modle no **1605022D** Balanoire en bois Manuel du proprietaire et instructions de montage FABRIQU PAR : Backyard Discovery 3305 Airport Drive Pittsburg, KS 66762 800-856-4445 dure de montage moyenne 2 personnes APPROX. Avant de commencer POUR UN MONTAGE RAPIDE ET FACILE VOUS TROUVEREZ L...

lang:fr score:46 filesize: 12.33 M page_count: 67 document date: 2024-06-17



[pdf] User Manual

Paula Spanish Instruction Manuals INS 1605022D BEACH FRONT SP 07 28 23 backyarddiscovery sirv |||

Beach Front Columpios de Madera Modelo n. **1605022D** Manual del Propietario e Instrucciones de Montaje FABRICADO POR: Backyard Discovery 3305 Airport Drive Pittsburg, KS 66762 800-856-4445 tiempo promedio de montaje entre 2 personas INTERMEDIO Antes de empezar PARA MONTAJE RPIDO Y FCIL ENCUENTRE ...

lang:es score:46 filesize: 11.92 M page_count: 67 document date: 2024-06-17



[pdf] User Manual Owner's Manual Instructions Dimension Guide Diagram

1605022B BEACH FRONT AI idw wsmalley English Instruction Manuals INS 1605022D ENG 07 28 23

backyarddiscovery sirv |||

Beach Front Wooden Swing Set Model # **1605022D** Owner s Manual Assembly Instructions MANUFACTURED BY: Backyard Discovery 3305 Airport Drive Pittsburg, KS 66762 800-856-4445 average 2 person assembly time assembly time may vary based on skill level For the most up to date assembly manual, to regi...

lang:en score:42 filesize: 7.81 M page_count: 67 document date: 2024-06-17



[pdf] User Manual Owner's Manual Instructions Dimension Guide Diagram

1605022B BEACH FRONT AI idw wsmalley 82ddf67f9877eb5fb39d41dbea0ff1dde78b9fb7 1assets wfcdn

dm document 45ea0b9c 4ae2 4da5 91f8 f2521745ec3a 1 |||

Beach Front Wooden Swing Set Model # **1605022D** Owner s Manual Assembly Instructions MANUFACTURED BY: Backyard Discovery 3305 Airport Drive Pittsburg, KS 66762 800-856-4445 average 2 person assembly time assembly time may vary based on skill level For the most up to date assembly manual, to regi...

lang:en score:11 filesize: 17.28 M page_count: 67 document date: 2023-08-16

