

[Manuals.plus](#) /

› [Bestol](#) /

› Bestol HUAYU RM-D703 Remote Control User Manual for Samsung TV and DVD Players

Bestol RM-D703

Bestol HUAYU RM-D703 Remote Control User Manual

For Samsung TV and DVD Players

INTRODUCTION

This manual provides instructions for the proper setup, operation, and maintenance of your Bestol HUAYU RM-D703 Remote Control. This remote is designed as a replacement or secondary control unit for various Samsung TV and DVD Player models, including 00084J/N/Q, 00061D/E/S/J, 00052G, DVD-1080P9, DVD-1080P8, and DVD-1080P8/XAA. It is pre-programmed for immediate use with compatible devices.

SETUP

1. Battery Installation

The remote control requires two (2) AA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Press down on the latch and slide the battery cover downwards to open it.
3. Insert two AA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



Image: Back view of the remote control with the battery compartment visible. This shows where to open the cover and insert the batteries.

2. Initial Use

This remote control is pre-programmed for compatible Samsung TV and DVD Player models. No additional programming is typically required. Once batteries are installed, point the remote at your device and begin operation.

OPERATING INSTRUCTIONS

The Bestol HUAYU RM-D703 remote control provides standard functions for your Samsung TV and DVD player.

Ensure there is a clear line of sight between the remote's infrared (IR) emitter and your device's IR receiver.



Image: Front view of the remote control, displaying the layout of all buttons for TV and DVD functions.

Basic Functions:

- **Power Button:** Turns the TV or DVD player on/off.
- **Number Buttons (0-9):** For direct channel selection or inputting numbers.
- **Volume Up/Down:** Adjusts the audio volume.
- **Channel Up/Down:** Changes TV channels.
- **Mute Button:** Silences the audio.
- **Input/Source Button:** Cycles through available input sources (HDMI, AV, etc.).
- **Navigation Buttons (Up, Down, Left, Right, Enter):** Used for menu navigation and selection.

DVD Player Functions:

Dedicated buttons are available for DVD player control:

- **Play/Pause:** Starts or pauses DVD playback.
- **Stop:** Stops DVD playback.
- **Fast Forward/Rewind:** Skips forward or backward through content.
- **Next/Previous Track:** Skips to the next or previous chapter/track.
- **Menu/Title:** Accesses the DVD menu or title screen.

MAINTENANCE

Cleaning the Remote:

To clean your remote control, use a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as

these can damage the remote's surface or internal components.

Battery Replacement:

Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new AA batteries. Do not mix old and new batteries, or different types of batteries.

TROUBLESHOOTING

Remote Not Responding:

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-).
- **Replace Batteries:** If batteries are old or depleted, replace them with fresh AA batteries.
- **Line of Sight:** Make sure there are no obstructions between the remote and the device's IR receiver. Point the remote directly at the device.
- **Distance:** Ensure you are within the effective operating range of the remote control.

Limited Functionality:

- This remote is specifically designed for Samsung TV and DVD players. Ensure your device is a compatible Samsung model.
- Some advanced functions specific to your original device's remote may not be available on this universal replacement.

SPECIFICATIONS

Brand	Bestol
Model	HUAYU RM-D703
Compatible Devices	Samsung Television, Samsung DVD Player (models: 00084J/N/Q, 00061D/E/S/J, 00052G, DVD-1080P9, DVD-1080P8, DVD-1080P8/XAA)
Special Features	Infrared, Pre Programmed
Battery Type	2 x AA (not included)
Connectivity Technology	Infrared
Dimensions	20 x 5.4 x 2.9 cm
Weight	87 g
ASIN	B07VD1JRVW

WARRANTY INFORMATION

Please refer to the product packaging or the retailer's website for specific warranty details regarding your Bestol HUAYU RM-D703 Remote Control. General warranty terms typically cover manufacturing defects for a limited period from the date of purchase.

SUPPORT

For further assistance or inquiries regarding your Bestol HUAYU RM-D703 Remote Control, please contact the retailer or manufacturer directly. You may find additional support resources on their official websites.

© 2026 Bestol. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07VD1JRVW>

More documents and user manuals: <https://manuals.plus/>