

## Noma 1513697

# Noma C9 LED Quick Clip Christmas Lights Instruction Manual

Model: 1513697

## INTRODUCTION

This manual provides essential instructions for the safe and efficient installation, operation, and maintenance of your Noma C9 LED Quick Clip Christmas Lights. Please read this manual thoroughly before use and retain it for future reference.

## SAFETY INFORMATION

- Always unplug the lights from the power source before installation, removal, or maintenance.
- Do not connect more than 22 strands end-to-end to avoid overloading.
- Ensure all connections are secure and protected from moisture.
- Do not mount or place near gas or electric heaters, fireplaces, candles, or other similar sources of heat.
- Do not secure the wiring of the product with staples or nails, or place on sharp hooks or nails.
- Do not let lamps rest on the supply cord or on any wire.
- Inspect the product carefully before each use. Discard any products that have cut, damaged, or frayed wire insulation or cords, cracked lampholders or enclosures, loose connections, or exposed copper wire.
- This product is intended for seasonal installation and removal.

## PACKAGE CONTENTS

- 1 x Noma C9 LED Quick Clip Christmas Lights Strand (100 Warm White Bulbs, 66.8 ft)
- Integrated Quick Clips

## SETUP AND INSTALLATION

The Noma C9 LED Quick Clip Christmas Lights are designed for easy installation on various surfaces, including rooflines, gutters, and tree branches, using the integrated quick clips.

## Step 1: Planning Your Display

Before installation, plan the layout of your lights. Each strand is 66.8 feet long and can be connected end-to-end with up to 22 strands for a total of 2,200 lights. Ensure your chosen location has access to a suitable power outlet.

## Step 2: Attaching the Lights

The lights feature built-in spring-loaded clips for secure attachment. These clips rotate 180 degrees, allowing for flexible light positioning.



Image: Noma C9 LED Quick Clip Christmas Lights securely attached to a snow-covered roofline using the integrated clips.

1. Identify the desired attachment point (e.g., gutter edge, roof shingle, tree branch).
2. Open the quick clip by pressing the spring-loaded mechanism.

3. Position the clip over the edge of the surface and release to secure.
4. Adjust the light bulb's direction by rotating the clip up to 180 degrees.



## Hang in Half the Time

Built-in spring loaded clips make installation quick & easy

Image: A hand demonstrating the attachment of a Noma Quick Clip light to a roof edge, highlighting the ease of installation.





## Adjustable Light Position

180 degree rotation allows you to easily adjust light position



## Built-In Spring Loaded Clip

Hang in half the time with built-in removable clips

Image: A diagram illustrating the 180-degree rotational capability of the Noma Quick Clip, allowing for adjustable light positioning.



Image: Noma Quick Clip lights attached to a tree branch, demonstrating versatility in placement.





Image: Noma Quick Clip lights attached to a gutter, showcasing another common installation method.

### Step 3: Connecting Multiple Strands

Each strand features end-to-end connectivity. To extend your display, simply plug the male end of one strand into the female end of another. Ensure the total connected wattage does not exceed 216 Watts (maximum 22 strands).

### Video: Installation Overview

Your browser does not support the video tag.

Video: This video demonstrates the installation process of Noma Quick Clip LED Christmas Lights, including attaching them to various surfaces and connecting multiple strands.

## OPERATING INSTRUCTIONS

Once installed, plug the light strand into a standard 120V AC power outlet. The lights will illuminate. There is no separate on/off switch on the strand itself; operation is controlled by plugging/unplugging or using an external timer (not included).

- **Light Source:** LED
- **Light Color:** Warm White
- **Bulb Shape Size:** C9
- **Number of Light Sources:** 100
- **Voltage:** 120 Volts
- **Wattage:** 9.6 watts per strand
- **Maximum Compatible Wattage:** 216 Watts (for connected strands)
- **Bulb Features:** Not Dimmable

## MAINTENANCE

These LED lights are designed for durability and low maintenance. However, proper care will extend their lifespan.

- **Cleaning:** Disconnect from power. Wipe bulbs and wires with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** After seasonal use, carefully unplug the lights. Store them in a cool, dry place, preferably in their original packaging or a protective container, to prevent tangling and damage.
- **Bulb Replacement:** The LED bulbs are integrated and not designed for individual replacement. If a bulb fails, the entire strand or section may be affected.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Lights do not illuminate.	Not plugged in. Power outlet not active. Blown fuse in the plug. Damaged wire or bulb.	Ensure the plug is fully inserted into a working outlet. Test the outlet with another device. Check and replace the fuse in the plug if necessary (refer to fuse replacement instructions on the plug). Inspect the entire strand for visible damage. If damaged, discontinue use.
Only a section of lights is out.	Loose bulb or connection. Damaged bulb in that section.	Gently check each bulb in the affected section to ensure it is seated correctly. If a bulb is visibly damaged, the entire strand may need replacement as bulbs are not individually replaceable.
Clips are not holding securely.	Improper attachment. Surface too thick or thin for the clip.	Ensure the clip is fully engaged with the surface. Try a different attachment point or adjust the clip's position.

## SPECIFICATIONS

Feature	Detail
Brand	Noma
Model Number	1513697
Light Type	LED
Bulb Shape Size	C9

Feature	Detail
Number of Bulbs	100
Light Color	Warm White
Color Temperature	3300 Kelvin
Strand Length	66.8 Feet
Bulb Spacing	8 inches
Power Source	Corded Electric
Voltage	120 Volts
Wattage	9.6 watts
Max Connectable Strands	Up to 22 strands (2,200 lights)
Maximum Compatible Wattage (Connected)	216 Watts
Indoor/Outdoor Usage	Indoor, Outdoor
Special Feature	Energy Efficient, Built-in Quick Clips (180-degree rotation)
Material	Acrylic (bulbs), GPPS (shade)
Item Weight	6.71 pounds

## WARRANTY INFORMATION

This Noma C9 Quick Clip string light product is covered by a**3-year limited warranty**. For warranty claims or further details, please contact Noma customer support.


## CUSTOMER SUPPORT

For assistance with your Noma C9 LED Quick Clip Christmas Lights, please refer to the contact information provided with your product packaging or visit the official Noma website.

**Online Resources:** [Noma Store on Amazon](#)

© 2024 Noma. All rights reserved.






## Related Documents - 1513697



[NOMA Advanced Christmas String Lights User Guide: Setup, App Control & Voice Commands](#)

Comprehensive user guide for NOMA Advanced Voice Command Christmas String Lights. Learn how to set up, control via the NOMA app, and integrate with Google Home and Amazon Alexa for smart holiday lighting.



	<p><a href="#">NOMA Advanced Christmas Voice Command String Lights User Guide</a></p> <p>User guide for NOMA Advanced Christmas Voice Command String Lights, covering app setup, smart home assistant pairing (Google Home, Amazon Echo), and basic operation for indoor and outdoor use.</p>
	<p><a href="#">NOMA Advanced Voice Command Christmas String Lights User Guide</a></p> <p>Comprehensive user guide for NOMA Advanced Voice Command Christmas String Lights, covering quick start, app setup, smart home integration with Google Home and Amazon Alexa, and programming features for indoor and outdoor use.</p>
	<p><a href="#">NOMA LED 70L C6 WW/PW Christmas Lights Instruction Manual</a></p> <p>Instruction manual for NOMA LED 70L C6 WW/PW Christmas lights, covering safety instructions, use and care, and user servicing for indoor and outdoor use.</p>
	<p><a href="#">NOMA Popup Snowman Assembly Instructions and Safety Guide</a></p> <p>Comprehensive assembly instructions, safety warnings, and usage guidelines for the NOMA Popup Snowman (LGNM201). Ensure safe and proper setup for your seasonal decoration.</p>
	<p><a href="#">NOMA Constant-Lit 7-Function Cluster Lights User Manual &amp; Safety Guide</a></p> <p>Official user manual and safety guide for NOMA Constant-Lit 7-Function Cluster Lights (models CTI1513964, CTI1513965, CTI1513974). Provides instructions for operation, care, function selection, timer use, adaptor compatibility, and warranty information.</p>