

[Manuals.plus](#) /

› [DIESEL](#) /

› DIESEL GRIFFED DZ4520 Men's Watch Instruction Manual

DIESEL DZ4520

DIESEL GRIFFED DZ4520 Men's Watch Instruction Manual

Model: DZ4520

INTRODUCTION

This manual provides essential instructions for the setup, operation, and maintenance of your DIESEL GRIFFED DZ4520 men's watch. Please read this manual carefully to ensure proper use and longevity of your timepiece.



Image: Front view of the DIESEL GRIFFED DZ4520 watch, showcasing the black dial, hands, and strap.

SETUP

1. Initial Setup and Time Setting

1. **Unlocking the Crown:** Gently pull the crown (the knob on the side of the watch) out to the outermost position.
2. **Setting the Time:** Rotate the crown to move the hour and minute hands to the correct time.
3. **Securing the Crown:** Once the time is set, push the crown back into its original position. This ensures water resistance and starts the watch movement.



Image: Side view of the DIESEL GRIFFED DZ4520 watch, highlighting the crown and pushers used for setting and operating functions.

OPERATING THE WATCH

Basic Timekeeping

Your DIESEL GRIFFED DZ4520 watch is a quartz movement timepiece, providing accurate time display with hour, minute, and second hands.

Chronograph Function

This model features a chronograph (stopwatch) function, indicated by the special second hand and additional pushers. Use the pushers adjacent to the crown to control the chronograph:

- **Start/Stop:** Press the top pusher to start and stop the chronograph.
- **Reset:** Press the bottom pusher to reset the chronograph hands to zero when stopped.

MAINTENANCE

Cleaning

To maintain the appearance of your watch, wipe the case and strap with a soft, dry cloth. For water-resistant models, a slightly damp cloth can be used, but ensure the crown is fully pushed in before cleaning.

Water Resistance

Your watch has a water resistance rating of 30 meters (3 ATM). This means it is suitable for daily use and can withstand splashes or brief immersion in water. It is **not** suitable for swimming, showering, or diving. Always ensure the crown is fully pushed in to maintain water resistance.

Battery Replacement

The watch is powered by a Lithium Ion battery. When the watch stops or the second hand moves erratically, it may be time for a battery replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and maintain water resistance.

Storage

When not in use, store your watch in a cool, dry place, away from direct sunlight, extreme temperatures, and strong magnetic fields.

TROUBLESHOOTING

- **Watch Not Running:**

Check if the crown is fully pushed in. If it is, the battery may need replacement. Consult a professional watch technician.
- **Incorrect Time:**

Pull out the crown and reset the time as described in the "Setup" section. Ensure the crown is pushed back in securely.
- **Water Inside the Watch:**

If you notice condensation or water droplets inside the watch, immediately take it to a professional watch repair service. Do not attempt to open the watch yourself.

SPECIFICATIONS

Brand	DIESEL
Model Number	DZ4520
Movement	Quartz
Display Type	Multi-analog
Case Shape	Round

Dial Color	Black
Case Thickness	12 mm
Band Width	20 mm
Water Resistance	30 meters (3 ATM)
Special Features	Chronograph
Battery Type	1 Lithium Ion battery
Product Weight	260 g

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official DIESEL website or contact your authorized DIESEL retailer. Keep your proof of purchase for any warranty claims.

