

Mabe EML735NXF0

Mabe EML735NXF0 Electric Range User Manual

Model: EML735NXF0

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your Mabe EML735NXF0 Electric Range. Please read all instructions thoroughly before using the appliance to ensure proper function and to prevent potential hazards. Keep this manual for future reference.

2. SAFETY INSTRUCTIONS

Your safety and the safety of others are paramount. Observe all safety precautions outlined in this manual.

- **Electrical Safety:** Ensure the range is properly grounded. Do not use extension cords. Disconnect power before servicing.
- **Burn Hazard:** Surface units and oven surfaces can remain hot after use. Exercise caution. Do not touch hot surfaces.
- **Child Safety:** Do not allow children to operate or play near the range. Activate the child lock feature when not in use.
- **Proper Ventilation:** Ensure adequate ventilation in the kitchen area during operation.
- **Flammable Materials:** Keep flammable materials away from the range.
- **Oven Use:** Do not line oven racks or bottom with aluminum foil. This can trap heat and cause damage or fire.

3. PRODUCT OVERVIEW

The Mabe EML735NXF0 is a freestanding electric range featuring a ceramic cooktop with four radiant burners, a 5 cubic foot self-clean oven, and a digital touch control panel. The appliance is constructed with a black and stainless steel finish.



Front view of the Mabe EML735NXF0 Electric Range, showcasing the control panel, ceramic cooktop, oven door, and storage drawer.

Key Components:

- **Control Panel:** Digital touch controls for oven functions and tactile knobs for surface burners.
- **Ceramic Cooktop:** Features four radiant heating elements, including a 12-inch dual element.
- **Oven:** 5 cubic foot capacity with self-clean function and digital temperature display.
- **Storage Drawer:** Located at the bottom for storing cookware.

4. SETUP AND INSTALLATION

Proper installation is crucial for the safe and efficient operation of your electric range. It is highly recommended that installation be performed by a qualified technician.

Installation Steps:

1. **Unpacking:** Carefully remove all packaging materials and protective films.
2. **Location:** Place the range in its desired location, ensuring adequate clearance from combustible surfaces.
3. **Electrical Connection:** Connect the range to a dedicated, properly grounded electrical circuit as per local electrical codes. Refer to the wiring diagram provided with the appliance.
4. **Leveling:** Adjust the leveling legs at the bottom of the range to ensure it is stable and level. Use a spirit level to verify.
5. **Anti-Tip Bracket:** Secure the anti-tip bracket to the wall or floor as instructed to prevent the range from tipping forward.

5. OPERATING INSTRUCTIONS

5.1. Using the Surface Burners

The ceramic cooktop features four radiant heating elements controlled by tactile knobs on the control panel.

- **Selecting a Burner:** Turn the corresponding burner knob to the desired heat setting (Min to Max).
- **Dual Element:** The 12-inch dual element allows for heating larger cookware. Refer to the knob markings for activating the inner or outer ring.
- **Indicator Lights:** A 'Burner On' indicator light will illuminate when any surface unit is active. A 'Hot Surface' indicator will glow when a cooking zone is hot, even after it has been turned off.

5.2. Using the Oven

The oven is controlled via the digital touch control panel.

- **Baking:** Press the 'Bake' button, then use the number pad to enter the desired temperature. Press 'Start'. The oven will preheat, and the digital display will show the current temperature.
- **Broiling:** Press the 'Broil' button, select the broil level (e.g., Hi or Lo if available), and press 'Start'.
- **Oven Light:** Press the 'Oven Light' button to turn the interior light on or off.
- **Timer:** Use the 'Timer' function for timed cooking or as a kitchen timer.

5.3. Special Features

- **Flexi Zone Function:** This feature allows for flexible cooking zones on the cooktop, adapting to various cookware sizes. Consult the control panel for specific activation instructions.
- **Heat Maintenance:** Designed to keep food warm at a low temperature without further cooking. Activate via the control panel.
- **Child Lock:** To prevent accidental operation, activate the child lock feature on the digital control

panel. Refer to the panel markings for the specific button sequence to engage and disengage.

- **Self-Clean Oven:** This cycle uses high temperatures to burn off food soils. Remove all oven racks and large food debris before starting. Follow the instructions on the control panel to initiate the self-clean cycle. The oven door will lock during this process.

6. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will prolong the life of your Mabe Electric Range.

- **Ceramic Cooktop:** Clean spills immediately after the surface has cooled. Use a ceramic cooktop cleaner and a non-abrasive pad. Avoid abrasive cleaners or scouring pads.
- **Oven Interior:** After a self-clean cycle, wipe away ash with a damp cloth once the oven has cooled. For light soils, use warm soapy water.
- **Exterior Surfaces (Stainless Steel):** Clean with a soft cloth and mild detergent or a specialized stainless steel cleaner. Wipe in the direction of the grain to avoid streaks.
- **Control Knobs:** Remove knobs by pulling them straight off. Wash with warm soapy water, rinse, and dry thoroughly before replacing.
- **Storage Drawer:** The drawer can be removed for cleaning.

7. TROUBLESHOOTING

Before contacting customer service, review the following common issues and solutions:

- **Range Not Heating:** Check if the range is properly plugged in and if the circuit breaker has tripped.
- **Surface Burner Not Working:** Ensure the knob is set correctly. Check for power supply issues.
- **Oven Not Heating:** Verify the oven function and temperature are set correctly. Check for power supply.
- **Error Codes:** If an error code appears on the digital display, consult the full troubleshooting guide in the comprehensive manual or contact customer support.
- **Uneven Baking:** Ensure the oven is level and that cookware is not blocking vents.

8. SPECIFICATIONS

Brand	Mabe
Model	EML735NXF0
Capacity (Oven)	141.5 Liters (5 cu ft)
Installation Type	Freestanding
Burner Type	Ceramic Radiant
Number of Heating Elements	4
Control Console	Touch (Digital) and Tactile Knobs
Fuel Type	Electric
Material	Stainless Steel
Item Weight	50 Kilograms


Color

Multi Color (Black & Stainless Steel)

9. WARRANTY AND SUPPORT

For warranty information, please refer to the warranty card included with your appliance or contact Mabe customer service. Keep your proof of purchase for warranty claims. For technical assistance or service, please contact an authorized Mabe service provider.

Related Documents - EML735NXF0

	<p>Mabe Electric Range Service Manual</p> <p>This service manual provides detailed technical information, troubleshooting guides, and operational procedures for Mabe electric ranges, including model nomenclature, features, installation, and electrical diagrams.</p>
	<p>Manual de Instrucciones Horno de Empotre Mabe IO8042HGW / IO8042HEY</p> <p>Guía completa para la instalación, uso y mantenimiento del horno de empotre Mabe. Incluye especificaciones técnicas, advertencias de seguridad y funciones detalladas para los modelos IO8042HGW e IO8042HEY.</p>
	<p>Mabe Washing Machine LMA79114CBAKO & Dryer SMG26N5MNBABO - Product Overview</p> <p>Detailed product information for Mabe automatic washing machine model LMA79114CBAKO and gas dryer model SMG26N5MNBABO, featuring specifications, key benefits, and installation guidelines.</p>
	<p>Manual de Servicio Mabe Centro de Lavado: Modelos MCL6840 y MCL6040</p> <p>Manual de servicio completo para centros de lavado Mabe, cubriendo modelos MCL6840ESBB, MCL6840PSBB, MCL6040ESBB y MCL6040PSBB. Incluye especificaciones técnicas, guías de diagnóstico, desensamblaje y diagramas eléctricos.</p>
	<p>Mabe Top Load Washer Kraken 27" Service Manual</p> <p>Comprehensive service manual for Mabe Kraken 27" top-load washers, covering model nomenclature, safety procedures, disassembly, component replacement, and troubleshooting.</p>



Ficha comercial de producto
Resumen
Prestaciones
Características
Consumo
Calendario
Carga
...

[Mabe HMM07CEBN Microwave Oven - Specifications and Installation Guide](#)

Detailed product specification sheet for the Mabe HMM07CEBN microwave oven, including its features, benefits, installation dimensions, and weight information.

Documents - Mabe – EML735NXF0



Service manual
mabe
Ingeniería de Servicio
servicio mabe

[\[pdf\] User Manual Instructions Diagram](#)

mabe Service manual ManualServicio EML visualizador serviplus mx datos pt cocc manuales ||| Service manual MODEL SERIES: EML27WWF0 JCB535DILWW JCB735DILBB EML535NNF0 EML735NNF0 JBS27DILWW JCB535DILBB JCB735SILSS EML535BBF0 **EML735NXF0** EML27NXF0 JCB535SILSS JCB835DILWW EML535NXF0 EML835BBF0 JBS27RILSS JCB735DILWW JCB835SILSS EML735BBF0 EML835NXF0 Ingeniera de Servicio Index Important... lang:en score:27 filesize: 4.63 M page_count: 72 document date: 2020-02-14



Service manual
mabe
Ingeniería de Servicio
serviplus

[Mabe Electric Range Service Manual](#)

This service manual provides detailed technical information, troubleshooting guides, and operational procedures for Mabe electric ranges, including model nomenclature, features, installation, and electrical diagrams.

lang:en score:27 filesize: 2.22 M page_count: 72 document date: 2019-07-22



Technical Product Sheet
Specifications
Product Free Standing Electric Range
UPC: 072618900133
Capacity: 76 cm / 30 in
Color: Black with Stainless Steel
Characteristics:
- Type: Electric
- Control: Electronic
- Burner type: Radiant
- Number of burners: 4
- Electronic ignition
- Delayed start
- Digital control
- Indicator lights: 2
- Defrost function
- Low broil
- 2 oven racks (stainless)
- Panoramic oven window
- Timer
- Storage drawer
- 230V / 50-60Hz
OCTOBER / 2019

[\[pdf\]](#)

PowerPoint Presentation Cruz Lilia MEX PAL VD Click to see Detailed Product Information Buy MABE Electric Cooker EML735NXF0 Price in Qatar Doha souqcart eng v 1631715870 cdn shopify s files 1 0079 1317 7151 |||

...

lang:en score:12 filesize: 247.55 K page_count: 1 document date: 2019-10-28