**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**Noma B07VFKLYYF**

# NOMA C9 LED Quick Clip Christmas Lights Instruction Manual

Model: B07VFKLYYF

## 1. Introduction

Thank you for choosing NOMA C9 LED Quick Clip Christmas Lights. This manual provides essential information for the safe and efficient installation, operation, and maintenance of your new lighting product. Please read these instructions carefully before use and retain them for future reference.

## 2. Safety Information

**WARNING: To reduce the risk of fire and electric shock:**

- Do not install on trees having needles, leaves, or branch coverings of metal or materials that look like metal.
- Do not mount or support strings in a manner that can cut or damage wire insulation.
- Ensure all connections are secure and protected from moisture.
- Always unplug the lights from the power source before performing any maintenance or installation.
- Do not overload electrical circuits. Refer to the specifications for maximum connectable strands.
- This product is rated for outdoor use. However, ensure all plugs and connections are kept dry.

## 3. Package Contents

Your NOMA C9 LED Quick Clip Christmas Lights package includes:

- 1 x String of NOMA C9 LED Quick Clip Christmas Lights (24 Purple, Blue, Green Bulbs, 16-foot strand)
- Spring-loaded clips (integrated)
- Extra plug-ins

## 4. Setup Instructions

The NOMA C9 LED Quick Clip Christmas Lights are designed for easy installation with built-in clips.

1. **Unpack the Lights:** Carefully remove the light string from its reusable storage container.
2. **Identify Mounting Location:** Determine where you wish to install the lights, such as along gutters, rooflines, or tree branches.
3. **Attach Clips:** The lights feature integrated spring-loaded clips. Simply press the clip to open it and attach it to your desired surface. The clips are designed to securely grip various edges.




*Image: A hand demonstrating the use of the integrated quick clip for easy attachment.*

4. **Adjust Light Position:** Each light bulb can rotate 180 degrees, allowing you to adjust the direction and angle of the light for optimal display.




*Image: Diagram illustrating the 180-degree rotation feature of the light bulbs.*

5. **Connect Multiple Strands (Optional):** For longer installations, you can connect up to 90 strands of these lights end-to-end. Ensure the total wattage does not exceed the maximum compatible wattage listed in the specifications.
6. **Secure Installation:** Ensure all clips are firmly attached and the light string is taut but not overly stressed.



*Image: NOMA C9 LED lights securely clipped to a house gutter, demonstrating outdoor installation.*



*Image: NOMA C9 LED lights clipped to a tree branch, showcasing versatile attachment options.*

For a visual guide on installation, please watch the official product video:

Your browser does not support the video tag.

*Video: An official NOMA video demonstrating the quick clip feature and ease of installation for the LED Christmas lights.*

## 5. Operating Instructions

Operating your NOMA C9 LED Quick Clip Christmas Lights is straightforward:

1. **Power Connection:** Plug the light string into a standard 120-volt electrical outlet. For outdoor use, ensure the outlet is weather-protected and rated for outdoor applications.
2. **Power On/Off:** The lights will illuminate once plugged in. To turn them off, simply unplug the string from the power source.
3. **Energy Efficiency:** These lights utilize LED technology, providing bright illumination while consuming significantly less energy compared to traditional incandescent lights.



*Image: NOMA C9 LED lights illuminated on a snow-covered roofline, showcasing their vibrant colors.*




*Image: A residential home beautifully illuminated with NOMA C9 LED Christmas lights, demonstrating a full outdoor display.*

## 6. Maintenance

Proper maintenance ensures the longevity and performance of your NOMA C9 LED Quick Clip Christmas Lights.

- **Cleaning:** Gently wipe bulbs and wires with a soft, dry cloth to remove dust or debris. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** After the season, carefully remove the lights. The reusable plastic container provided with your purchase is ideal for tangle-free storage.




*Image: The NOMA C9 LED lights neatly packed in their reusable storage container.*

- **Bulb Replacement:** These LED bulbs are designed for long life (approximately 1000 hours). If a bulb needs replacement, use only NOMA-approved C9 LED replacement bulbs with a B15D base. Refer to the 'Extra plug-ins' included in your package for spare components.
- **Inspection:** Before each use, inspect the light string for any signs of damage to the wire insulation, bulbs, or clips. Do not use if damaged.

## 7. Troubleshooting

If your NOMA C9 LED Quick Clip Christmas Lights are not functioning as expected, consider the following:

- **Lights Not Turning On:**
  - Ensure the power plug is fully inserted into a working electrical outlet.
  - Check if the outlet is receiving power by testing it with another device.
  - Verify that no circuit breaker has tripped.
- **Partial Section Not Lit:**
  - Inspect the connections between multiple strands to ensure they are securely joined.
  - Check individual bulbs for damage. While LED strings are generally more resilient, a damaged bulb could affect

a section.

- **Flickering Lights:**
  - Ensure all connections are tight.
  - Avoid connecting too many strands, which can overload the circuit. Refer to the maximum connectable strands in the specifications.

If troubleshooting steps do not resolve the issue, please contact customer support.

## 8. Specifications

| Feature | Detail |
|---|---|
| Model Number | B07VFKLYYF |
| Brand | Noma |
| Light Source Type | LED |
| Bulb Shape Size | C9 |
| Number of Light Sources | 24 |
| Light Color | Purple, Green, Blue |
| Length | 16 feet (approx.) |
| Power Source | Corded Electric |
| Voltage | 120 Volts |
| Wattage | 2.4 watts |
| Maximum Compatible Wattage | 216 Watts |
| Indoor/Outdoor Usage | Indoor (Rated for outdoor use as per product description) |
| Special Feature | Corded, Built-in Quick Clips |
| Material | Plastic (GPPS Shade Material) |
| Average Life | 1000 Hours |
| GTIN | 06937476974853 |

## 9. Warranty Information

NOMA products are manufactured to high-quality standards. This product is covered by a 3-year limited warranty against defects in materials and workmanship from the date of purchase. Please retain your proof of purchase for warranty claims. This warranty does not cover damage resulting from misuse, accident, modification, or unauthorized repair.

## 10. Customer Support

For further assistance, technical support, or warranty inquiries, please contact NOMA customer service through the retailer where the product was purchased or visit the official NOMA website for contact information.
**NOMA Store Link:** Visit the NOMA Store on Amazon

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B07VFKLYYF**

More documents and user manuals: **https://manuals.plus/**