

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Air Choice](#) /

› [Air Choice KPT-1502M Portable Ceramic Tower Space Heater User Manual](#)

## Air Choice KPT-1502M

# Air Choice KPT-1502M Portable Ceramic Tower Space Heater User Manual

Brand: Air Choice

Model: KPT-1502M

## 1. INTRODUCTION AND OVERVIEW

---

Thank you for choosing the Air Choice KPT-1502M Portable Ceramic Tower Space Heater. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new heater. Please read all instructions carefully before use and retain this manual for future reference.



Figure 1: Air Choice KPT-1502M Portable Ceramic Tower Space Heater

## 2. IMPORTANT SAFETY INFORMATION

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using this heater.
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. Use handles when moving this heater.
- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the heater and keep them away from the sides and rear.
- Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- Always unplug heater when not in use.
- Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner.
- Do not use outdoors.
- To disconnect heater, turn controls to OFF, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an

electric shock or fire, or damage the heater.

- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- This heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.
- Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.

### Advanced Safety Features

The Air Choice KPT-1502M heater is equipped with two important safety mechanisms:

- **Overheat Protection:** The heater will automatically shut off if it detects an internal temperature that is too high, preventing potential hazards. It will resume operation once it has cooled down to a safe temperature.
- **Tip-Over Switch:** If the heater is accidentally knocked over or placed on an uneven surface, the integrated tip-over switch will immediately cut power to the unit, minimizing the risk of fire or damage.



Figure 2: Overheat and Tip-Over Protection

## 3. PRODUCT FEATURES

- **Rapid Heating:** Utilizes advanced ceramic heating technology to deliver warmth within 3 seconds of activation.
- **Wide Oscillation:** Features 120° oscillation to distribute heat evenly across a larger area, ensuring comprehensive room warming.
- **Thermostatic Control:** An adjustable thermostat helps maintain a consistent and comfortable room temperature, optimizing energy usage and preventing overheating.
- **Quiet Operation:** Engineered with low-noise technology for minimal disturbance, making it suitable for bedrooms, offices, and other quiet environments.
- **No-Light Design:** Operates without strong light emission, ensuring a comfortable and undisturbed environment, especially during nighttime use.
- **Compact and Portable:** Designed with a compact footprint (similar to A4 paper size) and a built-in carrying handle for easy relocation between rooms or under desks.
- **Efficient Air Outlet:** Features a 15-inch curved surface air outlet, providing a 10% larger warm air distribution area compared to standard designs.

### Visual Features Overview

## Embrace Warmth in 3 Second

With the ceramic heating tech you can get rid of cold in 3 seconds



Heat(1500W)



Warm(750W)



Adjustable  
Thermostat



Figure 3: Fast Heating Capability

# 70% Wider Oscillation

120° Widespread Oscillation

Heads up your whole family on the couch



Figure 4: 120° Widespread Oscillation

# 10% Larger Warm Air Outlet

Curved surface and full-screen design



Figure 5: Large Warm Air Outlet Design

# Smart Thermostatic Control

Keep your room stay at a comfortable temperature



Constant warmth

## Air Choice Warm Up Solution




Figure 6: Smart Thermostatic Control

## Quite and No-Light Design

Air choice promises you a comfortable warm night



Quite



No-Light



Figure 7: Quiet and No-Light Design

### 4. SETUP

1. **Unpack:** Carefully remove the heater from its packaging. Retain packaging for storage or if return is necessary.
2. **Placement:** Place the heater on a firm, level surface. Ensure there are no obstructions within 3 feet (0.9 m) of the front, sides, and rear of the heater. Do not place on soft surfaces like rugs or carpets that could block air vents.
3. **Power Connection:** Plug the power cord directly into a 120V AC, 60Hz electrical outlet. Avoid using extension cords or power strips, as they may overheat and create a fire risk.

### 5. OPERATING INSTRUCTIONS

Your Air Choice KPT-1502M heater features two control knobs on the top panel:

- **Left Knob (Mode/Oscillation):** Controls the fan mode and oscillation function.
- **Right Knob (Thermostat/Heat Setting):** Adjusts the desired temperature and heat output.

#### Powering On/Off and Heat Settings

1. **Turn On:** Rotate the Right Knob (Thermostat/Heat Setting) clockwise from the 'OFF' position to select a heat setting. The red indicator light will illuminate.
2. **Heat Settings:**
  - **Fan Only:** Rotate the Left Knob to the fan icon for fan-only operation without heat.
  - **Low Heat (750W):** Rotate the Right Knob to 'I' for low heat output.
  - **High Heat (1500W):** Rotate the Right Knob to 'II' for high heat output.
3. **Adjust Thermostat:** Once a heat setting is selected, rotate the Right Knob further clockwise to increase the desired temperature, or counter-clockwise to decrease it. The heater will cycle on and off to maintain the set temperature.
4. **Turn Off:** Rotate the Right Knob counter-clockwise until it clicks into the 'OFF' position. The red indicator light will turn off.

## Oscillation Function

1. **Activate Oscillation:** With the heater powered on and a heat setting selected, rotate the Left Knob (Mode/Oscillation) to the 'OSC' position. The heater head will begin to oscillate 120 degrees.
2. **Deactivate Oscillation:** Rotate the Left Knob back to a non-OSC position (e.g., fan icon, 'I', or 'II' without oscillation).

## Official Product Video: Operation Overview

Your browser does not support the video tag.

Video 1: This official video provides a general overview of the Air Choice Ceramic Space Heater, demonstrating its fast heating, oscillation, and safety features.

## 6. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your heater.

- **Cleaning:** Always unplug the heater and allow it to cool completely before cleaning. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the heater in a cool, dry place. It is recommended to store it in its original packaging to protect it from dust and damage.
- **Air Vents:** Periodically check the air intake and exhaust vents for dust or debris. Use a vacuum cleaner with a brush attachment to gently clean the vents. Do not attempt to open the heater for internal cleaning.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Heater does not turn on.	No power to the unit.	Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker.
Heater turns off unexpectedly.	Overheat protection activated.	Unplug the heater, allow it to cool for 30 minutes, then restart. Ensure vents are not blocked.
Heater turns off when moved.	Tip-over switch activated.	Place the heater on a firm, level surface. It will resume operation automatically.

Problem	Possible Cause	Solution
Heat output is low.	Low heat setting selected or thermostat set too low.	Increase the heat setting (to 'II') or adjust the thermostat to a higher temperature.

If the problem persists after attempting these solutions, please contact customer support.

## 8. SPECIFICATIONS

Specification	Value
Brand	Air Choice
Model Number	KPT-1502M
Color	White
Form Factor	Tower
Indoor/Outdoor Usage	Indoor
Product Dimensions	6.6"D x 4.6"W x 16.5"H
Recommended Uses	Desk, Home, Office, Bedroom, Bathroom
Mounting Type	Floor Mount
Burner Type	Radiant
Fuel Type	Electric
Number of Speeds	2 (Low/High Heat)
Voltage	120 Volts
Amperage	6.25 Amps
Item Weight	4.84 pounds
UPC	712317382389

## 9. WARRANTY AND SUPPORT

Air Choice products are manufactured under strict quality standards. For information regarding warranty coverage, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official Air Choice website.

Air Choice is committed to providing safe, efficient, and durable products. For any questions or concerns, please do not hesitate to contact our customer service team.