

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Tiny Love](#) /

› [Tiny Love 4-in-1 Here I Grow Mobile Activity Center User Manual](#)

Tiny Love WA077FGO

Tiny Love 4-in-1 Here I Grow Mobile Activity Center Instruction Manual

Model: WA077FGO

Brand: Tiny Love

PRODUCT OVERVIEW

The Tiny Love 4-in-1 Here I Grow Mobile Activity Center is designed to support your child's development through various stages. It functions as a stationary activity center, a push-along walker, a jumper, and a traditional baby walker with wheels. This versatile product encourages independent movement and exploration while engaging your baby with multiple developmental toys.

Key Features:

- **4 Modes of Use:** Stationary activity table, push-along, jumper, and walker.
- **Developmental Activities:** Features 6 developmental toys and over 28 activities to foster cognition, language, fine and gross motor skills, senses, creativity, and emotional intelligence.
- **Easy to Clean:** The seat pad is machine washable for convenient cleaning.
- **Compact Storage:** Designed to nest inside its outer frame for hassle-free storage.
- **Adjustable Height:** Offers 3 adjustable height positions to grow with your child.
- **360° Rotating Seat:** Allows your baby to swivel and interact with all surrounding toys and activities.



1
Swivel



2
Push

4-in-1



3
Bounce



4
Walk

Figure 1: The four versatile modes of the Tiny Love Here I Grow Mobile Activity Center.

SETUP AND ASSEMBLY

Follow these steps to assemble your Tiny Love 4-in-1 Here I Grow Mobile Activity Center. It is recommended to assemble the unit on a flat, stable surface.

- 1. Unpack Components:** Carefully remove all parts from the packaging. Ensure all components listed in the manual are present.
- 2. Attach Legs:** Securely attach the four support legs to the main base unit. Ensure they click firmly into place.
- 3. Insert Seat:** Place the fabric seat into the designated opening in the activity table. Ensure it is properly aligned and secured.
- 4. Attach Handlebar:** If using the push-along mode, attach the handlebar to the front of the activity center.
- 5. Install Toys:** Attach the various developmental toys to their respective slots around the activity table. Ensure they are securely fastened.

Your browser does not support the video tag.

Video 1: Official assembly guide for the Tiny Love Here I Grow Mobile Activity Center. This video demonstrates the step-by-step process of putting the activity center together, including attaching the legs, seat, and various toys.



Figure 2: The Tiny Love 4-in-1 Here I Grow Mobile Activity Center fully assembled.

OPERATING INSTRUCTIONS

The Tiny Love 4-in-1 Activity Center offers multiple modes to adapt to your child's growth and developmental needs.

1. Stationary Activity Mode:

In this mode, the activity center remains stable, allowing your baby to sit and interact with the surrounding toys. The seat can swivel 360 degrees, providing access to all activities without needing to move the unit.

- To engage stationary mode, ensure the wheel lockouts on the base are activated.
- The seat can be locked in place or allowed to rotate freely for full access to toys.



Figure 3: The 360-degree swivel seat allows full access to all toys.

2. Jumper Mode:

The activity center features a bouncing mechanism to provide a fun and engaging experience for your baby.

- To enable bouncing, ensure the bounce lockout mechanism on the legs is disengaged.
- Adjust the height to ensure your baby's feet can comfortably touch the floor for bouncing.

3. Push-Along Mode:

As your child begins to stand and take their first steps, the activity center can be converted into a push-along walker.

- Ensure the handlebar is securely attached.
- Disengage the wheel lockouts to allow the unit to roll freely.
- Supervise your child closely in this mode.

4. Baby Walker Mode:

For independent walking, the activity center can be used as a traditional walker, allowing your child to move around freely.

- Ensure all wheel lockouts are disengaged.
- Adjust the height to the appropriate level for your child's comfort and safety.



Figure 4: The activity center provides over 20 developmental activities for engagement.

MAINTENANCE AND CARE

Regular cleaning and maintenance will ensure the longevity and hygiene of your activity center.

- **Seat Pad:** The fabric seat pad is machine washable. Remove it from the unit and wash on a gentle cycle with cold water. Do not bleach. Air dry or tumble dry on low heat.
- **Plastic Components:** Wipe down all plastic surfaces with a damp cloth and mild soap. Rinse thoroughly and dry completely before reassembly.
- **Toys:** Detachable toys can be wiped clean with a damp cloth and mild soap. Ensure they are dry before reattaching.

Seat pad is removable for an easy clean



Figure 5: The seat pad is easily removable for cleaning.

TROUBLESHOOTING

This section addresses common issues you might encounter with your activity center.

Problem	Possible Cause	Solution
Unit does not move freely in walker mode.	Wheel lockouts are engaged.	Ensure all wheel lockouts on the base are disengaged.
Unit bounces when in stationary mode.	Bounce lockout is disengaged.	Engage the bounce lockout mechanism on the legs to stabilize the unit.
Seat does not rotate.	Seat rotation lockout is engaged.	Disengage the seat rotation lockout mechanism located near the seat.

SPECIFICATIONS

- **Product Dimensions:** 28.5 x 24.5 x 7.63 inches
- **Item Model Number:** WA077FGO
- **Maximum Weight Recommendation:** 15 Kilograms (approximately 33 lbs)
- **Material Type:** Polyester, Plastic
- **Item Weight:** 13.14 pounds
- **Country/Region of Origin:** China
- **Color:** Magical Tales

WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the official Tiny Love website or the user manual PDF provided with your product.

You can also find the user manual [here](#).

© 2025 Tiny Love. All rights reserved.