

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Onset](#) /

› [Onset HOBO UX100-011A Temperature and Humidity Data Logger User Manual](#)

Onset UX100-011A

Onset HOBO UX100-011A Temperature and Humidity Data Logger User Manual

1. INTRODUCTION

1.1 Product Overview

The Onset HOBO UX100-011A is a data logger designed for accurate measurement and recording of ambient temperature and humidity. It features an internal sensor and an LCD display for real-time readings and status updates. This device is suitable for various monitoring applications requiring precise environmental data.




Image 1.1: The Onset HOBO UX100-011A data logger. The device features a clear LCD screen displaying temperature (78.54 °F) and humidity (42.6 %RH) readings, along with memory and logging indicators. A sensor grille is visible on the right side of the unit.

1.2 Key Features

- Internal sensor for temperature and humidity measurements.
- Measurement range: -20°C to 70°C (temperature) and 1% to 95% RH (humidity).
- Accuracy: 0.21°C and 2.5% RH.
- LCD display shows current temperature, humidity, recording mode, battery level, and alarm status.

- User-replaceable coin cell lithium battery with approximately a 1-year life at a 1-minute sampling rate.
- Software-selectable sampling rate from 1 second to 18 hours.
- Stores up to 84,650 measured readings.

2. SETUP

2.1 System Requirements

To configure the data logger and download recorded data, a computer with HOBOWare software is required. Compatible operating systems include:

- Windows: 8, 7, Vista, or XP
- Mac: OS X 10.6, 10.7, or 10.8

2.2 Software Installation

Download and install the latest version of HOBOWare software from the official Onset website. Follow the on-screen instructions to complete the installation process.

2.3 Initial Device Connection

1. Connect the HOB0 UX100-011A data logger to your computer using a standard USB cable.
2. The HOBOWare software should automatically detect the connected device.
3. Use HOBOWare to configure logging parameters such as sampling rate and start/stop times.

3. OPERATING INSTRUCTIONS

3.1 Data Logging

Once configured via HOBOWare, the data logger will begin recording temperature and humidity data at the specified sampling interval. The device can store up to 84,650 readings before requiring data download.

3.2 LCD Display Information

The LCD display provides real-time information:

- **Current Readings:** Displays the most recent temperature and humidity values.
- **Recording Mode:** Indicates if the logger is actively recording data.
- **Battery Level:** Shows the remaining battery charge.
- **Alarm Status:** Notifies if any configured alarms have been triggered.

3.3 Data Download and Analysis

1. Connect the data logger to your computer using the USB cable.
2. Open HOBOWare software.
3. Follow the software prompts to download the recorded data.
4. Within HOBOWare, you can view, graph, and export the collected data for further analysis.

4. MAINTENANCE

4.1 Battery Replacement

The HOBO UX100-011A uses a user-replaceable coin cell lithium battery. When the battery level indicator on the LCD display shows low charge, replace the battery to ensure continuous operation and data integrity. Refer to the HOBOWare software or the full product manual for specific battery replacement instructions.

5. TROUBLESHOOTING

5.1 Common Issues

- **Device not recognized by HOBOWare:** Ensure the USB cable is securely connected and that HOBOWare software is properly installed and updated. Check your computer's device manager for any driver issues.
- **No data logging:** Verify that the device battery is not depleted. Confirm that the logging parameters have been correctly configured and started in HOBOWare.
- **Inaccurate readings:** Ensure the data logger is placed in an environment free from direct sunlight, heat sources, or excessive airflow that could affect sensor accuracy.

For further troubleshooting, consult the HOBOWare help documentation or the Onset support website.

6. SPECIFICATIONS

Parameter	Value
Model Number	UX100-011A
Temperature Measurement Range	-20°C to 70°C (-4°F to 158°F)
Temperature Accuracy	±0.21°C (±0.38°F) typical
Humidity Measurement Range	1% to 95% RH (non-condensing)
Humidity Accuracy	±2.5% RH typical
Data Storage Capacity	84,650 measurements
Sampling Rate	1 second to 18 hours (user-selectable)
Battery Type	User-replaceable Coin Cell Lithium Battery
Battery Life	Approximately 1 year (at 1-minute sampling rate)
Dimensions	3.7 x 2.56 x 1.34 inches (94 x 65 x 34 mm)
Weight	0.21 Kilograms (7.37 ounces)
Manufacturer	Onset Computer Corporation


7. WARRANTY AND SUPPORT

For detailed warranty information and technical support, please refer to the official Onset Computer Corporation website or contact their customer service. Keep your purchase receipt for warranty claims.

Onset Website: www.onsetcomp.com


Related Documents - UX100-011A

	HOB0 MX801 Submersible Logger Quick Start Guide A quick start guide for the HOB0 MX801 Submersible Logger, detailing its overview, sensor connection, calibration, configuration, deployment, data download, and processing.
	HOB0 MX1101 Temp/RH Data Logger User Manual Comprehensive user manual for the HOB0 MX1101 Temp/RH Data Logger, detailing its features, specifications, setup, operation, and troubleshooting. Learn how to configure, deploy, and read data from this Bluetooth Smart-enabled logger for indoor environmental monitoring.
	HOB0 MX2300 Series Data Logger Manual: Temperature & RH Monitoring Comprehensive manual for the HOB0 MX2300 Series Bluetooth Low Energy (BLE) data loggers by Onset. Covers setup, specifications, operation, and data analysis for temperature and relative humidity monitoring.
	HOB0 MX801 Submersible Logger Quick Start Guide A quick start guide for the HOB0 MX801 Submersible Logger, detailing setup, configuration, deployment, data download, and processing for water parameter logging using HOB0connect.



[HOBOMX2300 Series Data Logger: Comprehensive User Manual and Specifications](#)

Explore the HOBOMX2300 Series Data Loggers from Onset, designed for reliable temperature and relative humidity monitoring. This manual details setup, operation, specifications, and data management using the HOBOMconnect app via Bluetooth Low Energy.



[HOBOMUX100-001 Temperatur-Datenlogger: Handbuch und Bedienungsanleitung](#)

Umfassendes Handbuch für den HOBOMUX100-001 Temperatur-Datenlogger von Onset. Enthält technische Daten, Einrichtungsanleitungen, Alarmkonfiguration, Burst-Aufzeichnung, Statistikfunktionen, Wartung und Fehlerbehebung.

Documents - Onset – UX100-011A



[\[pdf\] User Manual](#)


UX100 011A Manual Japanese Onset Computer Corporation HOBOM Temp RH 2 5% Data Logger

Loggers 22933 A onsetcomp files manual s |||

HOBOM / 2.5 **UX100-011A** HOBOM / 3.5 **UX100-011A** : TM : HOBOWare 3.7.16

www.onsetcomp.com/hoboware-free-download USB HOBOM / 2.5 HOBOWare/ LCD - 2070C 0.21C 050C A 25C 0.024C A 1 m/s 2.2 mph 4 1 0.1C RH 1 95 10 90 RH 2.5 3.5 25C 10RH 90R...

lang:i-klngon **score:51** filesize: 1.38 M page_count: 8 document date: 2018-11-30




[\[pdf\] User Manual Specifications](#)

manual Onset HOBOM UX100 011A Temperature Humidity Data Logger 2 5% accuracy ux100 011a itm s cache |||

HOBOM Temp/RH 2.5 Data Logger **UX100-011A** Manual HOBOM Temp/RH 2.5 Data Logger **UX100-011A** Included Items: CommandTM strip Double-sided tape Hook loop strap Required Items: HOBOWare 3.7.16 or later USB cable The HOBOM Temp/RH data logger records temperature and relative humidity within 2.5 ...


lang:en **score:49** filesize: 1.68 M page_count: 8 document date: 0000-00-00



[pdf] User Manual Specifications

manual Onset HOBOT UX100 011A Temperature Humidity Data Logger 2 5% accuracy ux100 011a globaltestsupply s cache |||


HOBOT Temp/RH 2.5 Data Logger **UX100-011A** Manual HOBOT Temp/RH 2.5 Data Logger **UX100-011A** Included Items: Command™ strip Double-sided tape Hook loop strap Required Items: HOBOWare 3.7.16 or later USB cable The HOBOT Temp/RH data logger records temperature and relative humidity within 2.5 ... lang:en **score:49** filesize: 1.66 M page_count: 8 document date: 0000-00-00



[pdf] User Manual Specifications Datasheet

ITM Datasheet Template manual Onset HOBOT UX100 011A Temperature Humidity Data Logger 2 5% accuracy ux100 011a calcert s cache |||


HOBOT Temp/RH 2.5 Data Logger **UX100-011A** Manual HOBOT Temp/RH 2.5 Data Logger **UX100-011A** Included Items: Command™ strip Double-sided tape Hook loop strap Required Items: HOBOWare 3.7.16 or later USB cable The HOBOT Temp/RH data logger records temperature and relative humidity within 2.5 ... lang:en **score:48** filesize: 1.77 M page_count: 8 document date: 2022-03-29



[pdf] User Manual

UX100 011A Manual German Onset Computer Corporation HOBOT Temp RH 2 5% Data Logger Loggers 22932 A onsetcomp files manual s |||

HOBOT-Datenlogger fr Temperatur/Relative Luftfeuchtigkeit 2,5 **UX100-011A** - Handbuch HOBOT-Datenlogger fr Temperatur/Relative Luftfeuchtigkeit 2,5 **UX100-011A** Lieferumfang: Command™-Strip Doppelseitiges Klebeband Klettband Erforderliches Zubehr: HOBOWare 3.7.16 oder hher www.onsetcomp.com/ ... lang:de **score:48** filesize: 1.34 M page_count: 8 document date: 2018-11-30




[pdf] User Manual Specifications

HOBO Temp RH 2 5% Data Logger UX100 011A Manual Onset Computer Corporation 22931 A precicon sg 2021 12 |||

HOBO Temp/RH 2.5 Data Logger **UX100-011A** Manual HOBO Temp/RH 2.5 Data Logger **UX100-011A** Included Items: Command™ strip Double-sided tape Hook loop strap Required Items: HOBOWare 3.7.16 or later download at www.onsetcomp.com/hoboware-free-download USB cable The HOBO Temp/RH data logge...

lang:en score:47 filesize: 507.55 K page_count: 8 document date: 2021-12-29



[pdf] User Manual Specifications

HOBO Temp RH 2 5% Data Logger UX100 011A Manual Onset Computer Corporation 22931 A onetemp co nz Attachment DownloadFile Id 4129 |||

HOBO Temp/RH 2.5 Data Logger **UX100-011A** Manual HOBO Temp/RH 2.5 Data Logger **UX100-011A** Included Items: Command™ strip Double-sided tape Hook loop strap Required Items: HOBOWare 3.7.16 or later download at www.onsetcomp.com/hoboware-free-download USB cable The HOBO Temp/RH data logge...

lang:en score:45 filesize: 2.02 M page_count: 8 document date: 2023-03-23




[pdf] User Manual

UX100 011A Manual Japanese Onset Computer Corporation HOBO® Temp RH 2 5% Data Logger s HOBO and InTemp LoggersHOBO® Loggers22933 A Japanese22933 Japaneseonsetcomp sites default files resources documents 22933 |||

HOBO / 2.5 **UX100-011A** HOBO / 3.5 **UX100-011A** : TM : HOBOWare 3.7.16 www.onsetcomp.com/hoboware-free-download USB HOBO / 2.5 HOBOWare/ LCD - 2070C 0.21C 050C A 25C 0.024C A 1 m/s 2.2 mph 4 1 0.1C RH 1 95 10 90 RH 2.5 3.5 25C 10RH 90R...

lang:i-klingson score:45 filesize: 1.38 M page_count: 8 document date: 2018-11-30





[pdf] User Manual

UX100 011A Manual German Onset Computer Corporation DE CiK HOBO shop cik solutions media 4b 09 08 1695117435 ||| ||| HOBO-Datenlogger fr Temperatur/Relative Luftfeuchtigkeit 2,5 UX100-011A -

Handbuch HOBO-Datenlogger fr Temperatur/Relative Luftfeuchtigkeit 2,5 UX100-011A Lieferumfang: Command™-Strip Doppelseitiges Klebeband Klettband Erforderliches Zubeh

HOBO-Datenlogger fr Temperatur/Relative Luftfeuchtigkeit 2,5 **UX100-011A** - Handbuch HOBO-Datenlogger fr Temperatur/Relative Luftfeuchtigkeit 2,5 **UX100-011A** Lieferumfang: Command™-Strip Doppelseitiges Klebeband Klettband Erforderliches Zubehr: HOBOWare 3.7.16 oder hher www.onsetcomp.com/ ... lang:de score:44 filesize: 1.5 M page_count: 8 document date: 2023-08-28






[\[pdf\]](#) User Manual Specifications

View 6 days ago — Range 20° to 70°C 4° 158°F Accuracy $\pm 0.21^{\circ}\text{C}$ from 0° 50°C see manual for plot 38°F 32° 122°F Resolution UX100 011A HOB0 Temp RH 2.5 Data Logger onsetcomp print node 13391 srsltid AfrmBOoqPkCipS36jxIGXtnPv7bkArF1nFaFqgaiccEWaMGqzWYpy4dDM |||

UX100-011A HOB0 Temp/RH 2.5 Data Logger With integrated sensors, measures and records temperature and relative humidity within 2.5 accuracy in indoor environments. Important Information Requires HOB0ware software and a USB cable. Note: A USB-A to USB-B mini cable is included w/HOB0ware Pro USB ...
lang:en score:35 filesize: 53.87 K page_count: 2 document date: 2025-02-07



[\[pdf\]](#) User Manual Specifications


View 7 дней назад — Range 20° to 70°C 4° 158°F Accuracy $\pm 0.21^{\circ}\text{C}$ from 0° 50°C see manual for plot 38°F 32° 122°F Resolution UX100 011A HOB0 Temp RH 2.5 Data Logger onsetcomp print node 13391 srsltid AfrmBOoqv3dhnSe8qQceiA4IAHffs WrL4m1 Y2psSrff2mjBUks WzX |||

UX100-011A HOB0 Temp/RH 2.5 Data Logger With integrated sensors, measures and records temperature and relative humidity within 2.5 accuracy in indoor environments. Important Information Requires HOB0ware software and a USB cable. Note: A USB-A to USB-B mini cable is included w/HOB0ware Pro USB ...
lang:en score:35 filesize: 53.87 K page_count: 2 document date: 2025-02-08



[\[pdf\]](#) Specifications Datasheet

EN CiK HOB0 Datasheet UX100 011A shop cik solutions media a0 40 18 1699440385 |||
HOB0 **UX100-011A** Data Logger Temp/RH 2.5 Data Logger The HOB0 UX100-011 Temperature/Relative Humidity data logger records temperature and relative humidity within 2.5 accuracy in indoor environments with its integrated sensors. This data logger is ideal for monitoring occupant comfort in office b...
lang:en score:34 filesize: 210.98 K page_count: 3 document date: 2023-09-15



[pdf]

HOB0 UX100 011A USB Temperature and Humidity Data Logger 2.5% accuracy 5 tempcon co uk product file id 1802 name |||

Call our friendly team on 44 0 1243 558270 Tempcon Instrumentation Ford Lane Business Park Ford West Sussex BN18 0UZ, UK www.tempcon.co.uk HOB0 **UX100-011A** USB Temperature and Humidity Data Logger 2.5 accuracy Product Images Short Description 1 <https://www.tempcon.co.uk/hobo-ux100-011-temp-rh-2-...> lang:en score:34 filesize: 304.62 K page_count: 4 document date: 2022-06-21

[pdf] Specifications

HOB0® UX100 011A Data Logger Instrumentation2000The HOB0 011 Temperature Relative Humidity data logger records temperature and relative humidity within 2.5% accuracy in onset ux100 011a sheetinstrumentation2000 pub media onset sheet srsId AfmBOOpK aDX6zwEKzaBVQxt4 N3Jp3aHgVaWmrnmibylHSGqyDV2BF Instrumentation2000HOB0® inThe sheetonset

N3Jp3aHgVaWmrnmibylHSGqyDV2BFInstrumentation2000 AfmBOOp

vAKpSVnVQVmPlt15SHOKsIOA3ZqGGYuHEsJBSh77ANbo9cut

vAKpSVnVQVmPlt15SHOKsIOA3ZqGGYuHEsJBSh77ANbo9cutinstrumentation2000

AfmBOOrB9BKMgWqBr1tmUappa1VBNeSie9SsBunBK6aXlukvdC8hLG

AfmBOOrB9BKMgWqBr1tmUappa1VBNeSie9SsBunBK6aXlukvdC8hLGinstrumentation2000

AfmBOOr2H TroXkpWUrQoCyLOPMSzb10cVtBzNiKQ2EL3GprPEPzCllg AfmBOoolLjjYay7qqDN

xqC9VZWKIrEVZiuMzCoVy4IEqw Ymoq6PhGlinstrumentation2000 AfmBOooby01Nsw

lusIRdol2dWfDsdRXLfWwQW9ORKXXG9krPzCP2Byjinstrumentation2000 AfmBOOppEY1MEP9

MCaBKlyWG5tl2t4u gcle6j 4yQMB08U8dUyef1Winstrumentation2000 ||| ||| HOB0 UX100-011A Data

Logger Temp/RH 2.5 The HOB0 UX100-011 Temperature/Relative Humidity data logger records temperature and relative humidity within 2.5% accuracy in indoor environments with its integrated sensors.

This data logger is ideal ||| HOB0 UX100-011A Data Logger Temp/RH 2.5 The HOB0 UX100-011

Temperature/Relative Humidity data logger records temperature and relative humidity within 2.5% accuracy in indoor environments with its integrated sensors. This data logger is ideal ||| HOB0 UX100-011A Data

Logger Temp/RH 2.5 The HOB0 UX100-011 Temperature/Relative Humidity data logger records

temperature and relative humidity within 2.5% accuracy in indoor environments with its integrated sensors.

This data logger is ideal ||| HOB0 UX100-011A Data Logger Temp/RH 2.5 The HOB0 UX100-011

Temperature/Relative Humidity data logger records temperature and relative humidity within 2.5% accuracy

in indoor environments with its integrated sensors. This data logger is ideal ||| HOB0 UX100-011A Data

Logger Temp/RH 2.5 The HOB0 UX100-011 Temperature/Relative Humidity data logger records

temperature and relative humidity within 2.5% accuracy in indoor environments with its integrated sensors.

This data logger is ideal ||| HOB0 UX100-011A Data Logger Temp/RH 2.5 The HOB0 UX100-011

Temperature/Relative Humidity data logger records temperature and relative humidity within 2.5% accuracy

in indoor environments with its integrated sensors. This data logger is ideal

HOB0 **UX100-011A** Data Logger Temp/RH 2.5 The HOB0 UX100-011


Temperature/Relative Humidity data logger records temperature and relative humidity

within 2.5% accuracy in indoor environments with its integrated sensors. This data

logger is ideal for monitoring occupant comfort in office buildings, tr...

lang:en score:33 filesize: 95.84 K page_count: 3 document date: 2021-08-03






[pdf]


HOB0 UX100 011A USB Temperature and Humidity Data Logger 2 5% accuracy Sheet Temp RH
Tempcon Instrumentation 5 tempcon co uk product file id 1802 name |||

Call our friendly team on 44 0 1243 558270 Tempcon Instrumentation Ford Lane
Business Park Ford West Sussex BN18 0UZ, UK www.tempcon.co.uk HOB0 **UX100-011A** USB Temperature and Humidity Data Logger 2.5 accuracy Product Images
Short Description The HOB0 **UX100-011A** Temperature/Relative Humidity ...
lang:en score:33 filesize: 304.98 K page_count: 4 document date: 2022-09-23



[pdf] Specifications

View HOB0 Data LoggersHOB0 Temp RH 2 5% Logger UX100 011A Specifications Temperature
Sensor Range 20° to 70°C 4° 158°F Accuracy ±0 21°C from 0° 50°C see UX100 5 Loggeronsetcomp
print node 13391 srsltd AfmBOooFIaMYSKWuZvvjeF5Ok32TX1zzU3sFxtwJ6NchAkqJrpgQXti |||
Supported Measurements Dew Point, Relative Humidity, Temperature Features Easy-
to-view LCD display L ... he box HOB0 UX100-011 Temp/RH 2.5 Data Logger
CommandTM strip Double-sided tape Hook loop strap **UX100-011A** HOB0 Temp/RH
2.5 Data Logger With integrated sensors, measures and records temperature a...
lang:en score:30 filesize: 67.51 K page_count: 2 document date: 2025-09-26



[pdf]


HOB0 UX100 011A USB Temperature and Humidity Data Logger 2 5% accuracy 1 tempcon co uk hobo
ux100 011 temp rh 5 percent data logger 02 05 2022 Call our friendly team on 44 0 1243 558270
Tempcon Instrumentation Ford Lane temperature trends in server rooms measuring humidity levels
museums product file id 1802 name TempRH |||
Call our friendly team on 44 0 1243 558270 Tempcon Instrumentation Ford Lane
Business Park Ford West Sussex BN18 0UZ, UK www.tempcon.co.uk HOB0 **UX100-011A** USB Temperature and Humidity Data Logger 2.5 accuracy Product Images
Short Description 1 https://www.tempcon.co.uk/hobo-ux100-011-temp-rh-2-...
lang:en score:29 filesize: 304.62 K page_count: 4 document date: 2022-05-11



[pdf] Guide

HOBOWare User s Guide Onset Computer Corporation MadCap Software hoboware guide itsensor it media productattachment h o |||


HOBOWare User s Guide Onset Computer Corporation 470 MacArthur Blvd. Bourne, MA 02532 www.onsetcomp. ... t in the software user interface Help and user guides are available in English only . Support for **UX100-011A** and UX100-023A loggers. Several bug fixes. HOBOWare 3.7.15: Support for Java 10 on Maci... lang:en score:29 filesize: 7.76 M page_count: 226 document date: 2020-03-31



[pdf] User Manual

Onset UX100 011A Manual HOBO Temp RH 2 5% Data Logger Manual746 04 KBOnset Temperature and Accuracyonset ux100011a manualfotronic asset akeneo cloud s media onset manual |||

... lang:en score:28 filesize: 746.04 K page_count: 8 document date: 2019-10-11




[pdf] User Manual Guide

HOBOWare User s Guide Onset Computer Corporation InstrumartSupport for UX100 011A and 023A loggers Several bug fixes Page 6 1 800 LOGGERS onsetcomp New Features in Previous HOBOWare manualinstrumart assets manual srsItid AfmBOoqYp6SFPOE9FXp FVCcBo0kG8n

KhP7MgMnOApH3P6TXsgTRbXG InstrumartHOBOWare Previous barometric data can come from another HOBO U20 or U20L Water Level Logger air a Weather Station Micro U30 Energy HOBOWare manualHOBOWare KhP7MgMnOApH3P6TXsgTRbXGinstrumart AfmBOooMRGsMOV55c4SEXG4avkrV5lhuvaOfDqsrBALJTc9d8A6bnPA Energy Support AfmBOooMRGsMOV55c4SEXG4avkrV5lhuvaOfDqsrBALJTc9d8A6bnPAinstrumart AfmBOoptTYmnCUR7y5OihoqHkyhrHqWIMT3n1PXj8Z5BX kUnytDdNP |||

HOBOWare User s Guide Onset Computer Corporation 470 MacArthur Blvd. Bourne, MA 02532 www.onsetcomp. ... t in the software user interface Help and user guides are available in English only . Support for **UX100-011A** and UX100-023A loggers. Several bug fixes. 1-800-LOGGERS 5 www.onsetcomp.com HOBOWa... lang:en score:27 filesize: 8.2 M page_count: 226 document date: 2018-10-25




[pdf] User Manual Guide

HOBOWare User s Guide Onset Computer Corporation HOBOWare® 1 800 LOGGERS 6 onsetcomp New Features in Previous Releases 3 7 15 Support for Java 10 on Macintosh works with 8 9 and both Windows manual instrumart assets

HOBOWare User s Guide Onset Computer Corporation 470 MacArthur Blvd. Bourne, MA 02532 www.onsetcomp. ... t in the software user interface Help and user guides are available in English only . Support for **UX100-011A** and UX100-023A loggers.

Several bug fixes. 1-800-LOGGERS 5 www.onsetcomp.com HOBOWa...

lang:en score:26 filesize: 8.2 M page_count: 226 document date: 2018-10-25




[pdf] Guide

HOBOWare User s Guide Onset Computer Corporation MadCap Software onetemp co nz Attachment DownloadFile Id 3491 ||| ||| HOBOWare User s Guide 20102020 Onset Computer Corporation. All rights reserved. Onset, HOBOWare, HOBOLink, HOBOWare, HOBOMobile, BoxCar, and FlexSmart are trademarks or registered trad

HOBOWare User s Guide 20102020 Onset Computer Corporation. All rights reserved. Onset, HOBOWare, HOBOLi ... t in the software user interface Help and user guides are available in English only . Support for **UX100-011A** and UX100-023A loggers. Several bug fixes. HOBOWare 3.7.15: Support for Java 10 on Maci...

lang:en score:26 filesize: 8.19 M page_count: 226 document date: 2022-05-09




[pdf] User Manual

Onset UX100 011A Manual HOBOWare Temp RH 2 5% Data Logger Manual746 04 KB Test Equipment Depot ux100011a manual ba23 testequipmentdepot media akeneo connector asset files u x |||

...

lang:en score:25 filesize: 746.04 K page_count: 8 document date: 2019-10-11




[pdf] Guide

HOBOWare® User s Guide Onset Computer Corporation 12730 AE HOBOWare onetemp co nz Attachment DownloadFile Id 4167 |||

HOBOWare User s Guide Onset Computer Corporation 470 MacArthur Blvd. Bourne, MA 02532 www.onsetcomp. ... t in the software user interface Help and user guides are available in English only . Support for **UX100-011A** and UX100-023A loggers.

Several bug fixes. HOBOWare 3.7.15: Support for Java 10 on Maci...

lang:en score:24 filesize: 8.38 M page_count: 226 document date: 2023-03-29




[\[pdf\]](#) Guide

HOBOWare® User s Guide Onset Computer Corporation 12730 AE HOBOWare onetemp co nz

Attachment DownloadFile Id 4186 |||

HOBOWare User s Guide 2010/2022 Onset Computer Corporation. All rights reserved. Onset, HOBOWare, HOBOWare ... t in the software user interface Help and user guides are available in English only . Support for **UX100-011A** and UX100-023A loggers. Several bug fixes. HOBOWare 3.7.15: Support for Java 10 on Maci...

lang:en score:24 filesize: 8.39 M page_count: 226 document date: 2023-04-04




[\[pdf\]](#) User Manual Guide

HOBOWare® User s Guide Onset Computer Corporation Manual HOBOWare 1 800 LOGGERS 5

onsetcomp Chapter An Overview of software is used for launching reading out and plotting data from HOBOWare® loggers Pro 12730 AE files manual View HOBOWare Water Level Data Logger Deluxe Kit 30 KIT D U20 01 Loggers 6 New Features in Previous Releases 3 7 17 Support a default time zone when logger viewing datafile |||

HOBOWare User s Guide Onset Computer Corporation 470 MacArthur Blvd. Bourne, MA 02532 www.onsetcomp. ... t in the software user interface Help and user guides are available in English only . Support for **UX100-011A** and UX100-023A loggers. Several bug fixes. HOBOWare 3.7.15: Support for Java 10 on Maci...

lang:en score:23 filesize: 8.04 M page_count: 226 document date: 2022-05-17



[\[pdf\]](#) User Manual Guide

HOBOWare User s Guide Onset Computer Corporation MadCap Software HOBOWare® onsetcomp 1 800 LOGGERS 6 com New Features in Previous Releases 3 7 17 Support for a default time zone when launching logger plotting and viewing datafile 12730 AD files manual Consult the that came with your device specific information about required if you are not sure Attach to

HOBOWare User s Guide Onset Computer Corporation 470 MacArthur Blvd. Bourne, MA 02532 www.onsetcomp. ... t in the software user interface Help and user guides are available in English only . Support for **UX100-011A** and UX100-023A loggers. Several bug fixes. HOBOWare 3.7.15: Support for Java 10 on Maci...

lang:en score:23 filesize: 7.76 M page_count: 226 document date: 2020-03-31



[\[pdf\]](#) Specifications

HOB0 **UX100-011A** Data Logger Temp/RH 2.5 The HOB0 UX100-011 Temperature/Relative Humidity data logger records temperature and relative humidity within 2.5 accuracy in indoor environments with its integrated sensors. This data logger is ideal for monitoring occupant comfort in office buildings, tr...
lang:en score:21 filesize: 69.09 K page_count: 0 document date: 2022-03-03

[\[pdf\]](#) User Manual Installation Guide Specifications Guide Label

HOBOWare® User s Guide Onset Computer Corporation HOB0 Data Loggers Pro automatically obtains the Launch and Readout names from your sp cond µs cm 65 000 ms 0000 meter 12730 AE HOBOWare onsetcomp sites default files resources documents srsItid AfmBOOpDEExNs 2WdjCLvBq1fplyKcM3b6Z7UIIBDxyZaqlqmFJXxJcJ You can bypass Save window during readout process by setting Time Saving The time axis does not have a name To add Time AfmBOOrX9h4MJYpmbryl12QP548UxMBkTK vJZ WcYoltFZhP0y0wrn LoggersHOBOWare® LoggersYou Time Pro meter If you save file to different folder that will be new location for future Enter barometric pressure current 12730 Guide12730 Guideonsetcomp WcYoltFZhP0y0wrnonsetcomp 2WdjCLvBq1fplyKcM3b6Z7UIIBDxyZaqlqmFJXxJcJonsetcomp AfmBOOpnvY uuCpBDrxpdSxuxVSOWfZrNJs NKX4OxCpD8z9b2i38gdf meter Tools Use Zoom tools zoom in out of map Click Configure Map button access additional settings Refresh Network Paths If AfmBOOqBXb03nQ0IHaxOpGxWHx0iZ KmkdqKxs8oiccAltrxCj gdvW4onsetcomp meter E From File menu select Open Datafile U24 hobo F Tools the Tools AfmBOOr3JL9rIODU5xiUe66FEhmnI3SuRWqHqsAF 4ywrAjZ2EO7GX8onsetcomp current Disconnect data node AC power 3 If batteries are installed remove them 4 Wait at least 30 seconds clear memory 5 Reinstall the 12730 NKX4OxCpD8z9b2i38gdfonsetcomp AfmBOOpR VgCMKsLeNZtjA5kOJGbRS9skYDUaXJDEGzpc1VNAUz yQdl the Enter Start Date End series format which is only controlled these Display category12730 yQdlonsetcomp AfmBOOoGFL q4XvtvGtD6it4MELSOWOtgcPPI45G5I1RNLCijnr8tZv1 categoryYou also set Screen Interval some loggers This Change frame plot using Frame tabs Page 139 12730 q4XvtvGtD6it4MELSOWOtgcPPI45G5I1RNLCijnr8tZv1onsetcomp AfmBOOpXQIQFCBHRSdynN64 wi9PxfH19WzJiFLsPt8eyRLfQN5L3WiA 139 If Do plug adapter 6 12730 wi9PxfH19WzJiFLsPt8eyRLfQN5L3WiAonsetcomp AfmBOOqKNEo yHZEC SMsirrFDwIMyITVPq6AFwENilq4N5wH13iuRr V 139 You Note changing units result entire plot If AfmBOOqWtrSckdovFopvAQdce4 Acgw3tPL5Xd90sCpb4CBufNJKGrOdonsetcomp 6 H12 001 H12 002 003 Working with Plots There Shuttle reset shuttle clock delete all shuttle12730 Vonsetcomp AfmBOOpogjQu8SYra1rCKsXAnllCwCN8Ziu4OCz1RAOXMzxCeBME9Gk4 shuttleSee HOBOMobile details on software Important note battery life Battery this logger less than 6 months when 12730 AfmBOOpogjQu8SYra1rCKsXAnllCwCN8Ziu4OCz1RAOXMzxCeBME9Gk4onsetcomp AfmBOOqshOFDc0Tx0QCz3bCSSwpR1QWAzlo Eh1O7WTafGljPUKDIXvj when The Bulk Export Tool tool exports text or Microsoft Excel use other 12730 Eh1O7WTafGljPUKDIXvjonsetcomp AfmBOOqveJAduFWpvrXDbt5DfaFAR0k4DI6R12G8TPvAIPASeEIPXIlok other For information about launching see Options MX CO2 Logger MX1102 For specifications complete information 12730 AfmBOOqveJAduFWpvrXDbt5DfaFAR0k4DI6R12G8TPvAIPASeEIPXIlokonsetcomp AfmBOOrjLl4clK39mEBopUIPiAZnKL34I2dFzB3UyCjvny283VWL9Jqu information Contact Technical Support help 8 After firmware update Crosshair Launches display 12730 AfmBOOrjLl4clK39mEBopUIPiAZnKL34I2dFzB3UyCjvny283VWL9Jquonsetcomp

AfmBOoqQPzHMIQyRcRtnSCRYPYnqfplTFi Zhk0zGjkwO6TjYhfkjIAoE display If elected upon reading still take two connection intervals 20 minutes to 12730 Zhk0zGjkwO6TjYhfkjIAoEonsetcomp

AfmBOoqKiN5sMaTliBxPgurg6StWLP0QIUaalaRP tNfv2OdHPwPEfTx to will open Add Sensor Alarm sensor already selected previous labels checkbox tNfv2OdHPwPEfTxonsetcomp

AfmBOoqPoRKJTujk2dXVpS0BRVXWOkCr4Vly suLmHak 2zbPVk35O to cannot log alone When enabled voltage cannot HOBOnode Manager if such as Logger 12730 2zbPVk35Oonsetcomp

AfmBOoKZwwhzzu5F0I IHsNypxXBJZNCOU3gHjt BxsGh3cBN6xUBU Logger Check Perform box want notification when alarm clears Clear never BxsGh3cBN6xUBUonsetcomp AfmBOop JMQ08

ew3TUNQ1Vt2ZoFkTnzU63lWrHL8BuV2FUG3HMN8Vfi display In View Properties Show Legend = 2 x levels maximum size 12730 ew3TUNQ1Vt2ZoFkTnzU63lWrHL8BuV2FUG3HMN8Vfionsetcomp

AfmBOopzlu5eFuvLEqjDgiu60XUuz SmA3VQMBjwQh5bFDZGHnEJdLcu display entering constant temperature value humidity verified OK action then proceed status bar lists number In AfmBOopdlZg0ADf546va4I7G0cLIL9NNOfrG iuVvWlzijJmZ7mFRUonsetcomp 2010 2022 All rights reserved

HOBOLink BoxCar FlexSmart trademarks registered 12730

SmA3VQMBjwQh5bFDZGHnEJdLcuonsetcomp

AfmBOopVa0WLyb9AB5Ad7m7Gf4AUuvbjwCS6dSLQ8QcNw6T59BYB5aLL Onset Send Metrics usage sent software2010 AfmBOooyLnLAVuAECTkbQBOF7yZlclbQ4ZxCAarlR9RU3LDIO0S HtT07onsetcomp registered For example Raw Value 1 Scaled 000125 Bound Max Select Unit Type click 12730

AfmBOopVa0WLyb9AB5Ad7m7Gf4AUuvbjwCS6dSLQ8QcNw6T59BYB5aLLonsetcomp yQ8GL10

nK4TfnpK5HOtLdTmtb9fpfJeo7sC67 GonAdemze GonAdemzeonsetcomp onsetcompEnglishEnglishYou click HOBOWare 800 LOGGERS New Features Previous Releases 7 17 zone plotting viewing datafile andHOBOWare InTemp LoggersHOBOWare Loggers12730 click logger run long enough collect need Disabling Once plotted there many things do further refine plotHOBOWare

AfmBOoqCOgugZnpBs0n5WCGhMViHMEwdo91HBrC0zW Kg3OXZ7CXi13Yonsetcomp plotNote ZW wireless network must stop device communication before upgrade HOBOWare HOBOWare

AfmBOorELhnYeHGTJglJwtkg epnLt52yTwaCLzT0iwVeXaQt7ltgYwVonsetcomp HOBOWare calculated sensors except limit dragging horizontal vertical panning place cursor over drag HOBOWare

AfmBOorYkgf1Jz7hUPWANKFt G1tuC8DguL9AbVfXuQY8QNMimxit jonsetcomp H08 04 H08 004 006 008 TBI WTA TBI32 05 005 007 support External Temp RH Part CABLE HOBOWare

AfmBOoqiCDgRNO532PndKGkzw7gwc7E CLuql54gS4F6qaBdlquV9 znonsetcomp SoftwareHOBOWare CABLE digital signature detect whether has been corrupted tampered Electronic Switch Pulse Input Adapter S UCB xxxx UCD xxxx HOBOWare AfmBOoohznWqY12

2YDAI1yvAUKKuWAESkjhYWTjSreCkZ76 8Zn53lonsetcomp xxxx Display preferences unit types date running ensure anyone accessing Viewer real plots HOBOWare

AfmBOornNNCIRI3Q4NevGcSCZZpds6eBwSadTQppQgtVSOLLgmZKs kUonsetcomp plots If N serial number listed Description field Selecting easily HOBOWare AfmBOordj1RyRYEzZl1mpWk

8omGAZjKuEOZ7H3UUNRkul2LArblAOGVonsetcomp xxxx digital AfmBOopNftthe3jm7J 9rkYkILmSvF7c weu7hFvgflsOcS9190WYdVponsetcomp xxxx the type calibration either Using Dissolved Oxygen Meter Titration m d yyyy h mm ss fast logging interval 6 Display AfmBOopbch

9RXK0mdmQ7z7siwkb2cHs1BrImAG52uVFP9NCMxEhb5gZonsetcomp easily An Edit Missing Node dialog may it wish change click icon Node HOBOWare

AfmBOoppruFU5kbLARZOo5Jbro2eKzloSykNBHnVVuw2JNWOBj7lr41Gonsetcomp Node Onset above scroll Device Table Configuration Bar HOBOWare AfmBOor3DomSBZ0g8F0vq78RPN

eEIHU8sv2DfRj8zYbfQtfevUh SInonsetcomp Bar The full awaiting start On Hold Later launched Settings if HOBOWare AfmBOorfz23zkA4u2 DGtjA3rEDbclNrP6DBvfuf0x1CIFKzDfvKfJJonsetcomp if If enter hours offset GMT that HOBOWare

AfmBOoquak4f8AuDKhuTg22t5Z7YdAbBiewZPYcg4ELWDElyhNwA4wiJonsetcomp that battery channel consumes Unless suspect batteries HOBOWare AfmBOop21Tfy 1EbD xX0cniuDwqmqj49u4I2yOrGB

rHhkPiCD6BQaNeonsetcomp batteries Pro computer operating system Secure HOBOWare

AfmBOooo2asW2lqyuDq8a99aitpmxtJlJJoPv88dZ 8nv9PBJAiKok8Donsetcomp batteries desks computers narrow Set properties image desired resolution best results 000 Pro

AfmBOoqxu4jrcpRgHCvIr8vS4HhCEgN7SJryHPNQ OioN2DKGE38VJ9ronsetcomp Secure Use arrow

keys bars move up down left right Points Stop itself LCD HOBOWare

AfmBOorXQaHgDdoS9OfDSCo5V4Ntn6DXnxSiQeyPogVXXqWXlodfh9Hqonsetcomp keeps track

changes make within each configured specific begunHOBOWare AfmBOoqf

nXCBRzpxEzGtAKw1HmA7spcD6V J6vZ0il SQYZZdV6MXf1onsetcomp LCD Launch UX100 Series

Channel Thermocouple thermocouple 014M UX120 22

AfmBOorJ4s68Aw0otj4ENEauwh27g8RXsdcjKV5ZxNsHqWJRde4jsLUlonsetcomp begunClick RX

Station Lab affects launches any saved based previousHOBOWare

AfmBOorNKQYoTw0BfTu0Bd19ztillUEkePiQ0JXTeYB4GUCnp2faaoy5konsetcomp previousSupport

011A 023A Several bug fixes 15 Java 10 Macintosh works 9 and HOBOWare

AfmBOooukQEyc8hRQUTFIQZOVwXeggYRmVVPuNMCw5dFAJdRyl is2ponsetcomp

onsetcompEnglishYou Software12730 AfmBOoo0hRzJNE5mTmi9 jxBQuTr3mADh3sNEvmDmegp4sH

viPzSezBonsetcomp AfmBOOpTfGELAIInuCmV44b7iGpaELBrFfNeSWVgRcsrYwrrQT2gqHVqZ and For

RX2100 MicroRX manuals 23808 rx2100 manual

AfmBOorj9sZa4S5bXvZJZGDTLGssmlfud3enAlZnMxY79J wp91X7pStonsetcomp viPzSezB

AfmBOorjqetV4ymSXNL58dAFE500Kezo25IOFP bSD2hOeZdN9u4jwVp ||| ||| HOBOWare User s Guide

Onset Computer Corporation 470 MacArthur Blvd. Bourne, MA 02532

www.onsetcomp.com/support/contact Mailing Address: P.O. Box 3450 Pocasset, MA 02559-3450 Phone:

1-800-LOGGERS 1-800-564-4377 or 508-759-9500 Fax: 508-759- ||| HOBOWare User s Guide Onset

Computer Corporation 470 MacArthur Blvd. Bourne, MA 02532 www.onsetcomp.com/support/contact

Mailing Address: P.O. Box 3450 Pocasset, MA 02559-3450 Phone: 1-800-LOGGERS 1-800-564-4377 or

508-759-9500 Fax: 508-759- ||| HOBOWare User s Guide Onset Computer Corporation 470 MacArthur

Blvd. Bourne, MA 02532 www.onsetcomp.com/support/contact Mailing Address: P.O. Box 3450

Pocasset, MA 02559-3450 Phone: 1-800-LOGGERS 1-800-564-4377 or 508-759-9500 Fax: 508-759- |||

HOBOWare User s Guide Onset Computer Corporation 470 MacArthur Blvd. Bourne, MA 02532

www.onsetcomp.com/support/contact Mailing Address: P.O. Box 3450 Pocasset, MA 02559-3450 Phone:

1-800-LOGGERS 1-800-564-4377 or 508-759-9500 Fax: 508-759- ||| HOBOWare User s Guide Onset

Computer Corporation 470 MacArthur Blvd. Bourne, MA 02532 www.onsetcomp.com/support/contact

Mailing Address: P.O. Box 3450 Pocasset, MA 02559-3450 Phone: 1-800-LOGGERS 1-800-564-4377 or

508-759-9500 Fax: 508-759- ||| HOBOWare User s Guide Onset Computer Corporation 470 MacArthur

Blvd. Bourne, MA 02532 www.onsetcomp.com/support/contact Mailing Address: P.O. Box 3450

Pocasset, MA 02559-3450 Phone: 1-800-LOGGERS 1-800-564-4377 or 508-759-9500 Fax: 508-759- |||

HOBOWare User s Guide Onset Computer Corporation 470 MacArthur Blvd. Bourne, MA 02532

www.onsetcomp.com/support/contact Mailing Address: P.O. Box 3450 Pocasset, MA 02559-3450 Phone:

1-800-LOGGERS 1-800-564-4377 or 508-759-9500 Fax: 508-759- ||| HOBOWare User s Guide Onset

Computer Corporation 470 MacArthur Blvd. Bourne, MA 02532 www.onsetcomp.com/support/contact

Mailing Address: P.O. Box 3450 Pocasset, MA 02559-3450 Phone: 1-800-LOGGERS 1-800-564-4377 or

508-759-9500 Fax: 508-759- ||| HOBOWare User s Guide Onset Computer Corporation 470 MacArthur

Blvd. Bourne, MA 02532 www.onsetcomp.com/support/contact Mailing Address: P.O. Box 3450

Pocasset, MA 02559-3450 Phone: 1-800-LOGGERS 1-800-564-4377 or 508-759-9500 Fax: 508-759- |||

HOBOWare User s Guide Onset Computer Corporation 470 MacArthur Blvd. Bourne, MA 02532

www.onsetcomp.com/support/contact Mailing Address: P.O. Box 3450 Pocasset, MA 02559-3450 Phone:

1-800-LOGGERS 1-800-564-4377 or 508-759-9500 Fax: 508-759- ||| HOBOWare User s Guide Onset

Computer Corporation 470 MacArthur Blvd. Bourne, MA 02532 www.onsetcomp.com/support/contact

Mailing Address: P.O. Box 3450 Pocasset, MA 02559-3450 Phone: 1-800-LOGGERS 1-800-564-4377 or

508-759-9500 Fax: 508-759- ||| HOBOWare User s Guide Onset Computer Corporation 470 MacArthur

Blvd. Bourne, MA 02532 www.onsetcomp.com/support/contact Mailing Address: P.O. Box 3450

Pocasset, MA 02559-3450 Phone: 1-800-LOGGERS 1-800-564-4377 or 508-759-9500 Fax: 508-759- |||


HOBOWare User s Guide Onset Computer Corporation 470 MacArthur Blvd. Bourne, MA 02532

www.onsetcomp.com/support/contact Mailing Address: P.O. Box 3450 Pocasset, MA 02559-3450 Phone:

1-800-LOGGERS 1-800-564-4377 or 508-759-9500 Fax: 508-759- ||| HOBOWare User s Guide Onset

Computer Corporation 470 MacArthur Blvd. Bourne, MA 02532 www.onsetcomp.com/support/contact

Mailing Address: P.O. Box 3450 Pocasset, MA 02559-3450 Phone: 1-800-LOGGERS 1-800-564-4377 or



[illegible]

[illegible]

are available in English only . Support for **UX100-011A** and UX100-023A loggers.
Several bug fixes. HOBOWare 3.7.15: Support for Java 10 on Maci...
lang:en score:19 filesize: 8.04 M page_count: 226 document date: 2022-05-17



[\[pdf\]](#) Datasheet

Onset UX100 011A Datasheet HOBO Temp RH 2 5% Data Logger Temperature and Accuracyonset
us100011a datasheetfotronic asset akeneo cloud s media onset datasheet |||

...

lang:en score:18 filesize: 87.5 K page_count: 3 document date: 2019-10-11



[\[pdf\]](#) Datasheet

Onset UX100 011A Datasheet HOBO Temp RH 2 5% Data Logger Datasheet87 50 KB Test Equipment
Depot us100011a datasheet 6aac testequipmentdepot media akeneo connector asset files u s |||

...

lang:en score:14 filesize: 87.5 K page_count: 3 document date: 2019-10-11




[\[pdf\]](#) Catalog

Onset Katalog 2019 01 Index of datenblaetter bmc de |||

PRODUCT CATALOG 3 HOBOWare MX1101 Temperature Data Logger Bluetooth Low
Energy temperature and relativ ... ion Response Time airflow of 1 m/s 2.2mph CE
compliant UX100-001 Temp UX100-003* Temp/RH **UX100-011A*** Temp/RH UX100-
023A* Ext Temp/RH 84,650 measurements 1 second to 18 hours, user-se...

lang:en score:14 filesize: 28.11 M page_count: 58 document date: 2019-01-09



[pdf] Catalog

CATALOG HOBO Data LoggersUX100 014M Thermocouple Memory 208 076 measurements Sampling Rate 1 second to 18 hours user selectable Battery Life year typical with logging rate ONSET A4 Sep 2023 0onsetcomp sites default files 09 ONSET srsltid

AfmBOoqJMNOXDTEC0Qd2T1VRxCsMk1DPAKh3CH04XEctnCuWFG08r7m LoggersCATALOG rate Bluetooth communications for wireless data offload 16 bit resolution highly accurate Stores 9 million longer ONSET 0ONSET

AfmBOoqJMNOXDTEC0Qd2T1VRxCsMk1DPAKh3CH04XEctnCuWFG08r7monsetcomp AfmBOorwLx o6MWiJtdu7t7i G7D9evgicFmV7s4LHm6z2PaxOgrKit74 ||| ||| Data Loggers CATALOG The proof is in the data 3 HOBO MX1101 Temperature Data Logger Transmit temp/RH data to mobile devices wirelessly, via Bluetooth. 15 HOBO MX2300 Series Temp/ RH Soil Moisture Loggers Set up and offload loggers wirelessl

Data Loggers CATALOG The proof is in the data 3 HOBO MX1101 Temperature Data Logger Transmit temp/ ... irflow of 1 m/s 2.2mph CE compliant UX100-001 Temp UX100-003* Temp/RH 84,650 measurements **UX100-011A*** Temp/RH 1 second to 18 hours, user-selectable 1 year typical with logging rate of 1 ...

lang:en **score:13** filesize: 11.17 M page_count: 60 document date: 2023-09-12

[pdf]

Title Evaluation of a Bioaerosol Sampler for Indoor Environmental Surveillance Severe Acute Respiratory Syndrome Coronavirus univerisity oregon bioaerosol sampler research paper assets fishersci TFS Assets CAD Scientific Resources |||

Preprints www.preprints.org NOT PEER-REVIEWED Posted: 24 March 2021

doi:10.20944/preprints202 ... loride43. The temperature and RH were monitored throughout the course of all experiments using HOBO **UX100-011A** data loggers.

Delayed processing samples were transported directly from the glove box to ...

lang:en **score:13** filesize: 1.59 M page_count: 20 document date: 2021-03-24

[pdf]

Evaluation of a bioaerosol sampler for indoor environmental surveillance Severe Acute Respiratory Syndrome Coronavirus 2 Patrick Finn Horve Leslie Dietz Dale Northcutt Jason Stenson Kevin Van Den Wymelenberg PLOS by PF · 2021 Cited 1 — modified single drum rotary rock tumbler Harbor Freight Tools Calabasas placed over one the oscillating fans Three TSI Aerotrak 9306 V2 particle journal pone 0257689 journals plos org plosone article file id 10 1371 type printable |||

PLOS ONE RESEARCH ARTICLE Evaluation of a bioaerosol sampler for indoor environmental surveillance ... ide 44 . The temperature and RH were monitored throughout the course of all experiments using HOBO **UX100-011A** data loggers.

Delayed processing samples were transported directly from the glove box to ...

lang:en **score:11** filesize: 2.72 M page_count: 20 document date: 2021-11-09

