

ELECOM P-TIPS03

ELECOM P-TIPS03 Stylus Pen Replacement Tips User Manual

Model: P-TIPS03

1. INTRODUCTION

This manual provides essential instructions for the proper use and maintenance of your ELECOM P-TIPS03 Stylus Pen Replacement Tips. These tips are designed to replace worn-out tips on compatible ELECOM 2-way stylus pens and AL.STYLUS series pens, ensuring continued smooth operation and responsiveness.

2. PRODUCT OVERVIEW

The ELECOM P-TIPS03 replacement tips are crafted with conductive fiber, providing a smooth and responsive experience for touch screen devices. Each package contains two replacement tips, allowing for convenient replacement when needed.

かぶせるタイプの 交換ペン先



2個入り

タッチペン本体は付属しておりません

Image: Close-up view of the ELECOM P-TIPS03 conductive fiber replacement tips, highlighting their woven texture.



Image: The ELECOM P-TIPS03 product packaging, illustrating the two replacement tips and indicating compatible stylus models.

3. COMPATIBILITY

These replacement tips are specifically designed for the conductive fiber side of the following ELECOM stylus pen series:

- **2-Way Stylus Pens:** P-TP2WY01 series (e.g., P-TP2WY01BK, P-TP2WY01WH), PCTP2WY01 series (e.g., PCTP2WY01GY, PCTP2WY01GD), PWTP2WY01BK.
- **AL.STYLUS Series:** P-TPATCF01 series (e.g., P-TPATPCF01GY), PCTPATCF01 series.

Ensure your stylus model is listed above for proper fit and function.

対応商品②



AL.STYLUS

- **P-TPATCF01GY**
- **P-TPATCF01GD**

Image: Visual representation of compatible ELECOM 2-Way type stylus pens and AL.STYLUS pens, indicating the models for which these tips are suitable.

4. INSTALLATION INSTRUCTIONS

To replace the stylus tip, follow these steps:

1. Gently twist the existing, worn-out tip counter-clockwise to remove it from the stylus pen body.
2. Align the new ELECOM P-TIPS03 replacement tip with the pen body.
3. Carefully twist the new tip clockwise onto the pen body until it is securely fastened. Do not overtighten.

The stylus pen body is not included with these replacement tips.

対応商品①



2WAYタイプ 導電繊維側

- P-TP2WY01BK
- P-TP2WY01WH
- PWTP2WY01BK

Image: A diagram demonstrating the process of twisting an old stylus tip off and twisting a new replacement tip on.

5. OPERATING INSTRUCTIONS

Once the replacement tip is securely installed, your stylus pen is ready for use. The conductive fiber tip provides a smooth gliding experience across your device's screen, allowing for precise input for drawing, writing, and navigation.

滑り心地が良く なめらかな操作性



Image: A stylus pen with the conductive fiber tip actively being used on a tablet screen, demonstrating smooth operation for drawing.

6. MAINTENANCE

To ensure the longevity and optimal performance of your ELECOM P-TIPS03 replacement tips:

- Keep the tips clean and free from dust or debris. A soft, dry cloth can be used for gentle cleaning.
- Avoid applying excessive pressure when using the stylus, as this can prematurely wear down the tip.
- Store the stylus in a protective case or cover when not in use to prevent damage to the tip.
- Replace tips when they show signs of significant wear, such as reduced responsiveness or scratching on the screen.

7. TROUBLESHOOTING

If you experience issues with your stylus pen after replacing the tip, consider the following:

- **Unresponsive or Intermittent Contact:**

- Ensure the tip is securely fastened to the stylus body.
- Check the screen of your device for any dirt, smudges, or screen protectors that might interfere with contact.
- Verify that the tip itself is not excessively worn or damaged. If so, replace it with a new one.

- **Scratching on Screen:**

- Immediately cease use if you notice scratching. This indicates a damaged or defective tip.
- Inspect the tip for any sharp edges or foreign particles embedded in the conductive fiber.
- Replace the tip if any damage is found.

If problems persist, refer to the support information provided by ELECOM.







8. SPECIFICATIONS

| Attribute | Detail |
|--------------------|--|
| Brand | ELECOM |
| Model Number | P-TIPS03 |
| Material | Conductive Fiber (Tip), Aluminum (Stylus body, not included) |
| Package Dimensions | 4.92 x 1.81 x 0.39 inches |
| Item Weight | 0.704 ounces |
| Compatible Devices | iPhone, Android, iPad (when used with compatible ELECOM stylus pens) |
| Unit Count | 2 Tips per pack |

9. WARRANTY AND SUPPORT

For warranty information or technical support regarding your ELECOM P-TIPS03 replacement tips, please refer to the official ELECOM website or contact ELECOM customer service directly. Keep your purchase receipt as proof of purchase.

ELECOM Official Website: <https://www.elecom.co.jp/global/en/>

| | |
|---|---|
|  | <p>ELECOM P-TPACSTEN02 Series Stylus Pen User's Guide</p> <p>Comprehensive user's guide for the ELECOM P-TPACSTEN02 series stylus pen. Provides detailed information on features, specifications, charging, LED indicators, usage precautions, troubleshooting, and compliance (FCC, RoHS). Includes manufacturer details and global support.</p> |
|  | <p>ELECOM P-TPACSTAP07 Stylus Pen User Guide</p> <p>User guide for the ELECOM P-TPACSTAP07 series stylus pen, providing instructions on usage, specifications, precautions, charging, and battery status.</p> |
|  | <p>ELECOM P-TPACST05 Stylus Pen User Guide</p> <p>User guide for the ELECOM P-TPACST05 Stylus Pen, covering its features, specifications, usage instructions, precautions, and limitation of liability. Includes details on power, charging, battery status, product specifications, and safety information.</p> |
|  | <p>ELECOM EC-AC13A 45W USB-C PD Charger User Manual Specifications & Safety</p> <p>Download the user manual for the ELECOM EC-AC13A 45W USB-C PD charger. Find specifications, connection guide, safety precautions, and compliance information.</p> |
|  | <p>ELECOM Screen Protector for Drawing: Application Guide and Precautions</p> <p>Detailed instructions and safety precautions for applying the ELECOM Screen Protector for Drawing, designed to protect your device's LCD screen. Includes tips for installation and usage.</p> |
|  | <p>ELECOM Screen Protector for Drawing - Installation Guide and Precautions</p> <p>Detailed installation guide and important precautions for the ELECOM Screen Protector for Drawing. Learn how to apply the film, remove air bubbles, and understand usage guidelines for stylus pens and device compatibility.</p> |