Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Nokia TA-1190

Nokia 106 (2018) TA-1190 Feature Phone

User Manual

1. Overview

The Nokia 106 (2018) TA-1190 is a reliable and durable feature phone designed for essential communication. It offers extended battery life, a robust build, and core functionalities like calling, texting, and basic entertainment. Its compact and contoured design ensures a comfortable grip.



Figure 1: Front view of the Nokia 106 phone, showing its display and keypad.

2. What's in the Box

Upon unboxing your Nokia 106, please ensure all the following items are present:

- Nokia 106 Handset
- Removable 800 mAh Battery
- Charger Adapter
- Quick Start Guide (not included in this manual)



Figure 2: The Nokia 106 phone and its included accessories, as packaged in the retail box.

3. Setup

3.1 Inserting the SIM Card(s) and Battery

1. **Remove the back cover:** Gently pry open the back cover of the phone using the notch provided, typically at the bottom edge.
2. **Insert SIM card(s):** Locate the SIM card slot(s). This model supports Dual SIM functionality. Carefully slide your SIM card(s) into the designated slot(s) with the gold contacts facing down, ensuring they click into place.
3. **Insert the battery:** Align the battery contacts with the phone's contacts and gently press the battery into its compartment.
4. **Replace the back cover:** Press the back cover firmly until it snaps into place all around the edges.



Figure 3: The Nokia 106 display indicating dual SIM card readiness.

3.2 Charging the Device

Before first use, it is recommended to fully charge the battery. Connect the charger adapter to the phone's charging port and plug it into a wall outlet. The battery indicator on the screen will show charging progress. A full charge can provide approximately 15 hours of talk time or up to 21 days of standby time.

3.3 Powering On/Off

- **To Power On:** Press and hold the Power/End Call key until the Nokia logo appears.
- **To Power Off:** Press and hold the Power/End Call key until the power off options appear, then select 'Power off'.

3.4 Network Compatibility Note

Please verify compatibility with your service provider prior to purchase and use. This device operates on 2G GSM networks. Note that it may not be compatible with certain providers in the US, including T-Mobile, depending on their network phase-out plans for 2G services.

4. Operating the Device

4.1 Basic Navigation

Use the navigation keys (up, down, left, right) and the center select key to move through menus and make selections. The left and right soft keys perform functions indicated on the screen directly above them.

4.2 Making and Receiving Calls

- **To make a call:** Enter the phone number using the keypad and press the Call key (green button).
- **To answer a call:** Press the Call key when the phone rings.
- **To end a call:** Press the End Call key (red button).

4.3 Sending and Receiving Text Messages (SMS)

- Navigate to the 'Messages' menu.
- Select 'Create message' or 'New message'.
- Enter your text using the keypad. Press a key multiple times for different characters (e.g., '2' for A, B, C, 2).
- Enter the recipient's number or select from contacts.
- Select 'Send'.

The phone can store up to 500 text messages.

4.4 Contacts Management

Access the 'Contacts' menu to save, edit, or delete contact information. The phone supports storage for up to 2000 contacts.

4.5 Preloaded Applications and Games

The Nokia 106 comes with classic games like Snake Xenzia and other try-and-buy games such as Nitro Racing, Danger Dash, and Tetris. These can be accessed from the main menu.



Figure 4: The Nokia 106 display showing the application menu with icons for calls, messages, contacts, and games like Snake Xenzia.

5. Maintenance

5.1 Battery Care

- Use only original Nokia chargers and batteries.
- Avoid exposing the battery to extreme temperatures.
- Do not puncture, disassemble, or short-circuit the battery.
- If the battery is swollen or damaged, discontinue use and dispose of it properly.

5.2 Cleaning the Device

Wipe the phone regularly with a soft, lint-free cloth. Do not use harsh chemicals, cleaning solvents, or strong detergents. Avoid getting moisture in any openings.

5.3 Storage

Store the device in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, ensure the battery is partially charged (around 50%) to maintain its health.

6. Troubleshooting

Problem	Possible Cause	Solution
Phone does not power on	Battery is drained or not inserted correctly.	Charge the battery. Ensure the battery is correctly inserted.
No network signal	SIM card not inserted, out of network coverage, or network issue.	Ensure SIM card is correctly inserted. Move to an area with better coverage. Contact your service provider.
Cannot make/receive calls	No network signal, incorrect number dialed, or call barring activated.	Check signal strength. Verify the number. Check call settings.
Battery drains quickly	Frequent use, old battery, or background processes.	Reduce usage. Consider replacing the battery if it's old. Power off when not in use.

If the problem persists after trying these solutions, please contact customer support.

7. Specifications

Feature	Detail
Model	TA-1190
Operating System	KaiOS
Display	1.8 inches, 128 x 160 resolution, LED
Processor	MTK 6261D
RAM	4 MB
Internal Storage	4 MB
Battery Capacity	800 mAh (Removable)
Talk Time	Up to 15 hours
Standby Time	Up to 21 days
SIM Support	Dual SIM (as per description and image, though product title specifies Single Sim)
Network Technology	2G GSM (Dual-Band 850/1900)
Dimensions	4.8 x 4.69 x 1.34 inches (Package)
Weight	2.48 ounces (70.2 grams)

Feature	Detail
Connectivity	USB
Audio Jack	No headphone jack

8. Warranty and Support

Your Nokia 106 (2018) TA-1190 is covered by a limited manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including warranty period and coverage details.
For technical support, troubleshooting assistance beyond this manual, or warranty claims, please contact Nokia customer service through their official website or the contact information provided in your product packaging. Keep your proof of purchase for warranty validation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question