

## KYG HU-XI-201

# KYG 7-in-1 Baby Food Maker User Manual

Model: HU-XI-201

## 1. INTRODUCTION AND OVERVIEW

---

The KYG 7-in-1 Baby Food Maker is a versatile appliance designed to simplify the preparation of healthy and nutritious meals for your baby. This multifunctional device combines seven essential functions: **Steaming**, **Blending**, **Heating**, **Sterilizing**, **Automatic Cleaning**, **Defrosting**, and **Pulsing**. Crafted from BPA-free materials, it ensures the safety and well-being of your child.

Its intuitive touch screen interface makes operation straightforward, allowing you to prepare baby food efficiently while saving time.



Image 1.1: The KYG 7-in-1 Baby Food Maker, a compact and efficient appliance for preparing baby food.



Image 1.2: Overview of the seven functions: Steaming, Blending, Heating, Defrosting, Sterilizing, Cleaning, and Auto mode.

## 2. SAFETY INSTRUCTIONS

Please read all safety instructions carefully before using the appliance to ensure safe operation and prevent damage.

- **Integrated Safety Lock:** The baby food maker is equipped with a built-in safety lock. The motor will not start if the mixing bowl is not correctly positioned or if the lid is not properly installed. Always ensure all components are securely in place before operation.
- **Overheating and Overload Protection:** The device features protection against overheating and overloading. If the unit stops unexpectedly, switch it off and allow it to cool down for a few minutes before reconnecting. This will reset the protection mechanism.
- **BPA-Free Materials:** The Tritan container (300 ml) and PP steaming basket are made from BPA-free materials, ensuring they are safe for your baby's health.
- **Anti-Scald Handle:** Use the anti-scald handle to safely remove the steaming basket after cooking.
- **Electrical Safety:** Do not immerse the main unit in water or any other liquid. Ensure your hands are dry when plugging or unplugging the appliance.
- **Child Safety:** Keep the appliance out of reach of children. Supervise children if they are near the appliance during operation.
- **Ventilation:** Ensure adequate ventilation around the appliance during use. Do not block any ventilation openings.



Image 2.1: Illustrates BPA-free materials, the safety lock mechanism, and automatic cleaning function.

### 3. PRODUCT COMPONENTS

Familiarize yourself with the different parts of your KYG Baby Food Maker:

- **Main Body:** The base unit containing the motor and heating element.
- **Rotary Cover of Water Tank:** Covers the water reservoir.
- **Spill-Proof Cover:** Additional cover for the stirring cup.
- **Lid of the Stirring Cup:** Seals the stirring cup during operation.
- **Steaming Basket:** Used for steaming food ingredients.
- **Blade Holder:** Holds the blending blade.
- **Stirring Cup:** The main container for blending and processing food.



Image 3.1: Exploded view showing the main body, stirring cup, blade holder, steaming basket, and various covers.

## 4. SETUP

Before first use, clean all removable parts as described in the 'Maintenance and Cleaning' section. Ensure the appliance is placed on a stable, flat, and heat-resistant surface.

1. **Fill Water Tank:** Open the rotary cover of the water tank and fill it with clean water. Do not exceed the maximum fill line.
2. **Assemble Components:** Place the blade holder into the stirring cup, then insert the steaming basket (if steaming) or place food directly into the stirring cup (for blending). Secure the lid onto the stirring cup.
3. **Place Stirring Cup:** Position the assembled stirring cup onto the main body, ensuring it clicks securely into place. The safety lock prevents operation if not correctly seated.



Image 4.1: Demonstrates how to easily fill the large water tank for steaming functions.

## 5. OPERATING INSTRUCTIONS

The KYG Baby Food Maker offers multiple functions accessible via its touch screen control panel.

# 5 in 1 Multifunction



## Clean

The auto-clean function will make cleaning much easier.



## Steam

Only need 20min max to cooked fruits and vegetables.



## Sterilizationg & Defrosting & Reheating

1. Touch this button to sterilize the mixing bowl with steam at high temperature.
2. you can also use this function to defrost refrigerated food and cold food.
3. It can also be used to reheat cold puree.



## Pulse

The pulse function helps you stir manually.



## Auto

Mix all of your preparation and choose the perfect texture for baby's needs.



Image 5.1: The control panel displaying various functions like Clean, Steam, Disinfect, Auto, and Pulse.

## 5.1. Steaming

This function allows you to steam fruits, vegetables, meat, or fish, preserving vitamins and nutrients.

1. Prepare ingredients: Wash, peel, and cut food into small pieces (approx. 1-2 cm).
2. Place food in the steaming basket.
3. Fill the water tank (refer to Section 4).
4. Place the steaming basket into the stirring cup and secure the lid.
5. On the control panel, select the 'Steam' function. Adjust steaming time if necessary using the '+' and '-' buttons.
6. Press the 'Start' button to begin steaming. The device will automatically stop when the cycle is complete.

## 5.2. Blending (Mixing)

After steaming, you can blend the cooked food to the desired consistency.

1. Carefully remove the steaming basket from the stirring cup using the anti-scald handle.
2. Transfer the steamed food into the stirring cup (ensure the blade holder is in place).

3. Secure the lid.
4. Select the 'Auto' function for automatic blending or 'Pulse' for manual control.
5. Press 'Start' for Auto mode, or repeatedly press 'Pulse' until desired consistency is achieved.

### **5.3. Heating (Reheating)**

Use this function to warm up previously prepared purees or baby food.

- Place the food in the stirring cup.
- Select the 'Heat' function (often combined with defrosting/sterilization icon).
- Adjust heating time as needed.
- Press 'Start'.

### **5.4. Sterilization**

This function uses steam to sterilize the mixing bowl or small accessories like pacifiers.

- Ensure the stirring cup is clean and empty.
- Fill the water tank.
- Place the stirring cup (or items to be sterilized) into the main unit and secure the lid.
- Select the 'Disinfect' function.
- Press 'Start'.

### **5.5. Defrosting**

Thaw frozen baby food portions safely.

- Place the frozen food in the stirring cup.
- Fill the water tank.
- Select the 'Defrost' function (often combined with heating/sterilization icon).
- Adjust defrosting time.
- Press 'Start'.



Image 5.2: A visual guide to the steaming and blending process, from filling water to ready puree.

## 6. MAINTENANCE AND CLEANING

Regular cleaning ensures hygiene and extends the lifespan of your appliance.

- **Automatic Cleaning:** The device features an 'Auto-Clean' function. Fill the stirring cup with water and select the 'Clean' function on the control panel. This helps loosen food residue.
- **Manual Cleaning:** All removable parts, except the main unit, can be easily cleaned. The stirring cup, steaming basket, and lids are dishwasher safe.
- **Blade Cleaning:** The blade and its unit are removable for thorough cleaning. Wash them quickly with water and mild detergent. Be cautious as the blade is sharp.
- **Main Unit:** Wipe the main body with a damp cloth. Do not immerse it in water.
- **Descaling:** Periodically descale the water tank to prevent mineral buildup. Use a descaling solution suitable for kitchen appliances and follow the product instructions.



## Easy clean

Image 6.1: Shows the ease of cleaning the removable blade under running water and dishwasher compatibility for the stirring cup and steaming basket.

## 7. TROUBLESHOOTING

If you encounter any issues with your KYG Baby Food Maker, refer to the following common solutions:

Problem	Possible Cause	Solution
Appliance does not start.	Mixing bowl or lid not correctly installed. Safety lock engaged.	Ensure the mixing bowl is securely seated and the lid is properly closed.
Appliance stops during operation.	Overheating or overload protection activated.	Switch off the device, unplug it, and allow it to cool down for a few minutes before restarting. Reduce food quantity if overloading.
Food is not blending smoothly.	Insufficient liquid or food pieces are too large.	Add a small amount of water or breast milk/formula. Cut food into smaller, more uniform pieces before blending. Use the 'Pulse' function for better control.

Problem	Possible Cause	Solution
Steam function not working.	Water tank is empty or low.	Fill the water tank to the appropriate level.
Unpleasant odor during first use.	Normal for new appliances.	This is normal and will dissipate after a few uses. Ensure good ventilation.

## 8. SPECIFICATIONS

Key technical specifications for the KYG 7-in-1 Baby Food Maker:

Feature	Specification
Brand	KYG
Model	HU-XI-201
Color	White
Product Dimensions	25.9 x 14 x 29.5 cm (10.2 x 5.5 x 11.6 inches)
Item Weight	2.75 Kilograms (6.06 lbs)
Heating Power	300W
Stirring Power	130W
Rated Power	220-240V~ 50/60Hz
Water Tank Capacity	200 ml
Stirring Capacity	300 ml (approx. 10 oz)
Special Features	Safety Lock



- **Heating Power : 300W**
- **Rated Power : 220V-240V~ 50/60Hz**
- **Water Tank Capacity : 200ml**
- **Net Weight : 1.9kg**
- **Stirring Power : 130W**
- **Stirring Capacity : 300ml**
- **Gross Weight : 2.7kg**

Image 8.1: Detailed dimensions of the KYG Baby Food Maker.

## 9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or contact KYG customer service directly. Keep your proof of purchase for any warranty claims. For further assistance, you may visit the official KYG website or contact their support team via the contact details provided in your product packaging.