

[Manuals.plus](#) /

› [FENIFOX](#) /

› FENIFOX Wireless Keyboard and Mouse User Manual

FENIFOX 2AJIS-DF22 Pink Keyboard

FENIFOX Wireless Keyboard and Mouse User Manual

Model: 2AJIS-DF22 Pink Keyboard

PRODUCT OVERVIEW

The FENIFOX Wireless Keyboard and Mouse combo offers a comfortable and efficient computing experience. Designed with ergonomics and quiet operation in mind, this compact full-size set is ideal for various environments, from home offices to libraries. It connects wirelessly via a single USB receiver, providing a stable connection for seamless productivity.



Image: The FENIFOX Wireless Keyboard and Mouse combo, showcasing its sleek design and included USB receiver.

Key Features

- **Ergonomic Design:** The keyboard's tilt angle and the mouse's contour curve are engineered to reduce fatigue during extended use.

- **Silent Operation:** Features scissor-foot 'X' keys on the keyboard for stability and silent mouse buttons, ensuring a low-noise experience.
- **Power Saving:** Equipped with a low-power intelligent chip, the devices automatically enter power-saving mode after a period of inactivity.
- **Plug and Play:** Utilizes a single USB receiver for both keyboard and mouse, requiring only one USB port for immediate use.
- **Compact Full-size:** A 102-key layout with a number pad, saving space while maintaining full functionality.
- **Stable Wireless Transmission:** Provides a reliable connection up to 10 meters (33 feet) in low-interference environments.



Image: Close-up of the keyboard illustrating its ergonomic tilt angle for comfortable typing.

WHISPER-QUIET KEYS AND BUTTONS

Isissor-key-switch Provide Smooth Typing And Sensitive Response, Lowest Volume Keyboard Keys And Quiet Mouse Button.



Image: Depiction of the quiet keys and buttons, highlighting the low-noise operation suitable for various environments.

SETUP GUIDE

Battery Installation

The keyboard requires 2 AA batteries, and the mouse requires 2 AAA batteries. Batteries are not included with the product and must be prepared in advance.

1. Locate the battery compartment on the underside of the keyboard and mouse.
2. Open the battery compartment cover.
3. Insert the batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.

① Batteries Slot (Need 2*AAA,not included)

② Power Switch

③ Non-slip pad

① Power Switch

② Nano receiver (Packed in a small transparent bag)



Image: Underside view of the keyboard and mouse, showing the battery slots, power switches, and the nano receiver storage.

Connecting the Device

The keyboard and mouse share a single USB receiver for convenient plug-and-play functionality.

1. Locate the nano USB receiver, typically stored in a small transparent bag or within the mouse's battery compartment.
2. Plug the USB receiver into an available USB port on your computer.
3. Turn on the power switch for both the keyboard and the mouse. The power switch for the keyboard is usually on the top right side, and for the mouse, it's on the underside.
4. Wait for your computer to automatically recognize and install the necessary drivers. The devices should be ready for use shortly.

Pairing/Repairing Devices (If Connection is Lost)

If your keyboard or mouse loses connection or does not respond, you may need to re-pair them with the USB receiver.

Repairing the Keyboard:

1. Ensure the keyboard is turned ON.

2. Press and hold the "ESC" and "+/=" keys simultaneously. The keyboard will enter repair mode, indicated by the low voltage indicator lighting up.
3. Within 20 seconds, insert the USB receiver into your computer.
4. If the repair is successful, the LED indicator will turn off immediately, and the keyboard will be available for use. If the repair fails, the keyboard will exit repair mode after 20 seconds, and the LED will go out. If this happens, restart from step 1.

Repairing the Mouse:

1. Turn off the mouse power and remove the USB receiver from your computer.
2. Turn the mouse ON.
3. Press and hold the left button, scroll wheel, and right button simultaneously for 1 second. The mouse will enter a 20-second pairing mode.
4. Plug the USB receiver back into your computer within these 20 seconds.
5. The mouse is successfully paired if it begins to function. If not, restart from step 1.

OPERATING INSTRUCTIONS

Basic Usage

Once connected, the FENIFOX Wireless Keyboard and Mouse operate like standard peripherals. The keyboard features a full 102-key layout, including a numeric keypad for data entry. The mouse provides precise cursor control with silent left and right click buttons.

Power Saving Mode

To conserve battery life, both the keyboard and mouse are designed with an intelligent power-saving chip. After a period of inactivity, the devices will automatically enter a sleep mode. For example, if the keyboard is not used for 30 seconds, its indicator light will go out to save power. To wake up the device, simply click any key on the keyboard or move/click the mouse.

Compatibility

The FENIFOX Wireless Keyboard and Mouse combo is widely compatible with various operating systems, including:

- Windows (XP, 7, 8, 10, 11)
- Mac OS (MacBook, etc.)
- Linux

It is suitable for use with PCs, laptops, tablets, and notebooks.



Image: Visual representation of the wide compatibility of the keyboard and mouse with various operating systems and devices.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your FENIFOX Wireless Keyboard and Mouse.

- **Cleaning:** Use a soft, dry cloth to wipe down the surfaces of the keyboard and mouse. For stubborn dirt, a slightly damp cloth with mild soap can be used, ensuring no liquid enters the internal components. Avoid abrasive cleaners or solvents.
- **Battery Replacement:** Replace batteries when performance degrades or the low voltage indicator lights up consistently. Always use fresh batteries of the specified type (AA for keyboard, AAA for mouse).
- **Storage:** When not in use for extended periods, turn off the power switches on both devices and consider removing the batteries to prevent leakage. Store in a cool, dry place.

TROUBLESHOOTING

Common Issues and Solutions

- **Device Not Responding:**
 - Check if the power switches on both the keyboard and mouse are turned ON.
 - Ensure batteries are correctly installed and have sufficient charge. Replace if necessary.
 - Verify the USB receiver is securely plugged into a working USB port on your computer. Try a different USB port.
 - Perform the pairing/repairing steps outlined in the "Setup Guide" section.
- **Interference or Lag:**
 - Wireless performance can be affected by interference from other wireless devices (e.g., Wi-Fi routers, other 2.4Ghz devices), metal objects, or USB 3.0/3.1 ports.
 - Try moving the USB receiver closer to the keyboard and mouse.
 - Ensure there are no large metal objects between the devices and the receiver.
 - If using a USB 3.0/3.1 port, try connecting the receiver to a USB 2.0 port instead, or use a USB extension cable to move the receiver away from the port.
- **Keys Not Registering Correctly (Mac Users):**
 - After connecting, go to System Preferences > Keyboard.
 - Click "Change Keyboard Type...".
 - Follow the on-screen prompts, which may ask you to press a key next to the Shift key. Press the indicated key (e.g., Page Down key) 2-3 times.
 - A pop-up will appear stating the keyboard is not recognized and ask you to select a type. Choose the standard English American keyboard option.

If you encounter issues not covered here, please refer to the "Warranty and Support" section for further assistance.

PRODUCT SPECIFICATIONS

Feature	Specification
Product Dimensions	5.8 x 14.5 x 0.3 inches
Item Weight	1.26 pounds
Item Model Number	2AJIS-DF22 Pink Keyboard
Batteries Required	2 AA batteries (keyboard), 2 AAA batteries (mouse)
Connectivity Technology	2.4G Wireless (USB Receiver)
Color	Pink
Manufacturer	FENIFOX
First Available Date	October 17, 2018

Special Features	Compact full-size 102-key, Ergonomic, Light and thin, Quiet, Low-profile, Plug and Play
Compatible Devices	Windows, Mac

FULL-SIZE AND SLIM SIZE



Image: Diagram showing the precise dimensions of the FENIFOX keyboard and mouse.

WARRANTY AND SUPPORT

FENIFOX is committed to providing quality products and customer satisfaction. If you encounter any issues with your FENIFOX Wireless Keyboard and Mouse, please do not hesitate to contact us.

For after-sales support, even if the Amazon return period has passed, you can reach out to us directly. In your Amazon order history, simply select "Contact Seller" for this product. We are dedicated to resolving your concerns efficiently and professionally.

Please note that no official product videos were found with relevant creator information for inclusion in this manual.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question