

XTREME XTM-1250

XTREME XTM-1250 Over-Ear Headphone User Manual

1. INTRODUCTION

This manual provides essential instructions for the proper use, setup, and maintenance of your XTREME XTM-1250 Over-Ear Headphones. Please read this manual thoroughly before using the product to ensure optimal performance and longevity. Keep this manual for future reference.

2. PRODUCT OVERVIEW

The XTREME XTM-1250 are wired over-ear headphones designed for comfortable audio listening. They feature a durable construction and a 3.5mm jack for universal compatibility with various audio devices.



Figure 1: XTREME XTM-1250 Over-Ear Headphones, folded for storage. This image displays the XTREME XTM-1250 Over-Ear Headphones in a folded configuration. The earcups are silver and black, featuring control buttons on one earcup and the 'XTREME' logo on the other. The black headband and ear hooks are visible, indicating a compact design.

Package Contents:

- XTREME XTM-1250 Over-Ear Headphones
- Ear Cushions (pre-installed)
- Headband (integrated)

3. SETUP

Setting up your XTREME XTM-1250 headphones is a simple process:

1. **Unfold Headphones:** Gently unfold the headphones from their compact storage position until the earcups are correctly oriented for wearing.
2. **Connect Audio Cable:** Insert the 3.5mm audio jack into the corresponding audio output port on your device (e.g., smartphone, tablet, computer, MP3 player).
3. **Adjust Fit:** Place the headphones over your ears and adjust the headband for a comfortable and secure fit.

4. OPERATING INSTRUCTIONS

Once connected, your XTM-1250 headphones are ready for use. The headphones feature integrated controls on one earcup for convenient management of audio and calls.

Audio Playback:

- **Volume Control:** Use the volume up (+) and volume down (-) buttons on the earcup to adjust the audio level.
- **Play/Pause:** Press the central button (often marked with a play/pause symbol) to play or pause audio playback.
- **Track Navigation:** Depending on your device and the button configuration, you may be able to press the central button twice for next track or three times for previous track.

Call Management:

- **Answer/End Call:** Press the call button (often marked with a phone icon) once to answer an incoming call or end an active call.
- **Reject Call:** Press and hold the call button for approximately two seconds to reject an incoming call.
- **Voice Assistant:** A quick double-press of the call button may activate your device's voice assistant (e.g., Siri, Google Assistant).

5. MAINTENANCE

Proper care will extend the life of your headphones:

- **Cleaning:** Use a soft, dry cloth to wipe the earcups and headband. Do not use harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the headphones in a clean, dry place, preferably in their folded position to protect them from dust and damage.
- **Avoid Moisture:** Do not expose the headphones to water or excessive moisture.
- **Cable Care:** Avoid sharply bending or twisting the audio cable to prevent internal damage.

6. TROUBLESHOOTING

If you encounter issues with your XTM-1250 headphones, refer to the following common solutions:

- **No Sound:**

- Ensure the 3.5mm audio jack is fully inserted into both the headphones and the audio source device.
- Check the volume level on your audio source device and on the headphone controls.
- Test the headphones with a different audio source device to rule out device-specific issues.

- **Poor Sound Quality:**

- Ensure the audio jack is clean and free of debris.
- Try a different audio source or audio file to determine if the issue is with the content.

- **Controls Not Responding:**

- Ensure the headphones are properly connected to your device.
- Some older devices or specific applications may not fully support inline headphone controls.

7. SPECIFICATIONS

Feature	Detail
Model Name	XTM-1250
Brand	XTREME DIGITAL LIFESTYLE ACCESSORIES
Connectivity Technology	Wired
Headphone Jack	3.5 mm Jack
Ear Placement	Over Ear
Form Factor	Over Ear
Noise Cancelling	No
Microphone Included	Yes (for call functions)
Color	Black
Material	Plastic
Package Dimensions	16.2 x 14 x 4.4 cm
Weight	164 g

8. WARRANTY AND SUPPORT

For information regarding warranty coverage, technical support, or service inquiries, please refer to the warranty card included with your purchase or contact XTREME customer service through their official website. Please retain your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question