

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Master Lock](#) /
- › [Master Lock 5406EURD Portable Key Safe Instruction Manual](#)

Master Lock 5406EURD



Master Lock 5406EURD Portable Key Safe Instruction Manual

Model: 5406EURD

PRODUCT OVERVIEW

The Master Lock 5406EURD is a small, portable key safe designed to securely store keys. It features a durable metal body, a vinyl-coated shackle for attachment, and a customizable 3-digit combination lock. This key safe provides a convenient and secure solution for sharing access to keys without the need for duplicates or hiding them in insecure locations.



Image: Master Lock 5406EURD Portable Key Safe securely attached to a brick wall, demonstrating its outdoor use.

Key features include:

- **Durable Construction:** Metal body for enhanced security.
- **Protective Shackle:** Vinyl coating prevents scratching surfaces when attached.
- **Customizable Combination:** Set your own 3-digit code for keyless convenience.
- **Weather Protection:** Flexible cover shields combination dials from weather, dirt, and grime.
- **Portable Design:** Shackle allows for easy attachment to gates, fences, or other anchor points.

Master Lock®

Image: Visual representation of the Master Lock 5406EURD's secure design, highlighting its 3-digit combination, aluminum body, vinyl-coated shackle, invisible hinge, and the limited lifetime warranty.

SETUP: SETTING YOUR COMBINATION

The Master Lock 5406EURD comes with a factory preset combination of 0-0-0. Follow these steps to set your personalized 3-digit combination:

1. **Open the Lock Box:** Use the default code (0-0-0) to open the key safe.
2. **Locate Reset Lever:** Inside the key safe, find the reset lever.
3. **Push Reset Lever:** Push the reset lever to the position indicated in the diagram.
4. **Set New Combination:** Rotate the dials to your desired 3-digit combination. Choose a memorable but secure code.
5. **Return Reset Lever:** Push the reset lever back to its original position.
6. **Close and Scramble:** Close the lock box and scramble the dials to secure your new combination.

Important: Make sure to record your new combination in a safe place. Do not store the combination inside the key safe.




Image: Step-by-step visual guide for setting a new 3-digit combination on the Master Lock 5406EURD Portable Key Safe, illustrating the open lock box, reset lever, dial rotation, and final reset.

OPERATING INSTRUCTIONS

Opening the Key Safe

1. Slide the flexible cover down to reveal the combination dials.
2. Rotate the dials to your preset 3-digit combination.
3. Pull the front cover of the key safe open.

Closing the Key Safe

1. Place your keys inside the compartment.
2. Close the front cover of the key safe firmly.
3. Scramble the combination dials to lock the safe and conceal your code.
4. Slide the flexible cover back up to protect the dials.

Attaching the Key Safe

The vinyl-coated shackle allows for easy attachment to various fixtures:

- Open the key safe and locate the shackle release mechanism (if applicable, or simply open the shackle).
- Hook the shackle around a secure anchor point such as a gate, fence, or railing.
- Close the shackle securely.

The internal dimensions are suitable for standard house keys. Car keys or access cards may not fit due to their size or shape.

SECURED DESIGN

3-DIGIT COMBINATION



ALUMINIUM BODY AND VINYL COATED SHACKLE



INVISIBLE HINGE

Image: Detailed diagram illustrating the external and internal dimensions of the Master Lock 5406EURD Key Safe, along with visual indicators for compatible items (standard house keys) and incompatible items (car keys, access cards).

MAINTENANCE

To ensure the longevity and proper functioning of your Master Lock 5406EURD Key Safe, follow these simple maintenance guidelines:

- **Cleaning:** Periodically wipe down the exterior of the key safe with a damp cloth to remove dirt and grime. For stubborn dirt, a mild soap solution can be used. Ensure the unit is dry before closing.
- **Combination Dials:** The flexible cover is designed to protect the dials from weather and debris. Keep this cover in place when the safe is not in use. If the dials become stiff, a small amount of graphite lubricant (not oil-based lubricants) can be applied.
- **Shackle:** Inspect the vinyl-coated shackle for any signs of wear or damage. The vinyl coating helps prevent scratches to surfaces.
- **Environmental Exposure:** While designed for outdoor use, extreme weather conditions (e.g., prolonged heavy rain, freezing temperatures) can affect performance. Ensure the cover is properly sealed.

TROUBLESHOOTING

- **Key Safe Will Not Open:**

- Ensure the combination dials are precisely aligned with your set code.
- Verify you are using the correct combination. If forgotten, there is no master key or override code.
- Check for any debris obstructing the opening mechanism.

- **Dials Are Stiff:**

- Clean the dials and the area around them.
- Apply a small amount of graphite lubricant to the dials. Avoid oil-based lubricants as they can attract dirt.

- **Shackle Is Difficult to Open/Close:**

- Ensure the key safe is fully open and the shackle release mechanism (if present) is engaged correctly.
- Check for any physical obstructions or damage to the shackle.

If you encounter persistent issues not covered here, please refer to the support section for further assistance.

SPECIFICATIONS

Feature	Detail
Model Number	5406EURD
Brand	Master Lock
Lock Type	3-Digit Combination Lock
Material	Metal body, Vinyl-coated shackle
Exterior Dimensions (L x W x H)	8.46 x 4.61 x 1.97 inches (21.5 x 11.7 x 5 cm)
Interior Dimensions (approx.)	6.2 cm (2.4") width, 2.8 cm (1.1") depth, 3 cm (1.2") height for key storage (refer to diagram for exact measurements)
Weight	0.29 Kilograms
Color	Gray
Special Features	Durable, Flexible, Lightweight, Portable, Weather-resistant cover

WARRANTY INFORMATION

The Master Lock 5406EURD Portable Key Safe is backed by a **Limited Lifetime Warranty** from Master Lock. This warranty provides peace of mind, ensuring the product is free from defects in material and workmanship for the life of the product under normal use.

For specific details regarding warranty claims, coverage, and limitations, please refer to the official Master Lock website or contact customer support.

SUPPORT

For additional assistance, product information, or to view frequently asked questions, please visit the official Master Lock website:

www.masterlock.com

You can also find helpful tutorials and guides by searching for "Master Lock 5406EURD" on video platforms like YouTube.

For direct customer service inquiries, please refer to the contact information provided on the Master Lock website.