

Kanto SP6HD

Kanto SP6HD Desktop Speaker Stands Instruction Manual

Model: SP6HD

INTRODUCTION

The Kanto SP6HD Desktop Speaker Stands are designed to optimize your audio experience by providing a stable and elevated platform for your bookshelf speakers or studio monitors. These stands help reduce unwanted vibrations and position your speakers for improved sound clarity and imaging. This manual provides essential information for setup, operation, and maintenance.

PACKAGE CONTENTS

Before beginning assembly, please ensure all components are present:

- 2 x SP6HD Speaker Stands
- 2 x 4-inch Wide Top Plates
- 2 x 7-inch Wide Top Plates
- Mounting Hardware (screws, washers, Allen key)

If any parts are missing or damaged, please contact Kanto customer support.

SETUP INSTRUCTIONS

1. **Unpack Components:** Carefully remove all parts from the packaging.
2. **Choose Top Plate:** Select either the 4-inch or 7-inch wide top plate based on the size of your speakers. The chosen top plate should accommodate the base of your speaker securely.
3. **Attach Top Plate:** Align the selected top plate with the stand's support column. Use the provided screws and Allen key to securely fasten the top plate to the stand. Ensure the plate is firmly attached.
4. **Position Speakers:** Place your speakers on the assembled stands. The stands feature a 1/4"-20 screw hole

on the top plate to secure compatible speakers. If your speakers have a corresponding mounting hole, use the provided screw to attach them.

5. **Cable Management:** Route speaker cables or power cords through the hollow support column of the stand for a tidy setup. The cable exit point is located at the rear base of the stand.



Image: Detail of the SP6HD stand showing the mounting hole for speaker security and the rotating top plate feature.



TWO TOP PLATE SIZES
TO ACCOMMODATE 4" TO 7" SPEAKERS



HOLLOW SUPPORT COLUMN
TO ROUTE CABLES AND SPEAKER WIRE




Image: Illustration of the two included top plate sizes and the hollow support column designed for cable routing.



Image: A speaker positioned on a Kanto SP6HD stand, demonstrating the elevated placement.




Image: Underside view highlighting the heavy steel construction and foam padding for vibration absorption.

Setup Video Guide

Your browser does not support the video tag.

Video: Kanto SP6HD & SP9 Feature Overview. This video provides a quick overview of the features and setup process for Kanto SP6HD speaker stands.

OPERATING INSTRUCTIONS

Once assembled, the Kanto SP6HD stands allow for optimal speaker positioning:

- **Ear-Level Alignment:** Position the stands so that the tweeters of your speakers are approximately at ear-level when you are seated at your listening position. This helps to ensure a direct sound path and improved

high-frequency response.

- **Adjusting Angle:** The top plates can be rotated up to 15 degrees left or right. Adjust the angle of each speaker to direct the sound towards your primary listening position for a more focused soundstage.
- **Vibration Reduction:** The heavy steel construction and closed-cell foam padding on the top and bottom plates are designed to absorb vibrations. Ensure the stands are placed on a stable, flat surface to maximize this benefit.

MAINTENANCE

To ensure the longevity and performance of your Kanto SP6HD speaker stands, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the stands with a soft, dry cloth to remove dust. For stubborn marks, a slightly damp cloth can be used, followed by immediate drying. Avoid abrasive cleaners or solvents.
- **Screw Check:** Periodically check all screws to ensure they remain tight. Loose screws can affect stability and sound performance.
- **Foam Padding:** Inspect the foam padding for any signs of wear or damage. While durable, extreme conditions or sharp objects can compromise its integrity.

TROUBLESHOOTING

If you encounter any issues with your speaker stands, consider the following common solutions:

- **Muddy Sound:** If your audio sounds unclear or lacks definition, ensure the stands are placed on a solid, level surface. Verify that the foam padding is intact and making full contact with both the speaker and the desktop to effectively absorb vibrations.
- **Unstable Speakers:** Confirm that the top plate is securely fastened to the stand. If your speakers have a 1/4"-20 mounting hole, use the provided screw to attach them to the stand for added stability. Ensure the stand's base is fully on the surface.
- **Poor Soundstage/Imaging:** Adjust the rotation of the top plates to angle the speakers directly towards your listening position. Experiment with small adjustments to find the optimal sweet spot.

SPECIFICATIONS

Feature	Detail
Brand	Kanto
Model Number	SP6HD
Material	Metal (Heavy Steel)
Color	Black
Product Dimensions (L x W x H)	6"L x 7"W x 6"H (15.2cm L x 17.8cm W x 15.2cm H)
Item Weight	13.7 Pounds (6.2 kg)
Maximum Height	6 Inches (15.2 cm)
Base Width	7 Inches (17.8 cm)
Load Capacity	Up to 30 Pounds (13.6 kg) per stand

Top Plate Sizes Included	4" Wide and 7" Wide
Rotation	Up to 15° left or right




Image: Technical drawing illustrating the dimensions of the Kanto SP6HD speaker stands and top plates.

WARRANTY INFORMATION

The Kanto SP6HD Desktop Speaker Stands are covered by a **Two Year Manufacturer's Warranty**. This warranty covers defects in materials and workmanship under normal use. For full details regarding warranty terms, conditions, and how to make a claim, please refer to the official Kanto website or contact Kanto customer support directly.

CUSTOMER SUPPORT

For technical assistance, troubleshooting, or warranty inquiries, please contact Kanto customer support:

- **Website:** Visit the official Kanto website for FAQs, support resources, and contact information.
- **Email/Phone:** Refer to the Kanto website for the most current email and phone contact details for your region.

You can also visit the [Kanto Store on Amazon](#) for additional product information and support resources.