

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- > [Cornat](#) /
- > [Cornat TECBW3411 Vario Riser Pipe User Manual](#)

Cornat TECBW3411

Cornat TECBW3411 Vario Riser Pipe User Manual

Model: TECBW3411 | Brand: Cornat

1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Cornat TECBW3411 Vario Riser Pipe. This height-adjustable riser pipe is designed to complement your shower system, offering flexibility and a modern aesthetic. Please read this manual thoroughly before installation and use to ensure proper function and safety.





Figure 1: The Cornat TECBW3411 Vario Riser Pipe. This image displays the complete riser pipe assembly, including the overhead shower arm, the adjustable hand shower holder, and the wall mounting points, all in a chrome-plated finish.

2. SAFETY INFORMATION

- Always turn off the main water supply before beginning any installation or maintenance work.
- Ensure all connections are properly sealed to prevent leaks.
- Use appropriate tools and wear protective gear during installation.
- If you are unsure about any part of the installation, consult a qualified plumber.
- Do not use abrasive cleaners or harsh chemicals on the chrome-plated surface, as this may damage the finish.

3. PACKAGE CONTENTS

Please check that all components are present and undamaged before proceeding with installation:

- Cornat TECBW3411 Vario Riser Pipe Assembly (main vertical pipe with integrated overhead shower

arm)

- Adjustable Wall Brackets (2 units)
- Hand Shower Holder with Push Button Slider
- Diverter/Switch Mechanism
- Mounting Hardware (screws, wall plugs)
- Sealing Washers/Gaskets

4. SETUP AND INSTALLATION

The Cornat TECBW3411 Vario Riser Pipe is designed for wall-mounted installation. Its variable wall fixings allow for the reuse of existing drill holes, simplifying the upgrade process.

4.1 Tools Required (Not Included)

- Drill
- Drill bits (appropriate for wall material)
- Screwdriver
- Adjustable wrench
- Measuring tape
- Pencil
- Spirit level
- Sealant tape (PTFE tape)

4.2 Installation Steps

1. **Prepare the Installation Area:** Turn off the main water supply. Remove any existing shower components if replacing.
2. **Position the Riser Pipe:** Hold the riser pipe assembly against the wall at the desired height. Use a spirit level to ensure it is perfectly vertical. Mark the positions for the wall brackets.
3. **Mount Wall Brackets:** Drill holes at the marked positions. Insert wall plugs. Secure the wall brackets to the wall using the provided screws. The variable design allows adjustment to align with existing drill holes within a certain range.
4. **Attach Riser Pipe:** Secure the riser pipe assembly to the mounted wall brackets. Ensure it is firmly held.
5. **Connect Water Supply:** The riser pipe features a 1/2 inch threaded connection at the bottom. Apply sealant tape to the threads of your water supply line (or shower hose connection) and connect it to the riser pipe. Tighten with an adjustable wrench, but do not overtighten.
6. **Install Overhead Shower Head (if applicable):** If you are attaching an overhead shower head, connect it to the top arm of the riser pipe. Ensure a proper seal with a washer.
7. **Install Hand Shower (if applicable):** Attach your hand shower hose to the diverter/switch mechanism. Place the hand shower into the adjustable holder.
8. **Test for Leaks:** Slowly turn on the main water supply and check all connections for leaks. Tighten any leaking connections carefully.



Produkt-Abmessungen




Figure 2: Product Dimensions. This diagram illustrates the key dimensions of the riser pipe, including its adjustable height range of 80-130 cm and a depth of 335 mm for the overhead shower arm.

5. OPERATION

5.1 Height Adjustment

The Cornat TECBW3411 Vario Riser Pipe features an adjustable length, allowing you to set the overall height of your shower system between 80 cm and 130 cm. This adjustment is typically made by loosening a locking mechanism on the main vertical pipe, sliding the upper section to the desired height, and then re-tightening the mechanism. Refer to Figure 2 for the adjustable range.

5.2 Hand Shower Holder

The hand shower holder is equipped with a push-button slider. Press the button to release the holder, slide it up or down the riser pipe to your preferred height, and then release the button to lock it in place. The holder can also be angled for optimal spray direction.

5.3 Diverter/Switch

A practical switch (diverter) is integrated into the system, allowing you to easily switch the water flow between the overhead shower and the hand shower. Rotate or push the switch to select your desired water outlet.

6. MAINTENANCE

To ensure the longevity and appearance of your Cornat TECBW3411 Vario Riser Pipe, follow these maintenance guidelines:

- **Cleaning:** Clean the chrome-plated surfaces regularly with a soft cloth and mild soap or a non-abrasive bathroom cleaner. Rinse thoroughly with water and dry with a soft cloth to prevent water spots.
- **Avoid Harsh Chemicals:** Do not use abrasive sponges, scouring pads, or cleaners containing ammonia, bleach, or acids, as these can damage the chrome finish.
- **Check Connections:** Periodically check all connections for any signs of leaks or corrosion. Tighten if necessary.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Water leaks from connections.	Loose connection, worn washer, insufficient sealant tape.	Turn off water supply. Tighten connections. Replace washers if damaged. Reapply sealant tape.
Difficulty adjusting height of riser pipe.	Locking mechanism not fully loosened, mineral buildup.	Ensure locking mechanism is completely disengaged. Clean any visible mineral deposits.
Diverter/Switch not changing water flow.	Internal mechanism obstruction or wear.	Ensure the switch is fully engaged in one position. If problem persists, contact customer support.

8. SPECIFICATIONS

Brand	Cornat
-------	--------

Model Number	TECBW3411
Style	Modern, Adjustable
Shape	Square
Material	Stainless Steel
Finish Type	Polished, Chrome-plated
Installation Type	Wall Mounted
Adjustable Length	80 - 130 cm
Depth (from wall)	335 mm
Connection Thread	1/2 inch
Special Feature	Push Button Slider (for hand shower holder)
Item Weight	3.65 pounds

9. WARRANTY AND SUPPORT

For warranty information or technical support regarding your Cornat TECBW3411 Vario Riser Pipe, please refer to the documentation provided with your purchase or contact Cornat customer service directly. Contact details can typically be found on the manufacturer's official website or on the product packaging.



Figure 3: Cornat Brand Logo. This image displays the official logo for the Cornat brand.