

WilTec 61807

WilTec Adjustable Height Aluminum Bistro Bar Table (Model 61807)

User Manual

1. INTRODUCTION

Thank you for choosing the WilTec Adjustable Height Aluminum Bistro Bar Table. This versatile table is designed for various settings, including indoor and outdoor use. Its robust aluminum construction, complemented by a stainless steel edge, provides durability and weather resistance. The table features an adjustable height mechanism, allowing it to be set at either 70 cm or 110 cm to suit different functional requirements, such as a standing bar table, dining table, or low lounge table. The four-legged cross base ensures stability and includes height compensation for uneven surfaces.

2. IMPORTANT SAFETY INFORMATION

WARNING: Use with caution. This table may tip over if not used correctly. Please read all instructions carefully before use.

- Ensure all components are securely fastened before use.
- Do not overload the table. Refer to specifications for weight limits.
- Always adjust the height with care, ensuring no objects or body parts are in the way of moving parts.
- Place the table on a stable, level surface to prevent tipping.
- Keep children and pets away from the table during assembly and height adjustment.
- Regularly inspect the table for any signs of damage or loose parts. Do not use if damaged.

3. PACKAGE CONTENTS

Please verify that all parts are present before beginning assembly. If any parts are missing or damaged, contact WilTec customer service.

- Tabletop (Ø 60 cm)
- Adjustable height central column

- Cross base with four feet
- Assembly hardware (screws, washers, tools if included)

4. ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your WilTec Bistro Bar Table:

1. **Attach the Central Column to the Base:** Align the central column with the mounting points on the cross base. Secure it using the provided screws and washers. Tighten firmly but do not overtighten.
2. **Attach the Tabletop to the Central Column:** Place the tabletop upside down on a soft, clean surface to prevent scratches. Align the central column's top plate with the pre-drilled holes on the underside of the tabletop. Secure it using the provided screws.
3. **Adjust Feet for Stability:** Turn the table upright. If the table wobbles, adjust the leveling feet on the cross base by rotating them until the table is stable on your surface.



Figure 4.1: Assembly diagram illustrating the table components and adjustable heights (70 cm and 110 cm) with a 60 cm diameter tabletop.

5. OPERATING INSTRUCTIONS

5.1. Height Adjustment

The WilTec Bistro Bar Table offers two height settings: 70 cm (low) and 110 cm (high). To adjust the table height:

1. **Clear the Table:** Remove all items from the tabletop before attempting to adjust the height.
2. **Locate the Adjustment Mechanism:** The height adjustment mechanism is typically a locking collar or pin located on the central column. (*Refer to your specific model for exact mechanism details.*)
3. **Adjust Height:** Carefully lift or lower the tabletop while disengaging the locking mechanism. Once the desired height (70 cm or 110 cm) is reached, ensure the mechanism locks securely into place. Verify that the table is stable before placing items back on it.



Figure 5.1: The WilTec table shown in both its high (110 cm) and low (70 cm) configurations.



Figure 5.2: The table in an outdoor setting, paired with bar stools, highlighting its practical application.

6. CARE AND MAINTENANCE

To ensure the longevity and appearance of your WilTec Bistro Bar Table, follow these maintenance guidelines:

- **Cleaning:** Wipe the table surfaces with a damp cloth. For stubborn dirt, use a mild soap solution and then wipe dry immediately. Avoid abrasive cleaners or harsh chemicals that could damage the aluminum finish.
- **Weather Protection:** While the table is weather-resistant, prolonged exposure to extreme weather conditions (heavy rain, snow, intense sun) may affect its appearance over time. Consider covering the table or storing it indoors during harsh weather.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Foot Pads:** Inspect the plastic foot pads on the base for wear and tear. Replace if significantly damaged to maintain stability and protect floor surfaces.



Figure 6.1: Detail of the tabletop's textured aluminum surface, which is easy to clean.



Figure 6.2: A close-up of one of the adjustable feet, designed for stability on uneven surfaces.

7. TROUBLESHOOTING

If you encounter issues with your WilTec Bistro Bar Table, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Table wobbles	Uneven surface; loose connections; uneven foot pads.	Adjust leveling feet on the base. Check and tighten all assembly screws. Ensure table is on a flat surface.
Difficulty adjusting height	Mechanism jammed; dirt in the column; incorrect procedure.	Ensure table is clear of objects. Clean the central column and adjustment mechanism. Refer to Section 5.1 for correct procedure. Do not force the mechanism.
Scratches on surface	Abrasive cleaning; sharp objects.	Use soft cloths for cleaning. Avoid placing sharp or rough objects directly on the tabletop without protection.

8. PRODUCT SPECIFICATIONS

Model Number	61807
Brand	WilTec
Product Dimensions (L x W x H)	60 x 60 x 74 cm (low height); 60 x 60 x 114 cm (high height)
Tabletop Diameter	60 cm
Weight	6.2 Kilograms
Frame Material	Aluminum
Tabletop Material	Aluminum
Color	Silver
Recommended Use	Outdoor celebrations, standing events, dining
Care Instructions	Wipe with a damp cloth
Country of Origin	China

9. WARRANTY AND CUSTOMER SUPPORT

For information regarding warranty coverage, spare parts availability, or technical support, please refer to the official WilTec website or contact WilTec customer service directly. Contact details can typically be found on the product packaging or the manufacturer's official website.



