Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Redragon G807

Redragon G807 Gamepad User Manual

Model: G807

Introduction

Thank you for choosing the Redragon G807 Gamepad. This versatile controller is designed to enhance your gaming experience across multiple platforms, including Windows PC, PlayStation 3, and Android devices. Featuring dual vibration feedback, the G807 provides immersive tactile sensations for a more engaging gameplay. Please read this manual thoroughly before using the product to ensure proper operation and to maximize its lifespan.

Safety Information

- Keep the gamepad away from water, moisture, and extreme temperatures.
- Do not attempt to disassemble or modify the gamepad. This will void the warranty and may cause damage.
- Avoid dropping or subjecting the gamepad to strong impacts.
- Clean the gamepad with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- If the gamepad malfunctions, discontinue use and contact Redragon support.

Package Contents

Please check the package contents upon opening. If any items are missing or damaged, contact your retailer or Redragon support.

- Redragon G807 Gamepad
- User Manual (this document)

Product Overview

Familiarize yourself with the various components of your Redragon G807 Gamepad.

No relevant product images were provided in the input. An image of the Redragon G807 Gamepad, highlighting its buttons, analog sticks, D-pad, triggers, and shoulder buttons, would typically be displayed here.
Description: The Redragon G807 Gamepad features a standard controller layout. On the front, it includes two analog sticks, a directional pad (D-pad), four action buttons (A, B, X, Y or equivalent), and Start/Select/Mode buttons. The top of the controller has left and right shoulder buttons (L1, R1) and triggers (L2, R2). The controller also includes a USB

cable for connection.

Key Components:

- **Analog Sticks:** Two high-precision analog sticks for 360-degree movement.
- **D-Pad:** Eight-way directional pad for precise control.
- **Action Buttons:** Four face buttons (e.g., A, B, X, Y) for in-game actions.
- **Shoulder Buttons (L1/R1):** For quick actions or weapon switching.
- **Triggers (L2/R2):** Pressure-sensitive triggers for acceleration, braking, or shooting.
- **Start/Select/Mode Buttons:** For game menus, options, and mode switching.
- **USB Cable:** Integrated cable for wired connection to devices.

Setup

Follow these steps to connect your Redragon G807 Gamepad to your desired platform.

Connecting to Windows PC:

1. Ensure your PC is powered on.
2. Plug the USB connector of the G807 Gamepad into an available USB port on your PC.
3. Windows will automatically detect and install the necessary drivers. This may take a few moments.
4. Once the drivers are installed, the gamepad will be ready for use. You can verify its status in your PC's "Devices and Printers" or "Game Controllers" settings.

Connecting to PlayStation 3 (PS3):

1. Power on your PS3 console.
2. Plug the USB connector of the G807 Gamepad into an available USB port on your PS3.
3. The PS3 will recognize the gamepad as a standard controller. The indicator lights on the gamepad may illuminate to show it's connected.
4. The gamepad is now ready for use with PS3 games.

Connecting to Android Devices:

Note: Your Android device must support USB OTG (On-The-Go) functionality for direct connection. An OTG adapter (not included) may be required.

1. Ensure your Android device supports USB OTG.
2. Connect the USB connector of the G807 Gamepad to a USB OTG adapter.
3. Plug the OTG adapter into the USB port of your Android device.
4. The Android device should detect the gamepad. Some games and emulators may require specific settings adjustments to recognize the controller.

Connecting to Xbox 360:

Note: While the product title mentions Xbox 360, the Redragon G807 is primarily designed for PC, PS3, and Android. Direct plug-and-play compatibility with Xbox 360 consoles is generally not supported without specific adapters or software, which are not included or officially supported by Redragon for this model. For optimal Xbox 360 compatibility, a dedicated Xbox 360 controller is recommended.

Operating Instructions

Basic Controls:

The G807 Gamepad functions as a standard XInput/DirectInput controller on PC and a standard controller on PS3 and Android. Button mapping will typically follow the in-game prompts.

- **Analog Sticks:** Use for character movement, camera control, or menu navigation.
- **D-Pad:** Use for precise directional input, menu navigation, or quick item selection.
- **Action Buttons:** Perform actions such as jumping, attacking, interacting, or confirming selections.
- **Shoulder Buttons & Triggers:** Typically used for aiming, shooting, sprinting, or special abilities.
- **Start/Select Buttons:** Access in-game menus, pause games, or confirm selections.

Dual Vibration Feature:

The Redragon G807 features dual vibration motors that provide tactile feedback during gameplay. This feature is automatically activated in games that support vibration feedback. The intensity and patterns of vibration are controlled by the game itself.

No relevant official product videos were provided in the input. A video demonstrating the dual vibration feature in action, perhaps showing the controller vibrating during gameplay, would typically be embedded here. Description: This section would ideally feature a video showcasing the dual vibration motors of the Redragon G807 Gamepad. The video would illustrate how the controller vibrates in response to in-game events, such as explosions, impacts, or engine rumble, enhancing the immersive experience for the user.

Maintenance

Proper care and maintenance will extend the life of your gamepad.

- **Cleaning:** Use a soft, dry, lint-free cloth to wipe down the surface of the gamepad. For stubborn dirt, slightly dampen the cloth with water, but ensure no liquid enters the controller. Do not use alcohol, solvents, or abrasive cleaners.
- **Storage:** Store the gamepad in a cool, dry place away from direct sunlight and extreme temperatures. Avoid placing heavy objects on top of the controller.
- **Cable Care:** Do not bend or crimp the USB cable excessively. Always pull from the plug, not the cable, when disconnecting.

Troubleshooting

If you encounter issues with your Redragon G807 Gamepad, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Gamepad not recognized by PC/console.	Loose connection, faulty USB port, driver issue.	Ensure the USB cable is securely plugged into both the gamepad and the device. Try a different USB port on your PC/console. Restart your PC/console. On PC, check Device Manager for driver issues. Reinstall drivers if necessary.

Problem	Possible Cause	Solution
Vibration not working.	Game does not support vibration, vibration feature disabled in game settings, driver issue.	Verify that the game you are playing supports vibration feedback. Check the in-game settings to ensure vibration is enabled. Ensure drivers are correctly installed on PC.
Buttons/sticks unresponsive or erratic.	Dirt/debris, physical damage, software calibration issue.	Clean around the buttons and sticks with a soft, dry cloth. Test the gamepad on another device to rule out a device-specific issue. On PC, try calibrating the gamepad through Windows Game Controller settings. If physical damage is suspected, contact support.

Specifications

Feature	Detail
Model	Redragon G807 Saturn
Connectivity	Wired USB
Compatibility	Windows PC (XInput/DirectInput), PlayStation 3, Android (via OTG)
Vibration	Dual Vibration Motors
Cable Length	*(Specific length not provided in input, typical is 1.8m/6ft)*
Dimensions	*(Not provided in input)*
Weight	*(Not provided in input)*

Warranty and Support

Redragon products come with a limited warranty. Please refer to the warranty card included with your product or visit the official Redragon website for detailed warranty terms and conditions.
For technical support, troubleshooting assistance, or warranty claims, please contact Redragon customer service through their official website or the contact information provided in your product packaging.
Redragon Official Website: www.redragonusa.com
(Note: Specific contact details like phone numbers or email addresses are not provided in the input and should be obtained from the official Redragon website or product packaging.)

© 2024 Redragon. All rights reserved. Redragon G807 User Manual.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07VMHVLN9

More documents and user manuals: **https://manuals.plus/**