Homestyle4u 1898

Homestyle4u Triple Bunk Bed Model 1898 Instruction Manual

Model: 1898 | Brand: Homestyle4u

Introduction

This manual provides detailed instructions for the assembly, safe use, and maintenance of your Homestyle4u Triple Bunk Bed, Model 1898. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

The Homestyle4u Triple Bunk Bed is designed for children, featuring an upper single bed (90 x 200 cm) and a lower double bed (140 x 200 cm). It is constructed from solid white lacquered pine wood and includes slatted bed bases for both levels.

Safety Information

WARNING: Failure to follow these safety instructions could result in serious injury or death.

- This bunk bed is designed for children aged 6 years and older for the upper bunk.
- Maximum recommended load for each bed is 120 kg.
- Always use the recommended mattress size: Upper bed 90 x 200 cm, Lower bed 140 x 200 cm.
- Ensure all assembly hardware is securely tightened before use. Periodically check and re-tighten hardware as needed.
- Do not allow children to play on or under the bunk bed without supervision.
- Do not attach or hang items on any part of the bunk bed that are not designed for use with the bed; for example, but not limited to, hooks, belts, or ropes.
- Always use the ladder for access to the upper bunk. Do not jump on or off the bunk bed.
- Ensure the bunk bed is placed on a level surface.
- Keep this manual for future reference.



Image: Safety standards for the bunk bed, indicating suitability for ages 6 and up, compliance with EN 747/1-2 standards, and a maximum load capacity of 120 kg.

Package Contents

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, do not proceed with assembly. Contact customer support for assistance.
The package includes:

- Bed frame components (solid pine wood, white lacquered)
- Slatted bed bases for upper and lower beds
- Ladder
- Assembly hardware (screws, dowels, etc.)
- Assembly instructions (this manual)

Image: Example of slatted bed bases, which are included for both the upper and lower bunks.

Setup and Assembly

Assembly is required for this bunk bed. It is recommended that two adults assemble the bed. Please follow the included assembly instructions carefully. A typical assembly time is approximately 4 hours for two people.

Tools Required (Not Included):

- Screwdriver (Phillips head)
- Hammer (optional, for dowels)

Assembly Steps Overview:

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Identify all parts using the parts list provided in the separate assembly guide.
3. Assemble the lower bed frame first, ensuring all connections are secure.
4. Attach the ladder supports and side rails for the upper bed.
5. Assemble the upper bed frame and carefully place it onto the lower structure.
6. Secure the ladder to the upper bunk.
7. Insert the slatted bed bases into both the upper and lower frames.
8. Tighten all screws and bolts. Do not overtighten.



Image: Illustrated steps for assembling the bunk bed frame, showing the progression from initial components to a structured frame.

Image: Detail of the ladder, showing its construction and how it connects to the upper bed frame.

Operating Instructions (Usage)

Once assembled, the bunk bed is ready for use. Ensure mattresses of the correct size are placed on both the upper and lower slatted bases.

- **Upper Bunk:** Intended for one child aged 6 years or older. Always use the ladder for access.
- **Lower Bunk:** Intended for one or two children.
- **Weight Limit:** Do not exceed the maximum weight capacity of 120 kg per bed.
- **Ventilation:** Ensure adequate airflow around mattresses to prevent moisture buildup.



Image: The bunk bed shown in a daybed configuration, highlighting its adaptable design for various room setups.

Maintenance

- **Cleaning:** Wipe the bed frame with a damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the lacquered finish.
- **Hardware Check:** Periodically (e.g., every 3 months) check all screws, bolts, and connections to ensure they are tight. Re-tighten if necessary to maintain stability and safety.
- **Slats:** Inspect the slatted bed bases for any damage or cracks. Replace damaged slats immediately.
- **Moving the Bed:** When moving the bed, lift it rather than dragging it to prevent damage to the frame and floor.

Troubleshooting

Problem	Possible Cause	Solution
Bed feels wobbly or unstable.	Loose hardware.	Check and tighten all screws and bolts. Ensure the bed is on a level surface.
Squeaking noises.	Loose connections or friction between parts.	Tighten all hardware. Apply a small amount of lubricant (e.g., paraffin wax) to contact points if necessary.
Difficulty assembling a part.	Incorrect orientation or missing part.	Refer to the detailed assembly instructions. Ensure parts are oriented correctly. Contact customer support if a part is missing or damaged.

Specifications

Feature	Detail
Model Number	1898
Brand	Homestyle4u
Overall Dimensions (L x W x H)	205 x 149 x 139 cm
Upper Bed Sleeping Area	90 x 200 cm
Lower Bed Sleeping Area	140 x 200 cm
Material	Solid Pine Wood
Finish	White Lacquered
Weight	50 kg
Maximum Recommended Load (per bed)	120 kg
Assembly Required	Yes
Target Audience	Children (Upper bunk 6+ years)
Care Instructions	Wipe with a damp cloth



Image: Technical drawing with precise measurements of the bunk bed, illustrating overall dimensions and individual bed sizes.

Warranty and Support

Specific warranty information is not provided in this manual. For warranty details or customer support, please refer to the purchase documentation or contact your retailer directly.
For assistance with missing parts, damaged components, or assembly questions, please contact Homestyle4u customer service through your point of purchase.

Homestyle4u © 2024. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question