USHA BLOOM DAFFODIL

USHA Bloom Daffodil 1250mm Ceiling Fan Instruction Manual

Model: BLOOM DAFFODIL | Blade Size: 1250mm

1. Product Overview

The USHA Bloom Daffodil 1250mm Ceiling Fan is designed for efficient air circulation and cooling in various indoor spaces. This model features a 'Goodbye Dust' coating for easier maintenance and a durable aluminium construction. It operates with a corded electric power source and offers 5 speed settings.



Figure 1: USHA Bloom Daffodil 1250mm Ceiling Fan (Sparkle Golden and Brown)

2. Safety Instructions

Read all instructions carefully before installation and use. Retain this manual for future reference.

- Ensure the power supply is disconnected before installation, cleaning, or maintenance.
- Installation must be performed by a qualified electrician in accordance with local electrical codes.
- The mounting structure must be capable of supporting the fan's weight (approximately 4.72 kg) and the dynamic load during operation.
- Maintain a minimum clearance of 2.3 meters (7.5 feet) from the floor to the fan blades.
- Do not insert objects into the fan blades while the fan is operating.
- Ensure all connections are secure and properly insulated.

3. Package Contents

Verify that all components are present and undamaged before proceeding with installation.

- 1x Fan Motor Assembly
- 3x Fan Blades
- 2x Canopy (Top and Bottom)
- 1x Fixing Clamp/Shackle Assembly
- 1x Down Rod
- 3x Set of Nut-Bolt-Lockpin Assembly (including shackle ones)
- 1x Cord (Included Components)




Figure 2: Exploded view of fan components for assembly.

4. Setup and Installation

This fan is designed for ceiling mount installation. Follow these steps carefully.

4.1 Mounting the Fan

1. **Prepare the Mounting Location:** Ensure the ceiling junction box or support structure is securely fastened and can support the fan's weight.
2. **Install the Down Rod:** Insert the down rod through the canopy and then through the fan motor assembly. Secure it with the provided pin and clip.
3. **Attach Blades:** Securely attach each of the three fan blades to the motor housing using the provided screws. Ensure they are tightened evenly to prevent wobbling.
4. **Hang the Fan:** Carefully lift the fan assembly and hang it onto the ceiling mounting bracket using the shackle assembly. Ensure it is seated correctly and securely.
5. **Electrical Connection:** Connect the fan's electrical wires to the household wiring. Ensure proper grounding and insulation. Refer to local electrical codes.
6. **Position Canopies:** Slide the upper canopy up to the ceiling to cover the wiring and mounting bracket. Secure the lower canopy against the motor housing.



Figure 3: Close-up of the fan motor and blade attachment points.

5. Operating Instructions

The USHA Bloom Daffodil fan is controlled via a standard wall-mounted button control (regulator).

- **Power On/Off:** Use the main switch to turn the fan on or off.
- **Speed Control:** Adjust the fan speed using the button control. This model offers 5 distinct speed settings, from low to high.
- Select a speed that provides comfortable airflow for your room.

6. Maintenance

Regular maintenance ensures optimal performance and longevity of your fan.

- **Cleaning:** The fan features a 'Goodbye Dust' coating, making it easier to clean. Wipe the blades and motor housing with a soft, damp cloth. Do not use abrasive cleaners or solvents.

- **Frequency:** Clean the fan blades and motor housing periodically, especially in dusty environments, to maintain efficiency and appearance.
- **Blade Tightness:** Periodically check that all blade screws are securely tightened. Loose blades can cause wobbling and noise.
- **Lubrication:** The fan motor is permanently lubricated and does not require additional oiling.

7. Troubleshooting

Refer to the table below for common issues and their solutions.

Problem	Possible Cause	Solution
Fan does not start	No power supply Loose wiring connection	Check circuit breaker/fuse Ensure all electrical connections are secure (consult an electrician)
Fan wobbles excessively	Loose blade screws Unbalanced blades Loose mounting hardware	Tighten all blade screws Ensure blades are installed correctly and evenly Check and tighten all mounting bolts and screws
Fan is noisy	Loose components Motor issues Improper installation	Check for loose screws on blades, canopies, and mounting Ensure the fan is securely mounted and balanced If noise persists, contact customer support
Low airflow	Incorrect speed setting Dust accumulation on blades	Increase speed setting Clean fan blades thoroughly

8. Specifications

Detailed technical specifications for the USHA Bloom Daffodil 1250mm Ceiling Fan.

Feature	Specification
Brand	USHA
Model Name	BLOOM DAFFODIL
Model Number	NON STAR RATED
Colour	Sparkle Golden and Brown
Blade Length	1250 Millimetres
Number of Blades	3
Material Type	Aluminium
Power Source	Corded Electric
Wattage	85 Watts
Voltage	230 Volts
Number Of Speeds	5

Feature	Specification
Controller Type	Button Control
Speed	380 RPM
Air Flow Capacity	215 Cubic Feet Per Second
Mounting Type	Ceiling Mount
Item Weight	4720 Grams
Product Dimensions (D x W x H)	18D x 18W x 60H Centimeters
Special Feature	Lightweight, Dust Resistant
Indoor Outdoor Usage	Indoor, Outdoor
Specification Met	CE

9. Warranty Information

This USHA Bloom Daffodil Ceiling Fan comes with a manufacturer's warranty.

- **Warranty Period:** 3 Years on Motor Warranty.
- The warranty covers manufacturing defects under normal use.
- Keep your purchase receipt as proof of purchase for warranty claims.
- For detailed terms and conditions, please refer to the warranty card included with your product or contact USHA customer support.

10. Customer Support

For any queries, assistance, or service requests, please contact USHA customer support.

- **Manufacturer:** Usha International Limited
- **Registered Office:** Surya Kiran Building, 19 K.G. Marg, New Delhi-110 001
- **Toll Free No.:** 18001033111