Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- One For All /
- One for All URC7880 Universal Smart Remote Control up to 8 Devices with Free Setup App Easy Learning Feature Infrared
 Connectivity Technology and 3 Shortcut App Keys Black

One For All URC7880

One For All URC7880 Universal Smart Remote Control Instruction Manual

Model: URC7880 Brand: One For All

INTRODUCTION

The One For All URC7880 Universal Smart Remote Control is designed to simplify your home entertainment experience by consolidating control of up to 8 devices into a single, intuitive remote. This manual provides comprehensive instructions for setting up, operating, and maintaining your new universal remote.





Image: Front view of the One For All URC7880 Universal Smart Remote Control.

KEY FEATURES

- 8-Device Control: Compatible with TVs, Sat/Cable boxes, DVD/Blu-ray players, Media players, Game Consoles (IR Only), and Audio devices (Soundbars, Stereos, Amplifiers) from over 7000 brands.
- Smart App Setup: Free setup app for smartphones (iOS/Android) for easy configuration and device management via Bluetooth Smart.
- Infrared Connectivity: Utilizes infrared technology for broad compatibility.
- Learning Feature: Copy any function directly from your original remote to customize the URC7880.
- Shortcut App Keys: Three dedicated keys for direct access to favorite streaming services like Amazon Prime, YouTube, and Netflix.
- Activity Modes: Control multiple devices as if they were one with pre-programmed activity modes (e.g., Watch Movie, Listen to Music).

- Macro Programming: Combine a series of functions onto a single key for complex actions.
- Remote Finder: Use the app to make the remote beep, helping you locate it if misplaced.





Image: Packaging of the One For All URC7880 Universal Smart Remote Control, highlighting key features.

SETUP

1. Inserting Batteries

The URC7880 remote requires 2 AA batteries (not included). Open the battery compartment cover on the back of the remote and insert the batteries, ensuring correct polarity (+/-). Close the cover securely.

2. Initial Setup & Device Pairing

The Smart Control 8 offers multiple setup methods, including Simple Set and app-based setup for optimal compatibility.

Using the One For All Setup App (Recommended)

For the easiest and most comprehensive setup, download the free One For All Setup App from your smartphone's app store (available for iOS and Android). The app uses Bluetooth Smart to communicate with your remote and access the latest code database.

- 1. Download and open the "My Nevo" app (or "One For All Setup" app).
- 2. Follow the on-screen prompts to pair your remote via Bluetooth.
- 3. Select the type of device you wish to set up (e.g., TV, STB, Blu-ray).
- 4. Choose your device's brand from the list. The app will guide you through testing functions to ensure correct pairing.
- 5. Confirm successful pairing in the app.

Your browser does not support the video tag.

Video: One for All Smart Control 8 Tutorial - Provides a detailed walkthrough of the setup process, including app usage and device pairing.

Manual Code Setup (Using Code List)

If you prefer not to use the app, you can manually enter codes from the included code list.

- 1. Turn on the device you want to control.
- 2. Press the DEVICE key on the URC7880 for the device you want to set up (e.g., TV, STB).
- 3. Hold down the MAGIC key until the LED under the DEVICE key blinks twice and stays lit.
- 4. Enter the 4-digit code for your device's brand from the code list. The LED will blink twice if the code is valid.
- 5. Point the remote at your device and press the POWER key. If the device turns off, the setup is successful. If not, try the next code for your brand.

OPERATING THE REMOTE

1. Device Selection

To control a specific device, press the corresponding DEVICE key at the top of the remote (TV, STB, BLU, AUD, DVD, GAME, MEDIA, S.BAR). The LED under the selected device key will light up, indicating which device the remote is currently controlling.



Image: The One For All URC7880 remote control resting on a reflective surface, showcasing its button layout.

2. Activities

Activity modes allow you to control multiple devices as if they were one. For example, in "Watch Movie" mode, the remote can control your TV, Blu-ray player, and sound system simultaneously.

- 1. Press the ACTIVITY key.
- 2. Select the desired activity icon (e.g., TV, Movie, Music, Game, Custom).
- 3. The remote will automatically switch to the correct device for each function (e.g., volume controls your soundbar, play/pause controls your Blu-ray player).
- 4. To turn off all devices in an activity, hold down the POWER key.

3. Learning Feature

The learning feature allows you to copy any function from your original remote control onto any key on the URC7880. This is useful for functions not available in the pre-programmed codes or for personalizing your remote.

- 1. Place the URC7880 and your original remote on a flat surface, facing each other, about 1-2 inches apart.
- 2. Press the MAGIC key until the LED under the DEVICE key blinks twice and stays lit.

- 3. Press the key on the URC7880 where you want to learn the function. The LED will blink rapidly.
- 4. Press the corresponding key on your original remote. The LED on the URC7880 will blink twice to confirm successful learning.
- 5. Repeat for other keys or press the MAGIC key to exit learning mode.

4. Macros

A macro is a series of functions combined onto a single key. This allows you to perform multiple actions with a single button press.

- 1. Press the MAGIC key until the LED under the DEVICE key blinks twice and stays lit.
- 2. Press the key on the URC7880 you want to assign the macro to. The LED will blink rapidly.
- 3. Enter the sequence of key presses you want to include in the macro.
- 4. Press the MAGIC key to save the macro. The LED will blink twice.

5. Remote Finder

If you misplace your remote, you can use the One For All Setup App to make it beep, helping you locate it.

- 1. Open the One For All Setup App on your smartphone.
- 2. Navigate to the "Remote Finder" function within the app.
- 3. Tap the button in the app to activate the remote's beeping sound.
- 4. Follow the sound to find your remote.

Your browser does not support the video tag.

Video: Smart Control 8 - A concise overview of the remote's features, including device control, activities, and the remote finder function.

MAINTENANCE

1. Battery Replacement

When the remote's performance degrades or the LED indicator blinks weakly, it's time to replace the batteries. The URC7880 uses 2 AA batteries.

- 1. Slide open the battery compartment cover on the back of the remote.
- 2. Remove the old batteries.
- 3. Insert two new AA batteries, ensuring correct polarity (+ and -).
- 4. Replace the battery compartment cover.

2. Cleaning

To clean your remote control, use a soft, slightly damp cloth. Do not use abrasive cleaners, alcohol, or other chemical solvents, as these may damage the remote's surface or internal components.

TROUBLESHOOTING

- Remote not responding: Check battery levels and replace if necessary. Ensure the remote is pointed directly
 at the device.
- Device not responding to commands: Verify that the correct DEVICE key is selected. If using manual code setup, try alternative codes for your device's brand.

- Learning feature not working: Ensure the remotes are placed correctly (facing each other, 1-2 inches apart). Check that the original remote's batteries are not low.
- **App connectivity issues:** Ensure Bluetooth is enabled on your smartphone and the remote is within range. Try restarting the app or your phone.

For more detailed troubleshooting or specific device issues, please refer to the official One For All support website or contact their customer service.

SPECIFICATIONS

Attribute	Value
Product Dimensions	9.4 x 4.8 x 1.1 inches
Item Weight	3.52 ounces
Item Model Number	URC7880
Batteries Required	2 AA batteries
Connectivity Technology	Infrared
Max Number of Supported Devices	8
Color	Black

WARRANTY AND SUPPORT

One For All products typically come with a limited warranty. Please refer to the warranty information included in your product packaging or visit the official One For All website for detailed terms and conditions.

For technical support, product registration, or frequently asked questions, please visit the One For All website or contact their customer service hotline.

Related Documents - URC7880



One For All Essential 8 Device Universal Remote Control URC3680 Setup Guide

Comprehensive guide to setting up and using the One For All Essential 8 Device Universal Remote Control (URC3680) for managing up to 8 audio-video devices, including features like backlighting, simple setup, code setup, learning functions, volume lock, and activity modes.



One For All URC3661 Essential 6 Device Universal Remote Control Setup Guide

Comprehensive guide to setting up and using the One For All URC3661 Essential 6 Device Universal Remote Control for managing multiple audio-visual devices.



One For All Essence 6 Universal Remote Control URC2160 Setup Guide

Comprehensive guide to setting up and using the One For All Essence 6 Universal Remote Control (URC2160) for TV, Streaming, Set-Top Box, Audio, Blu-ray, and DVD devices. Learn about SimpleSet, Code Setup, Learning functions, Volume Lock, and App Shortcut keys.



One For All 5 Universal Remote URC-7552 User Manual

Comprehensive user guide for the One For All 5 Universal Remote (Model URC-7552), detailing setup, features, troubleshooting, and customer service information for operating various audio and video devices.



One For All URC7935 Streamer Remote Quick Setup Guide

Learn how to set up and use the One For All URC7935 Streamer Remote to control your streaming box, TV, and audio devices. Features include SimpleSet, Code Setup, Learning, and customizable LED colors.



One For All URC7880 Smart Control Remote Setup Guide

A comprehensive guide for setting up and using the One For All URC7880 Smart Control remote, covering SimpleSet, code setup, learning functions, macros, activities, and volume lock.