

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [mDesign](#) /

› [mDesign Tall Dresser Storage Tower Stand with 4 Removable Fabric Drawers - Model 08375MDB Instruction Manual](#)

## mDesign 08375MDB

# mDesign Tall Dresser Storage Tower Stand Instruction Manual

Brand: mDesign | Model: 08375MDB

## INTRODUCTION

Thank you for purchasing the mDesign Tall Dresser Storage Tower Stand. This manual provides essential information for the safe assembly, operation, and maintenance of your new storage unit. Please read these instructions carefully before beginning assembly and retain them for future reference.



Image: The mDesign Tall Dresser Storage Tower Stand, featuring a white steel frame, wood top, and four navy blue fabric drawers.

## SAFETY INFORMATION

- Always assemble the unit on a soft, clean surface to prevent scratches.
- Ensure all connections are securely tightened before use.
- Do not overload drawers. Distribute weight evenly.
- Keep small parts and packaging materials away from children.
- Place the unit on a level surface to prevent tipping.
- For added stability, consider anchoring the unit to a wall, especially in households with children or pets. Wall

anchoring hardware is typically not included and may need to be purchased separately.

## PACKAGE CONTENTS

Please verify that all components are present before beginning assembly:

- Steel Frame Components
- Wood Top Panel
- 4 Removable Fabric Drawers
- Adjustable Leveling Feet
- Assembly Hardware (screws, Allen wrench, etc.)

## SETUP AND ASSEMBLY

Follow these steps to assemble your mDesign Tall Dresser Storage Tower Stand. An assembly video is also provided for visual guidance.

### Assembly Video Guide

Your browser does not support the video tag.

Video: This video demonstrates the step-by-step assembly process for the mDesign Vertical Furniture Unit, showing how to connect frame components, attach the top, and insert drawers.

### Step-by-Step Instructions

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a soft, flat surface to avoid damage.
2. **Assemble Frame Sides:** Connect the horizontal bars to the vertical frame posts. Ensure the metal stops on the frame sides face the back of the unit.
3. **Connect Frame Sides:** Join the two assembled frame sides using the remaining horizontal bars. Secure all connections with the provided hardware and Allen wrench.
4. **Attach Wood Top:** Place the wood top panel onto the assembled frame. Align the pre-drilled holes and secure it with the appropriate screws.
5. **Install Leveling Feet:** Screw the adjustable leveling feet into the bottom of the frame posts. Adjust them as needed to ensure the unit is stable and level on your floor.
6. **Prepare Drawers:** Unfold each fabric drawer and insert the rigid base panel into the bottom to create a sturdy box.
7. **Insert Drawers:** Slide the prepared fabric drawers into the designated slots in the frame.



**STRONG STEEL FRAME**



**DURABLE FABRIC**



**ADJUSTABLE FEET**



Image: Detailed view highlighting the strong steel frame, durable fabric of the drawers, and adjustable leveling feet for stability.

## OPERATING INSTRUCTIONS

- **Drawer Use:** Gently pull and push the fabric drawers using the integrated handles. Avoid forcing drawers, as this may damage the fabric or frame.
- **Weight Distribution:** Distribute items evenly within each drawer and across the unit to maintain stability. Avoid placing excessively heavy items in a single drawer or on the top surface.
- **Top Surface:** The wood top can be used for displaying lightweight decorative items, lamps, or other small objects. Ensure items placed on top do not exceed the unit's stability limits.



**WATER-RESISTANT TOP**



**GENEROUSLY SIZED DRAWERS!**

Image: This image illustrates the water-resistant wood top and the spacious interior of the fabric drawers, suitable for various items like clothing or toys.

## MAINTENANCE

- **Cleaning the Frame and Top:** Wipe the steel frame and wood top with a dry cloth to remove dust and debris. Avoid abrasive cleaners or harsh chemicals.
- **Cleaning Fabric Drawers:** The fabric drawers can be spot cleaned with a damp cloth and mild soap if necessary. Allow them to air dry completely before reinserting. Do not machine wash or tumble dry.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight. Retighten if any looseness is detected.

## TROUBLESHOOTING

- **Unit is Wobbly:**
  - Ensure the unit is placed on a flat, level surface.

- Adjust the leveling feet at the bottom of the frame until the unit is stable.
- Check all frame connections and tighten any loose screws.

- **Drawers Do Not Slide Smoothly:**

- Verify that the rigid base panel is fully inserted into the bottom of each fabric drawer.
- Ensure drawers are not overloaded, which can cause them to sag.
- Check for any obstructions in the drawer slots.

## SPECIFICATIONS

Feature	Detail
Brand	mDesign
Product Dimensions	12"D x 17.75"W x 37"H
Color	Navy
Style	Classic
Room Type	Baby, Bedroom, Nursery, Playroom
Product Care Instructions	Wipe with Dry Cloth
Assembly Required	Yes
Number of Pieces	1
UPC	192173083758
Item Weight	10.48 pounds
ASIN	B07VRS4CTB
Item model number	08375MDB
Date First Available	July 25, 2019
Material	Fabric
Number of Drawers	4



Image: Visual representation of the dresser's dimensions, indicating a depth of 12 inches (30.5 cm), width of 17.75 inches (45 cm), and height of 37 inches (94 cm).

## WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the product packaging or contact mDesign directly through their official website or the retailer where the product was purchased. Please have your model number (08375MDB) and purchase details available when contacting support.

