



Manuals.plus /

› VITADE /

› VITADE 928A HD 1080P Webcam Instruction Manual

VITADE 928A

VITADE 928A HD 1080P Webcam Instruction Manual

Model: 928A

1. INTRODUCTION

Thank you for choosing the VITADE 928A HD 1080P Webcam. This manual provides essential information for setting up, operating, and maintaining your webcam to ensure optimal performance. The VITADE 928A webcam delivers high-definition video at 1080p/30fps with an 80° wide-angle lens, featuring a built-in microphone, privacy cover, automatic low-light correction, and real-time autofocus. Its innovative design includes a 360° rotatable clip and plug-and-play compatibility for various operating systems.

What's in the Box

- 1 x VITADE 928A HD Webcam
- 1 x Mini Tripod

2. SETUP

2.1 Connecting the Webcam

The VITADE 928A webcam is designed for plug-and-play functionality. Simply connect the USB cable from the webcam to an available USB port on your computer. No additional drivers are typically required for most operating systems.

Plug & Play with Xbox One

Livestream Xbox games without driver



Image: The VITADE 928A webcam connected to a computer, demonstrating its plug-and-play capability for gaming.

2.2 Mounting Options

The webcam features a universal clip that can be securely attached to various devices, including computer monitors, laptops, and LCD screens. The clip also allows for 360° rotation, enabling flexible viewing angles. For desktop use, the included mini tripod can be attached to the webcam for stable placement.

Background Replacement

Download ChromaCam-2.2.1.14 on Windows




Image: The webcam displayed with its universal clip for monitor mounting and with the included mini tripod for desktop use.

2.3 System Compatibility

The VITADE 928A webcam is compatible with a wide range of operating systems:

- Windows 7, 8, 10
- Mac OS 10.6 and above
- Chrome OS
- Android 5.0 or higher

Note: This webcam is not compatible with PlayStation 4 (PS4).

3. OPERATING INSTRUCTIONS


3.1 High-Definition Video and Audio

The VITADE 928A captures video in Full HD 1080p resolution at 30 frames per second, providing clear and detailed images. The


integrated microphone ensures clear audio capture during calls and recordings.

Full HD 1080P Camera

1920x1080 pixels



1080P HD



Autofocus



Dual Mics



Plug&Play

Image: The webcam's Full HD 1080P video capability is highlighted, along with its autofocus and dual microphone features.

3.2 Privacy Cover

For enhanced privacy and security, the webcam includes a built-in privacy shutter. Slide the cover over the lens when the webcam is not in use to prevent unauthorized access to your camera feed.

TRIPOD INCLUDED

Adjustable viewing angles with tripod



Image: The webcam featuring its integrated privacy cover, demonstrating how to slide it to cover the lens.

3.3 Autofocus and Low-Light Correction

The VITADE 928A features real-time autofocus, which quickly detects and captures moving objects precisely, eliminating the need for manual focus adjustments. Additionally, automatic low-light correction ensures that your video remains clear and true-to-life even in dim lighting conditions.

Autofocus & Low-light Correction

Provide true-to-life video in dim or overexposed lighting conditions.



Image: Visual demonstration of the webcam's autofocus and low-light correction capabilities, showing improved image quality in various lighting scenarios.

4. MAINTENANCE

4.1 Cleaning the Webcam

- To clean the lens, use a soft, lint-free cloth. Avoid abrasive materials or harsh chemicals.
- For the body of the webcam, wipe with a dry or slightly damp cloth.
- Ensure the webcam is disconnected from the power source before cleaning.

4.2 Storage

When not in use, store the webcam in a cool, dry place away from direct sunlight and extreme temperatures. Utilize the privacy cover to protect the lens from dust and scratches.

5. TROUBLESHOOTING

5.1 Webcam Not Detected

- Ensure the USB cable is securely connected to both the webcam and your computer.
- Try connecting the webcam to a different USB port.
- Restart your computer.
- Verify that your operating system is compatible (Windows 7/8/10, Mac OS 10.6+, Chrome OS, Android 5.0+).

5.2 Poor Image Quality

- Ensure the lens is clean and free from dust or smudges.
- Check lighting conditions. While the webcam has low-light correction, sufficient ambient light improves quality.
- Confirm that the privacy cover is fully open.
- Ensure the webcam is selected as the primary video device in your application settings.

5.3 No Audio from Microphone

- Verify that the webcam's microphone is selected as the input device in your computer's sound settings and in the application you are using.
- Check the microphone volume levels in your system settings.
- Ensure the microphone is not muted in your application.

6. SPECIFICATIONS

Feature	Detail
Model Number	928T
Video Resolution	1080p (Full HD) at 30fps
Lens Angle	80° Wide Angle
Focus Type	Autofocus
Microphone	Built-in
Privacy Feature	Built-in Privacy Shutter
Connectivity	USB Plug & Play
Mounting	Universal Clip, Tripod-ready
Product Dimensions	4.3 x 3.7 x 2.5 inches
Item Weight	8.8 ounces

7. WARRANTY AND SUPPORT

7.1 Warranty Information

For detailed warranty information, please refer to the warranty card included with your product packaging or visit the official VITADE website. Keep your proof of purchase for warranty claims.

7.2 Customer Support

If you encounter any issues or have questions regarding your VITADE 928A webcam that are not covered in this manual, please contact VITADE customer support. Contact details can typically be found on the product packaging or the official VITADE website.

