Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XIPUDA XPD-0005x

XIPUDA Mason Jar Wall Sconces Instruction Manual

Model: XPD-0005x

1. Important Safety Information

Please read these instructions carefully before installation and use. Keep this manual for future reference.

- **Electrical Safety:** Always turn off the main power supply at the circuit breaker before installing, cleaning, or replacing bulbs. Consult a qualified electrician if you are unsure about wiring.
- **Bulb Requirements:** Use E26 base bulbs, maximum 60W. Bulbs are not included. Ensure the bulb wattage does not exceed the specified maximum.
- **UL Listed:** This product is UL-listed, ensuring compliance with safety standards.
- **Indoor Use Only:** These sconces are designed for indoor use. Avoid installation in outdoor or excessively wet environments.
- **Handle with Care:** The glass shades are fragile. Handle them carefully during installation and maintenance.

2. Package Contents

Verify that all components are present before beginning installation.

- Mason Jar Wall Sconce Fixtures (2 units)
- Clear Glass Shades (2 units)
- Mounting Hardware (screws, wire nuts, mounting plate)
- Instruction Manual




Figure 1: Package contents including sconce fixtures, glass shades, and mounting hardware.

3. Product Specifications

Brand	XIPUDA
Model Number	XPD-0005x
Color	Black (Matte Finish)
Material	Glass, Iron
Dimensions (L x W x H)	14.17"L x 6.69"W x 13.39"H
Item Weight	1.2 Kilograms (per unit)
Bulb Base	E26

Max Wattage	60W (per bulb)
Voltage	120 Volts (AC)
Dimmable	Yes (requires compatible dimmer switch and bulb)
Indoor/Outdoor Usage	Indoor



Figure 2: Product dimensions.

4. Setup & Installation

Follow these steps for safe and proper installation. Professional installation is recommended if you are unfamiliar with electrical wiring.

1. **Turn Off Power:** Before starting, ensure the power to the installation area is turned off at the circuit breaker.
2. **Prepare Mounting:** Secure the mounting plate to the junction box using the provided screws.
3. **Wire Connections:** Connect the fixture's wires to your household electrical wires. Connect the black wire (live) to

the black wire, the white wire (neutral) to the white wire, and the ground wire to the ground wire. Secure connections with wire nuts.

4. **Mount Fixture:** Carefully push the wired fixture onto the mounting plate and secure it with the provided screws.
5. **Install Bulb:** Screw an E26 base bulb (max 60W, not included) into the socket.
6. **Attach Glass Shade:** Carefully screw the clear glass mason jar shade onto the fixture. Ensure it is securely tightened but do not overtighten.
7. **Restore Power:** Once installation is complete, turn the power back on at the circuit breaker.



Figure 3: Bulb and glass shade installation steps.

5. Operating Instructions

These sconces are designed for simple operation.

- **Turning On/Off:** Operate the sconces using your standard wall switch.
- **Dimmable Functionality:** If you have installed a compatible dimmer switch and dimmable E26 bulbs, you can

adjust the light intensity by using the dimmer control.

- **Control Method:** The primary control method is via a wall switch. Some models may support app control if integrated with smart home systems and compatible smart bulbs.

6. Maintenance

Regular maintenance ensures the longevity and appearance of your sconces.

- **Cleaning:** Turn off power before cleaning. Wipe the metal parts with a soft, dry cloth. For the glass shades, use a soft cloth dampened with water or a mild glass cleaner. Avoid abrasive cleaners or solvents.
- **Bulb Replacement:** Ensure power is off. Allow the old bulb to cool before unscrewing it. Replace with a new E26 base bulb (max 60W).
- **Inspection:** Periodically check all connections and mounting hardware to ensure they remain secure.

7. Troubleshooting

If you encounter issues, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Light does not turn on.	◦ Power is off at the breaker. ◦ Loose wire connection. ◦ Defective bulb.	◦ Check the circuit breaker and wall switch. ◦ Turn off power, check wire connections. ◦ Replace the bulb with a new one.
Light flickers.	◦ Loose bulb. ◦ Incompatible dimmer switch/bulb. ◦ Loose wire connection.	◦ Tighten the bulb. ◦ Ensure dimmer and bulb are compatible. ◦ Turn off power, check wire connections.
Glass shade is wobbly.	◦ Shade not tightened properly.	◦ Gently tighten the glass shade until secure. Do not overtighten.

8. Warranty & Support

XIPUDA provides lifetime quality assurance for this product.
If you encounter any issues with your wall light set, require replacement parts, or need expert support, please contact XIPUDA customer service. Refer to your purchase documentation or the XIPUDA website for contact details.

9. Product Application Examples

The XIPUDA Mason Jar Wall Sconces are versatile and suitable for various indoor settings, enhancing the aesthetic of your home.



Figure 4: Application in a Bathroom Vanity.




Figure 5: Application as Bedside Lighting.



Figure 6: Application in a Stairway.




Figure 7: Application in a Hallway.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07VSQTKRC

More documents and user manuals: **https://manuals.plus/**