

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Clarisonic](#) /

› [Clarisonic Mia Smart Sonic Facial Cleansing Brush User Manual](#)

Clarisonic Mia Smart

Clarisonic Mia Smart Sonic Facial Cleansing Brush User Manual

INTRODUCTION

This manual provides comprehensive instructions for the safe and effective use of your Clarisonic Mia Smart Sonic Facial Cleansing Brush. Please read this manual thoroughly before first use and retain it for future reference.



Image: The Clarisonic Mia Smart device with a brush head attached, presented on a white background.

SAFETY INFORMATION

For your safety and to ensure optimal performance, observe the following precautions:

- Charge the device for 18 hours before first use.
- Do not use the device on broken or irritated skin.
- Consult a physician before use if you have a skin condition or are undergoing medical treatment.
- Keep out of reach of children.
- Ensure the charging stand is dry before placing the device on it.

WHAT'S IN THE BOX

Your Clarisonic Mia Smart package includes the following components:

- Mia Smart Device Handle
- Daily Radiance Brush Head
- USB Charging Stand
- Mia Smart User Guide (this document)
- Warranty & Rewards Benefits Information



Image: An exploded view of the Clarisonic Mia Smart packaging, showing the device handle, daily radiance brush head, USB charging stand, user guide, and warranty information.

SETUP

Initial Charging

1. Place the Clarisonic Mia Smart device onto the USB charging stand.
2. Connect the USB charging stand to a compatible USB power adapter (not included) and plug it into a power outlet.
3. Charge the device for a full 18 hours before its first use to ensure optimal battery life.



Image: The Clarisonic Mia Smart device resting on its white charging stand.

OPERATING INSTRUCTIONS

Daily Cleansing Cycle

Follow these steps for an effective 60-second cleansing routine:

1. **Wet Face and Brush Head:** Dampen your face and the brush head with warm water.
2. **Apply Cleanser:** Apply a small amount of your preferred facial cleanser directly to the brush head.
3. **Turn On Device:** Press the power button to activate the device.
4. **Cleanse Forehead (20 seconds):** Gently move the brush in circular motions across your forehead.
5. **Cleanse Nose and Chin (20 seconds):** Move the brush across your nose and chin area.
6. **Cleanse Cheeks (10 seconds each):** Cleanse each cheek for 10 seconds. The device will pause briefly to indicate when to move to the next area.
7. **Rinse:** Rinse your face thoroughly with water and pat dry. Rinse the brush head under running water.

WET
BRUSH HEAD
AND FACE



GENTLE
FOR USE
2X DAILY

Image: A collage showing the steps for daily cleansing: wetting the brush head, applying cleanser, and gently cleansing the face.

App Connectivity

The Mia Smart device can connect to the Clarisonic app via Bluetooth for customized skincare routines, how-to videos, and progress tracking. Download the Clarisonic app from your device's app store and follow the in-app instructions to pair your device.



Image: An illustration showing the Clarisonic Mia Smart device connecting to a smartphone app, highlighting features like setting skincare goals, personalized routines, how-to videos, and warranty activation.

Official Product Video: How to Cleanse with Mia Smart

Video: A step-by-step guide demonstrating how to properly cleanse your face using the Clarisonic Mia Smart device, including attaching the brush head, applying cleanser, and moving the device across different facial zones.


ATTACHING AND CHANGING BRUSH HEADS

To attach a brush head, align the three tabs on the back of the brush head with the three slots on the device handle. Push down and twist clockwise until it locks into place. To remove, twist counter-clockwise and pull up.

Firming Massage Head

To maximize your Mia Smart functions, add the Sonic Awakening Eye Massager*

*sold separately



DEFY 15 SIGNS OF AGING

A rejuvenating facial massage targets aging on face, neck and décolleté



FACE AND NECK APPEAR UPLIFTED

Tightens and tones to restore a youthful appearance



SMOOTHS THE LOOK OF WRINKLES

Visibly reduce fine lines & deeper wrinkles in 12 weeks



SKIN FEELS FIRMER

Awaken skin's natural elasticity for a firmer, more supple feel



Image: A visual guide showcasing various brush heads and applicators available for the Clarisonic Mia Smart, categorized by function such as everyday cleansing, specialty cleansing, and applicators for firming, eye massage, makeup, and exfoliation.

USING DIFFERENT ATTACHMENTS

The Clarisonic Mia Smart is compatible with various brush heads and applicators (sold separately) to address different skincare needs:

- **Firming Massage Head:** Designed to visibly reduce fine lines and wrinkles, and improve skin firmness on the face, neck, and décolleté.
- **Sonic Awakening Eye Massager:** Helps to visibly reduce puffiness and smooth fine lines around the delicate eye area, enhancing skincare absorption.
- **Sonic Foundation Brush:** For flawless makeup blending.
- **Sonic Exfoliator:** For rough, uneven skin.

Connect to the Clarisonic App



SET SKINCARE GOALS
and track your progress



PERSONALIZED ROUTINES
customized routines for cleansing,
anti-aging, and makeup application



ACCESS HOW-TO VIDEOS & TIPS
Expert guidance right at your fingertips



ACTIVATE YOUR WARRANTY
Good for 2 years after registration




Image: A woman using the Clarisonic Mia Smart with a Firming Massage Head on her jawline, illustrating its use for firming and contouring.




Image: A woman using the Clarisonic Mia Smart with a Sonic Awakening Eye Massager around her eye area, demonstrating its application for reducing puffiness and fine lines.

MAINTENANCE AND CARE

Cleaning the Device

After each use, rinse the device handle and brush head thoroughly with warm water. You can use a mild soap to clean the handle if necessary. Ensure the device is dry before storing or placing it on the charging stand.

Replacing Brush Heads

For optimal performance and hygiene, replace your brush head every three months. Worn bristles can reduce effectiveness.

TROUBLESHOOTING

If you encounter issues with your Clarisonic Mia Smart, refer to the following common solutions:

- **Device not turning on:** Ensure the device is fully charged. Charge for 18 hours for the first use, and regularly thereafter.
- **Brush head not oscillating:** Check that the brush head is correctly attached. Push down and twist clockwise until it clicks into place.
- **Reduced performance:** Replace the brush head if it has been in use for more than three months. Ensure the device is clean and free from residue.
- **App connectivity issues:** Ensure Bluetooth is enabled on your smartphone and the device is within range. Try restarting both the device and the app.

SPECIFICATIONS

Product Dimensions	5.85 x 2.84 x 6.96 inches; 15.68 ounces
Brand	Clarisonic
Model Name	Mia Smart
Power Source	Battery Powered
Color	Blue (Note: Product images often show a light blue/teal device, while some descriptions may refer to it as white.)
ASIN	B07VVB6DSY

WARRANTY AND SUPPORT

Clarisonic offers a Two-Year Warranty on the Mia Smart device. For detailed information regarding your warranty and to register your product, please refer to the included Warranty & Rewards Benefits Information or visit the official Clarisonic website.

clarisonic®

**GENTLY
OSCILLATES**



**OTHER
DEVICES SPIN
SPINNING
TUGS ON SKIN**

Image: A collection of award badges for the Clarisonic Mia Smart, including Allure Reader's Choice, InStyle Best Beauty Buys, Glamour Beauty Reader's Choice, and NewBeauty Best Skin Products.

Official Product Video: About Mia Smart



Video: An overview video highlighting the key features and benefits of the Clarisonic Mia Smart, including its ability to tighten pores, firm skin, and brighten eyes, and its interchangeable brush heads.

Official Product Video: Mia Smart Tech Video



Video: A technical overview of the Clarisonic Mia Smart, explaining its sonic technology, cleansing effectiveness (6x better than hands alone), and its ability to minimize pores, firm contours, and boost absorption of skincare products.

Official Product Video: Makeup Removal Comparison



Video: A comparison demonstrating the effectiveness of Clarisonic Mia Smart in makeup removal versus a competitor, highlighting its

superior cleansing capabilities.

