



[Manuals.plus](#) /

› [DELUX](#) /

› DELUX M618MINI Ergonomic Wireless Vertical Mouse User Manual

DELUX M618MINI

DELUX M618MINI Ergonomic Wireless Vertical Mouse

Model: M618MINI | Brand: DELUX

INTRODUCTION

Thank you for choosing the DELUX M618MINI Ergonomic Wireless Vertical Mouse. This manual provides detailed instructions for setting up, operating, and maintaining your new mouse. Designed with user comfort in mind, the M618MINI promotes a natural handshake posture, reducing wrist strain during extended use. It features dual-mode connectivity (2.4GHz wireless and Bluetooth 5.0), adjustable DPI, a long-lasting rechargeable battery, and quiet click buttons for a productive and comfortable computing experience.



Natural Handshake Posture

Reduce carpal tunnel syndrome efficiently

The ergonomic design of the DELUX M618MINI mouse encourages a natural handshake posture, which helps to alleviate wrist discomfort and prevent repetitive strain injuries.

PACKAGE CONTENTS

Please check the package contents to ensure all items are present:

- DELUX M618MINI Ergonomic Wireless Vertical Mouse
- USB Nano Receiver (stored in the mouse's bottom compartment)
- USB-C Charging Cable
- User Manual

PRODUCT OVERVIEW

Key Features

- **Ergonomic Vertical Design:** Promotes a natural hand and wrist position.
- **Dual-Mode Connectivity:** Seamlessly switch between 2.4GHz wireless and Bluetooth 5.0.

- **Rechargeable Battery:** Built-in 1000mAh polymer lithium-ion battery for long-lasting use.
- **Adjustable DPI:** 5 levels of DPI (800/1200/1600/2400/4000) for precise control.
- **Quiet Clicks:** Reduced clicking noise for a quieter work environment.
- **RGB Lighting:** Dynamic RGB backlight effects (can be turned off).

Button Layout



Front view of the DELUX M618MINI mouse, highlighting its ergonomic form and button placement.

1. **Left Click Button:** Standard left mouse button.
2. **Right Click Button:** Standard right mouse button.
3. **Scroll Wheel:** For vertical scrolling and middle-click function.
4. **DPI Switch Button:** Cycles through DPI settings.
5. **Forward Button:** Navigates forward in web browsers or file explorers.
6. **Backward Button:** Navigates backward in web browsers or file explorers.

SETUP

1. Charging the Mouse

Before first use, or when the battery is low, connect the mouse to a USB power source using the provided USB-C charging cable. The mouse can be used while charging.



1000mAh Rechargeable Battery

Stable use for weeks with the RGB light on

The DELUX M618MINI mouse features a 1000mAh rechargeable battery, providing stable use for weeks. It can be charged via the USB-C port located at the front of the mouse.

2. 2.4GHz Wireless Connection

1. Locate the USB Nano Receiver stored in the compartment at the bottom of the mouse.
2. Plug the USB Nano Receiver into an available USB port on your computer.
3. Turn on the mouse using the ON/OFF switch located on the bottom.
4. The mouse should automatically connect to your computer.

3. Bluetooth 5.0 Connection

1. Turn on the mouse using the ON/OFF switch on the bottom.
2. Press the mode switch button on the bottom of the mouse to switch to Bluetooth mode (indicated by a specific LED color or pattern).
3. On your computer or device, go to Bluetooth settings and enable Bluetooth.
4. Search for new devices. Select "DELUX M618MINI" from the list of available devices.

5. Follow any on-screen prompts to complete the pairing process.



Multi-Device Workflow

3 ways to connect
Connect with up to 3 devices

The bottom of the DELUX M618MINI mouse illustrates its multi-device workflow, supporting wired, 2.4GHz wireless, and Bluetooth 5.0 connections.

OPERATING INSTRUCTIONS

Adjusting DPI Sensitivity

The DELUX M618MINI mouse offers 5 adjustable DPI levels: 800, 1200, 1600, 2400, and 4000. To change the DPI, press the DPI switch button located above the backward button. Each press will cycle through the available DPI settings, allowing you to adjust cursor speed and precision to your preference.



The DPI button on the DELUX M618MINI allows for quick adjustment between 800, 1200, 1600, 2400, and 4000 DPI settings.

Controlling RGB Lighting

The mouse features dynamic RGB lighting. To turn the RGB lighting on or off, simultaneously press the Left Click, Right Click, and Scroll Wheel buttons.

Quiet Click Feature

The DELUX M618MINI is designed with quiet click buttons, significantly reducing the sound produced when clicking. This feature is ideal for quiet work environments, minimizing distractions for both the user and those nearby.



Quiet Clicks

Work with less distractions

The quiet click design of the DELUX M618MINI mouse ensures a silent operation, allowing you to work with fewer distractions.

MAINTENANCE

Cleaning

To maintain the performance and appearance of your mouse, regularly clean its surface. Use a soft, dry cloth to wipe away dust and debris. For stubborn marks, a slightly damp cloth with mild soap can be used, ensuring no liquid enters the mouse. Avoid using harsh chemicals or abrasive materials.

Battery Care

The built-in rechargeable battery is designed for long life. To maximize battery lifespan:

- Avoid fully discharging the battery frequently.
- Store the mouse in a cool, dry place when not in use for extended periods.
- Use only the provided charging cable or a certified USB-C cable.

TROUBLESHOOTING

If you encounter any issues with your DELUX M618MINI mouse, please refer to the following table for common problems and solutions:

Problem	Solution
Mouse not responding	Ensure the mouse is turned ON. Check battery level and charge if necessary. For 2.4GHz: Ensure USB receiver is properly plugged in. Try a different USB port. For Bluetooth: Ensure Bluetooth is enabled on your device and the mouse is paired. Try re-pairing. Restart your computer.
Cursor movement is erratic or slow	Clean the optical sensor at the bottom of the mouse. Ensure you are using the mouse on a suitable surface (non-reflective, non-glass). Adjust DPI settings to a higher level.
Cannot connect via Bluetooth	Ensure the mouse is in Bluetooth mode. Delete previous pairings for the mouse on your device and try pairing again. Ensure your device's Bluetooth is enabled and discoverable.
RGB lighting is off	Simultaneously press the Left Click, Right Click, and Scroll Wheel buttons to toggle the lighting.

SPECIFICATIONS

Feature	Detail
Model	M618MINI
Brand	DELUX
Connectivity	2.4GHz Wireless, Bluetooth 5.0, Wired (charging)
DPI Levels	800 / 1200 / 1600 / 2400 / 4000
Number of Buttons	6
Battery Type	1000mAh Polymer Lithium-ion (Rechargeable)
Operating System Compatibility	Windows XP/Vista/7/8/10/Android, Mac (limited support for forward/backward buttons)
Dimensions	103 x 89 x 69 mm (approx.)
Color	Brown
Special Features	Ergonomic Design, LED Light, Rechargeable, Wireless, Silent Clicks



Vertical Mouse for Small Hands

The compact dimensions of the DELUX M618MINI make it suitable as a vertical mouse for various hand sizes.

WARRANTY AND CUSTOMER SUPPORT

DELUX products are manufactured to high-quality standards and are backed by a reliable warranty. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official DELUX website. If you have any questions, require technical assistance, or need to claim warranty service, please contact DELUX customer support through the following channels:

- **Email:** Refer to your product packaging or the official DELUX website for the support email address.
- **Website:** Visit the official DELUX website for FAQs, drivers, and support resources.

Please have your product model (M618MINI) and purchase information ready when contacting support.