

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Transformers](#) /

› [Transformers Studio Series 49 Deluxe Class Movie 1 Bumblebee Action Figure Instruction Manual](#)

Transformers E7195AS00

Transformers Studio Series 49 Deluxe Class Movie 1 Bumblebee Action Figure Instruction Manual

Model: E7195AS00

INTRODUCTION

Welcome to the world of Transformers Studio Series. This manual provides comprehensive instructions for your Studio Series 49 Deluxe Class Movie 1 Bumblebee Action Figure. Inspired by iconic movie scenes, this figure is designed with specific details to reflect the Transformers movie universe. This collectible figure converts between robot and car modes, offering an engaging experience for collectors and enthusiasts aged 8 and up.

PRODUCT OVERVIEW

The Studio Series 49 Deluxe Class Bumblebee figure is a 4.5-inch scale action figure featuring vivid, movie-inspired deco. It includes a detailed weapon accessory and is designed to reflect the character's size in the first Transformers movie. The figure and its packaging are inspired by the iconic city tunnel switch scene.



Image: Bumblebee figure in robot mode, ready for action.



Image: Bumblebee figure transformed into its Chevrolet Camaro car mode.

SAFETY INFORMATION

WARNING: This product may contain sharp points, small parts that are choking hazards, and other elements that are not suitable for children under 3 years of age. Adult supervision is recommended for younger users.

TRANSFORMATION TO ROBOT MODE (SETUP)

The Bumblebee figure converts from car mode to robot mode in 39 steps. This transformation is designed for advanced users and requires careful handling.

1. Begin with the figure in car mode.
2. Carefully separate the rear section of the car to begin unfolding the legs.
3. Rotate and extend the leg components, ensuring all joints click into place.
4. Open the car doors and manipulate the side panels to form the robot's arms.
5. Fold and position the front hood and windshield section to form the robot's chest and head.
6. Extend the robot's head and ensure all panels are securely tabbed.
7. Attach the detailed weapon accessory to Bumblebee's hand.
8. Adjust the figure's pose as desired.

For a visual guide, please refer to the official transformation video below.

Your browser does not support the video tag.

Video: Official demonstration of the Transformers Studio Series 49 Bumblebee figure's transformation.



Image: Bumblebee in robot mode with its weapon accessory.

TRANSFORMATION TO CAR MODE (OPERATING)

To convert Bumblebee from robot mode back to car mode, follow the 39 steps in reverse order, ensuring all panels align correctly for a seamless vehicle form.

1. Remove the weapon accessory.

2. Collapse the robot's head and chest section, tucking it into the car's front.
3. Fold the arm panels inward to form the car doors.
4. Compress and align the leg components to form the rear section of the car.
5. Ensure all tabs and slots are securely connected to achieve a solid car mode.

Refer to the official transformation video for detailed visual instructions.



Image: Side view of Bumblebee in car mode.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to gently wipe dust from the figure. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the figure in a cool, dry place away from direct sunlight to prevent discoloration or material degradation.
- **Handling:** Always handle the figure with care, especially during transformation, to avoid stressing small joints or breaking delicate parts.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Difficulty transforming	Incorrect step sequence, stiff joints, or misaligned panels.	Review the instruction steps carefully. Apply gentle, even pressure. Refer to the official video for visual guidance. Do not force parts.
Loose joints or parts	Repeated transformations or rough handling.	For minor looseness, some collectors use clear nail polish or floor polish on ball joints (apply sparingly and allow to dry). For broken parts, contact customer support.
Figure does not stand stably in robot mode	Feet or leg panels not fully locked into position.	Ensure all leg and foot components are fully extended and tabbed as per instructions. Adjust the pose for better balance.

SPECIFICATIONS

- **Product Dimensions:** 6 x 2.5 x 9.13 inches
- **Item Weight:** 2.88 ounces

- **Model Number:** E7195AS00
- **Manufacturer Recommended Age:** 8 years and up
- **Release Date:** August 3, 2019
- **Manufacturer:** Hasbro




Image: Dimensions of the Bumblebee figure in robot mode.

WHAT'S IN THE BOX

- 1 x Bumblebee Action Figure

- 1 x Weapon Accessory
- 1 x Removable Backdrop
- 1 x Instruction Sheet (This manual)



Image: Bumblebee figure with its removable backdrop, depicting the city tunnel switch scene.

WARRANTY AND SUPPORT

For any questions regarding your Transformers Studio Series 49 Bumblebee figure, including warranty information or replacement parts, please contact Hasbro customer support directly. Refer to the packaging for specific contact details or visit the official Hasbro website.

