

[Manuals.plus](#) /

> [Lavazza](#) /

> Lavazza Blue Classy Mini Espresso Coffee Machine LB 300 Instruction Manual

Lavazza LB 300

Lavazza Blue Classy Mini Single Serve Espresso Coffee Machine

MODEL: LB 300

Your guide to perfect espresso, simply.

1. Product Overview

The Lavazza Blue Classy Mini LB 300 is a compact and efficient single-serve espresso coffee machine designed for ease of use and consistent quality. It is specifically engineered to work with Lavazza Blue capsules, delivering authentic Italian espresso with minimal effort.



Image: The Lavazza Blue Classy Mini Espresso Machine shown alongside a Lavazza Caffè Crema coffee capsule.

Key Features:

- Works exclusively with Lavazza Blue capsules.

- Two coffee selections: simple touch controls for 1 programmable free dose and 1 pre-set espresso.
- Designed for a creamy espresso experience.

2. Setup

Before first use, ensure all packaging materials are removed and the machine is placed on a stable, level surface near a power outlet.

1. **Clean the Water Tank:** Remove the water tank from the back of the machine. Wash it with mild soap and water, then rinse thoroughly.
2. **Fill the Water Tank:** Fill the water tank with fresh, potable water up to the 'MAX' line. Place the tank back into the machine securely.
3. **Power On:** Plug the machine into a suitable power outlet. The indicator lights for Lungo and Espresso will begin to blink, indicating the machine is heating up. Wait for the lights to become solid, which signifies the machine is ready for use (approximately 1 minute).
4. **First Use Rinse:** Before brewing coffee, perform a rinse cycle. Place a cup under the dispenser. Press either the Lungo or Espresso button. Allow the hot water to run through the system. Discard the water. This primes the machine and cleans any manufacturing residue.



Image: The Lavazza Blue Classy Mini Espresso Machine with a cup placed on the drip tray, ready for operation.

3. Operating Instructions

Brewing espresso with your Lavazza Blue Classy Mini is a simple, one-touch process.

1. **Ensure Machine is Ready:** Confirm the water tank is filled and the indicator lights are solid (not blinking).
2. **Insert Capsule:** Lift the top handle of the machine. Insert one Lavazza Blue capsule into the designated slot. Close the handle firmly until you hear a click, indicating the capsule is correctly pierced.
3. **Place Cup:** Position your espresso cup on the drip tray directly under the dispenser.

4. **Select Coffee:** Choose your desired coffee selection:

- **Espresso Button:** For a standard espresso shot.
- **Lungo Button:** For a longer espresso shot.

The machine will begin brewing automatically.

5. **Enjoy:** Once brewing is complete, the machine will stop automatically. Carefully remove your cup and enjoy your fresh espresso.

6. **Eject Used Capsule:** Lift the top handle again to eject the used capsule into the internal collection drawer. Close the handle.



Image: A close-up of a freshly brewed espresso shot in a small white cup, showcasing the rich crema.

4. Maintenance

Regular cleaning ensures optimal performance and longevity of your machine.

- **Daily Cleaning:**
 - Empty and rinse the drip tray and used capsule collection drawer daily.
 - Wipe the exterior of the machine with a soft, damp cloth.

- **Water Tank Cleaning:** Clean the water tank weekly with mild soap and water. Rinse thoroughly to prevent residue buildup.
- **Descaling:** The frequency of descaling depends on water hardness. It is recommended to descale every 3-6 months. Refer to the full user manual for detailed descaling instructions using a suitable descaling solution.

5. Troubleshooting

If you encounter issues with your machine, refer to the following common solutions:

Problem	Possible Cause	Solution
Machine not turning on.	Not plugged in; power outage.	Check power connection; check circuit breaker.
No coffee dispenses.	Water tank empty; capsule not inserted correctly; machine not heated.	Fill water tank; re-insert capsule firmly; wait for indicator lights to become solid.
Coffee is cold or lukewarm.	Machine not fully heated; machine needs descaling.	Wait for indicator lights to become solid; perform descaling procedure.
Leaking from machine.	Water tank not seated correctly; drip tray full.	Ensure water tank is firmly in place; empty drip tray.

For persistent issues, please contact Lavazza customer support.

6. Specifications

Attribute	Detail
Brand	Lavazza
Model Number	LB 300
Coffee Maker Type	Espresso Machine
Operation Mode	Fully Automatic
Compatible Coffee	Lavazza Blue Capsules
Special Feature	Programmable (for one coffee selection)
Filter Type	Reusable (internal filter system, not user-replaceable filter)
Unit Count	1.0 Count (machine only)
Date First Available	July 30, 2019

7. Warranty & Support

For warranty information and customer support, please refer to the documentation included with your product or visit the official Lavazza website. Keep your proof of purchase for warranty claims.

Online Resources:

- Visit the [Lavazza Store on Amazon](#) for product information and accessories.