

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Como Audio](#) /
- › [Como Audio Bluetooth Turntable \(Model CATTWU\) Instruction Manual](#)

Como Audio CATTWU

Como Audio Bluetooth Turntable Instruction Manual

Model: CATTWU

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Como Audio Bluetooth Turntable. Please read this manual thoroughly before using the product to ensure proper function and longevity.



Image: The Como Audio Bluetooth Turntable in Hickory finish, showcasing its elegant design.

SETUP

1. Unpacking and Inspection

Carefully remove all components from the packaging. Ensure the following items are present:

- Como Audio Bluetooth Turntable
- Removable clear dust cover
- Como Audio slip mat
- Universal power supply

- High-quality audio cable

Inspect all components for any signs of damage. If any items are missing or damaged, contact Como Audio customer support.

2. Placement

Place the turntable on a stable, level surface away from direct sunlight, heat sources, and excessive vibration. Ensure adequate ventilation around the unit.

3. Assembly

1. Place the platter onto the spindle.
2. Position the Como Audio slip mat on top of the platter.
3. Attach the removable clear dust cover by aligning its hinges with the slots on the turntable's rear.
4. The Ortofon OM10 cartridge is pre-mounted on the tonearm, and no anti-tracking or counterweight adjustments are necessary.



Image: The removable clear dust cover, designed to protect the turntable from dust.



Image: Close-up of the pre-mounted Ortofon OM10 cartridge on the tonearm.

4. Connections

Your Como Audio Turntable offers three connection options:

- **Bluetooth:** For wireless connection to compatible Como Audio systems, Bluetooth headphones, or Bluetooth speakers.
- **Phono Pre-amp Output:** For connecting to a device's dedicated Moving Magnet Phono input.
- **Line Output:** For connecting to a device's Line/Aux input, including powered speakers.

Connect the universal power supply to the turntable and then to a power outlet.



Image: Rear view of the turntable showing the Phono Stage and Line Out connections.

OPERATING INSTRUCTIONS

1. Power On/Off

Connect the power supply. The turntable will power on. To power off, disconnect the power supply.

2. Speed Selection

Use the anodized aluminum speed button to select between 33 and 45 RPM. Press the button to toggle between speeds. The turntable also supports 78 RPM with an optional belt and stylus (not included).



Image: The speed selection button, used to switch between 33 and 45 RPM.

3. Playing a Record

1. Place a record on the slip mat.
2. Select the correct speed (33 or 45 RPM) using the speed button.
3. Carefully lift the tonearm and position the stylus over the desired track on the record.
4. Gently lower the tonearm onto the record.
5. At the end of the record, lift the tonearm and return it to its rest.

4. Bluetooth Pairing

To stream records wirelessly:

1. Ensure the Bluetooth transmitter on the turntable is powered on.
2. Put your Como Audio system, Bluetooth headphones, or Bluetooth speakers into pairing mode.
3. The turntable will automatically attempt to pair with nearby Bluetooth devices.
4. Once paired, audio from the turntable will stream wirelessly to the connected device.

The Bluetooth transmitter has its own power switch, allowing you to transmit only when desired. The effective range is up to 33 feet (10 meters).

5. Wired Connections

For wired audio output, connect the turntable to your audio system using the provided high-quality audio cable. Use either the Phono pre-amp output for a dedicated phono input or the Line output for a standard auxiliary input.

MAINTENANCE

1. Cleaning

- **Dust Cover:** Clean the dust cover with a soft, damp cloth. Avoid abrasive cleaners.
- **Turntable Chassis:** Wipe the wooden chassis with a dry, soft cloth.
- **Stylus:** Use a specialized stylus cleaning brush to gently remove dust and debris from the stylus tip. Always brush from back to front.

2. Cartridge Care

The Ortofon OM10 cartridge is a precision component. Avoid touching the stylus with your fingers. If the sound quality degrades, inspect the stylus for wear or damage. Replacement cartridges are available from Como Audio or authorized dealers.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound output	Power not connected Incorrect input selected on receiver/speaker Bluetooth not paired or out of range Wired connection loose or incorrect	Ensure power supply is securely connected. Select the correct input (Phono/Line/Bluetooth) on your audio system. Re-pair Bluetooth device; ensure it's within 33 feet (10m). Check all wired connections.
Skipping or distorted sound	Record is dirty or damaged Stylus is dirty or worn Turntable not level Excessive vibration	Clean the record. Clean or replace the stylus. Ensure the turntable is on a level surface. Place the turntable away from sources of vibration.
Incorrect playback speed	Wrong speed selected Belt issue	Press the speed button to select 33 or 45 RPM. Check if the drive belt is properly seated or needs replacement.

SPECIFICATIONS

Feature	Detail
Product Dimensions	16.34 x 4.65 x 12.6 inches
Item Weight	11.66 pounds (5.3 Kilograms)
Model Number	CATTWU
Brand	Como Audio

Feature	Detail
Included Components	Dust cover, Slip mat, Power supply, Audio cable
Special Features	Built-In Phono Preamp, Bluetooth, 78 RPM Support (optional)
Material	Plastic (Chassis may include wood veneer)
Color	Hickory
Compatible Devices	Speakers, Bluetooth Audio Systems
Motor Type	AC Motor
Signal Format	Analog
Cartridge	Ortofon OM10 (pre-mounted)

OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

Video: An official product video from Como Audio Inc, demonstrating the Bluetooth Turntable. This video highlights key features and usage scenarios.

WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please contact Como Audio directly. Refer to the official Como Audio website or your purchase documentation for specific warranty terms and contact details.

Manufacturer: Como Audio

Website: [Visit the Como Audio Store on Amazon](#)