Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JOYIN 10884

JOYIN Halloween Zombie Groundbreaker Decoration User Manual

Model: 10884

Product Overview

The JOYIN Halloween Zombie Groundbreaker is an outdoor decoration designed to enhance your Halloween display. It features a realistic zombie head and arms, complete with flashing LED eyes and spooky sounds activated by an infrared (IR) motion sensor. This decoration is crafted from high-quality latex, plastic, and fabric for durability and reusability.



Main product view of the JOYIN Halloween Zombie Groundbreaker.

Safety Information

- For outdoor use only.
- Unplug or remove batteries during inclement weather to prevent damage.
- Do not allow children to play on or near the display.
- Keep away from flammable materials.

Setup Instructions

1. **Unpack:** Carefully remove all components from the packaging. You should have one zombie head and two arms.
2. **Battery Installation:** Locate the battery compartment, typically on the back or bottom of the zombie head. Open the compartment (a screwdriver may be required). Insert 3 AA batteries (not included), ensuring correct polarity (+/-). Close the compartment securely.

3. **Placement:** Position the zombie head and arms in your desired outdoor location, such as a yard, garden, or front door area. Arrange them to appear as if the zombie is crawling out of the ground.
4. **Activate:** Turn the power switch to the "ON" position. The IR sensor is now active.



Illustration of the battery compartment and power switch for easy setup.

Operating Instructions

The JOYIN Zombie Groundbreaker is equipped with an IR motion sensor. Once activated, it will respond to movement within approximately 3 feet.

- **Motion Activation:** When motion is detected by the IR sensor, the zombie's eyes will flash red, and it will emit spooky sounds (screams and yells).
- **Automatic Reset:** After activation, the unit will return to standby mode, awaiting the next motion detection.
- **Nighttime Effect:** The flashing LED eyes are designed to be particularly effective in low-light conditions, creating a more terrifying atmosphere.



The zombie groundbreaker's built-in LED lights create a scary atmosphere in the dark.



The zombie groundbreaker features realistic details and produces horrific sounds.

Maintenance

- **Cleaning:** Wipe the surface with a soft, dry cloth. Do not use abrasive cleaners or immerse in water.
- **Storage:** When not in use, remove batteries and store the decoration in a cool, dry place away from direct sunlight to preserve its materials and electronic components.
- **Battery Replacement:** Replace batteries when the lights dim or sounds become faint.

Troubleshooting

Problem	Possible Cause	Solution
No lights or sound	Batteries are dead or incorrectly installed. Power switch is off.	Check battery polarity and replace if necessary. Ensure power switch is in the "ON" position.

Problem	Possible Cause	Solution
Lights and sound are weak	Low battery power.	Replace with fresh AA batteries.
Motion sensor not activating	Obstruction in front of sensor. Sensor range exceeded.	Ensure nothing is blocking the sensor. Move closer to the decoration to activate.

Specifications

Feature	Detail
Brand	JOYIN
Model Number	10884
Material	Latex, Plastic, Fabric
Power Source	3 AA Batteries (not included)
Activation	IR Sensor Activated (within 3 ft)
Features	Flashing LED Eyes, Spooky Sounds
Dimensions (L x W x H)	9.06 x 7.87 x 6.1 inches
Recommended Use	Outdoor decor, home yard, garden, front door, Halloween party, indoor Halloween props

Warranty and Support

This product is designed for durability and enjoyment. For any questions or concerns regarding your JOYIN Halloween Zombie Groundbreaker, please refer to the retailer's return and support policies where the product was purchased.

© 2023 JOYIN. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07VYNP47P

More documents and user manuals: **https://manuals.plus/**