Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Nekteck PL6

Nekteck LED Floor Lamp PL6 User Manual

Model: PL6

1. Important Safety Instructions

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- Do not operate the lamp with a damaged cord or plug. If damaged, contact customer support.
- Do not use this lamp in wet locations or near water.
- Ensure the lamp is unplugged before cleaning or attempting any maintenance.
- Do not attempt to modify the lamp or replace the LED light source. The LED components are not user-replaceable.
- Place the lamp on a stable, level surface to prevent tipping.
- Keep the lamp away from heat sources and direct sunlight to prevent damage to components.
- This lamp is for indoor use only.

2. Package Contents

Carefully unpack all components and check for any damage. If any parts are missing or damaged, please contact Nekteck customer support.

- Lamp Head with Control Panel (1)
- Light Pole #1 (1)
- Light Pole #2 (1)
- Reliable Base (1)



Image: All components of the Nekteck LED Floor Lamp, including the lamp head, two pole sections, and the base.

3. Assembly Instructions

Follow these steps to assemble your Nekteck LED Floor Lamp:

1. Place the Reliable Base on a flat, stable surface.
2. Screw Light Pole #2 into the threaded hole on the Reliable Base. Turn clockwise until secure.
3. Screw Light Pole #1 into the top of Light Pole #2. Turn clockwise until secure.
4. Carefully screw the Lamp Head with Control Panel onto the top of Light Pole #1. Ensure the power cord is not twisted during this step. Turn clockwise until secure.
5. Plug the power adapter into a standard wall outlet.

Your lamp is now assembled and ready for use.

4. Product Overview and Features

The Nekteck LED Floor Lamp PL6 offers versatile lighting with adjustable brightness and color temperature, designed for

various environments such as living rooms, bedrooms, and offices.

- **Adjustable Brightness:** 5 levels of brightness to suit your needs.
- **Adjustable Color Temperature:** 4 color temperature modes (3000K-6500K) for different moods and tasks.
- **Flexible Gooseneck:** A 360-degree adjustable silicone gooseneck allows you to direct light precisely where it's needed.
- **Touch Control:** Intuitive touch-sensitive controls for easy operation.
- **Memory Function:** The lamp remembers your last brightness and color temperature setting when turned off and on (unless power is interrupted).



Image: The flexible gooseneck of the Nekteck LED Floor Lamp demonstrating its adjustability.

5. Operating Instructions

The Nekteck LED Floor Lamp features an easy-to-use touch control panel located on the lamp head.



Image: Detailed view of the touch control panel on the lamp's pole, showing icons for brightness, color temperature, and power.

5.1. Power On/Off

Tap the **Power Button** (circle icon with a vertical line) once to turn the lamp on or off.

5.2. Adjusting Brightness

To adjust the brightness, touch and hold the **Brightness Control** icon (sun icon with up/down arrows). The brightness will cycle through its 5 levels. Release your finger when the desired brightness is reached.



Image: Visual representation of the lamp's 5 brightness levels, from 20% to 100% illumination.

5.3. Adjusting Color Temperature

To change the color temperature, touch and hold the**Color Temperature Control** icon (stacked wavy lines). The color temperature will cycle through its 4 modes (3000K, 4000K, 5000K, 6000K, 6500K). Release your finger when the desired color temperature is reached.



Image: Visual representation of the lamp's 5 color temperature settings, ranging from warm white (3000K) to cool daylight (6500K).

5.4. Memory Function

The lamp is equipped with a memory function. When you turn the lamp off and then on again using the power button, it will resume the last brightness level and color temperature setting you used. This function will reset if the lamp is unplugged or if power to the outlet is interrupted.

6. Maintenance

To ensure the longevity and optimal performance of your Nekteck LED Floor Lamp, follow these simple maintenance guidelines:

- **Cleaning:** Always unplug the lamp before cleaning. Use a soft, dry cloth to wipe down the lamp's surfaces. Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish.
- **Dusting:** Regularly dust the lamp head and pole to prevent dust buildup, which can affect light output.
- **LED Care:** The LED light source is integrated and does not require replacement. Do not attempt to open the lamp

head.

7. Troubleshooting

If you encounter any issues with your Nekteck LED Floor Lamp, please refer to the following common problems and solutions:

- **Lamp does not turn on:**
  - Ensure the power cord is securely plugged into a working electrical outlet.
  - Check if the outlet is receiving power (test with another device).
  - Verify all lamp sections are securely screwed together.
- **Light flickers or is dim:**
  - Ensure the power connection is stable.
  - Try adjusting the brightness level.
  - If flickering persists, unplug the lamp for a few minutes and then plug it back in.
- **Touch controls are unresponsive:**
  - Ensure your fingers are clean and dry when operating the touch controls.
  - Unplug the lamp from the power outlet for 30 seconds, then plug it back in to reset the controls.

If the problem persists after trying these solutions, please contact Nekteck customer support.

8. Specifications

Feature	Specification
Model Number	PL6
Wattage	10 Watts
Light Source Type	LED
Color Temperatures	3000K-6500K (4 modes)
Brightness Levels	5 levels
Control Method	Touch Control
Material	Metal, Plastic
Power Source	Corded Electric
Voltage	120 Volts
Room Type	Living Room, Office, Bedroom

9. Warranty and Customer Support

Nekteck provides an 18-month warranty for this product, which can be extended to two years upon registration. This warranty covers manufacturing defects and ensures your satisfaction with the product.

For warranty claims, technical support, or any questions regarding your Nekteck LED Floor Lamp, please contact our

customer support team. Please have your model number (PL6) and purchase information ready when contacting support.

Contact Information:

- Please refer to the contact details provided on the Nekteck official website or your purchase documentation.

© 2023 Nekteck. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07W131P48

More documents and user manuals: **https://manuals.plus/**