Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Nissan Rogue

2015 Nissan Rogue Owner's Manual

Comprehensive Guide for Your Vehicle

Introduction

This manual provides essential information for the safe and efficient operation, maintenance, and care of your 2015 Nissan Rogue. Familiarize yourself with its contents to ensure a thorough understanding of your vehicle's features and capabilities. Always refer to this manual for detailed instructions and safety warnings.
Note: No specific product images of the 2015 Nissan Rogue vehicle or official product videos were provided in the input data. The image below is of the owner's manual cover itself.




Image: Cover of the original 2015 Nissan Rogue Owner's Manual. This document serves as the primary reference for vehicle owners.

Safety Information

Your safety and the safety of your passengers are paramount. This section outlines critical safety precautions and features of your Nissan Rogue.

- **Seat Belts:** Always wear your seat belt and ensure all passengers are properly restrained.
- **Airbags:** Understand the location and function of the airbag system. Do not place objects over airbag deployment areas.
- **Child Safety:** Use appropriate child restraint systems for children as required by law and vehicle recommendations.
- **Driving Safely:** Adhere to all traffic laws, avoid distractions, and never drive under the influence of alcohol or drugs.
- **Warning Lights:** Pay attention to dashboard warning lights and indicators. Consult a qualified technician if a critical warning light illuminates.

Setup and Initial Adjustments

Before driving, perform these initial setup steps for comfort and safety.

1. **Seat Adjustment:** Adjust the driver's seat for optimal pedal reach and steering wheel access. Ensure a comfortable and safe driving position.
2. **Steering Wheel Adjustment:** Adjust the steering wheel tilt and telescopic position for comfort and to maintain proper distance from the airbag.
3. **Mirror Adjustment:** Adjust the rearview mirror and side mirrors to provide clear visibility of the rear and sides of the vehicle.
4. **Climate Control:** Familiarize yourself with the climate control system for heating, ventilation, and air conditioning.
5. **Infotainment System:** Set up radio presets, connect Bluetooth devices, and configure navigation (if equipped).

Operating Your Vehicle

This section covers the basic operation of your 2015 Nissan Rogue.

Starting the Engine

- **Key Ignition:** Insert the key into the ignition switch. For push-button start models, ensure the Intelligent Key is inside the vehicle.
- **Brake Pedal:** Press the brake pedal firmly.
- **Start:** Turn the key to the "START" position or press the "ENGINE START/STOP" button. Release once the engine starts.

Driving

- **Transmission:** Shift the gear selector to "D" (Drive) for forward motion or "R" (Reverse) for backing up.
- **Parking Brake:** Release the parking brake before driving.
- **Steering:** Use smooth and controlled steering inputs.
- **Braking:** Apply the brake pedal smoothly to slow down or stop.

Advanced Features (if equipped)

- **All-Wheel Drive (AWD):** Understand how to engage and disengage AWD lock mode for challenging conditions.
- **Cruise Control:** Learn to set, adjust, and cancel cruise control for highway driving.
- **NissanConnect:** Explore the features of your infotainment system, including navigation, audio, and connectivity options.

Maintenance

Regular maintenance is crucial for the longevity and performance of your Nissan Rogue. Refer to your maintenance schedule for specific intervals.

- **Oil and Filter Change:** Check engine oil level regularly and change oil and filter according to the recommended schedule.
- **Tire Pressure and Rotation:** Maintain correct tire pressure and rotate tires at recommended intervals for even wear.
- **Fluid Levels:** Regularly check coolant, brake fluid, power steering fluid (if applicable), and windshield washer fluid levels.
- **Brake Inspection:** Have brakes inspected periodically for wear on pads, rotors, and fluid condition.
- **Battery Care:** Inspect battery terminals for corrosion and ensure proper charge, especially in extreme temperatures.
- **Wiper Blades:** Replace wiper blades when they no longer clear the windshield effectively.

Troubleshooting Common Issues

This section addresses common issues you might encounter with your vehicle.

Engine Won't Start

- **Battery:** Check for a dead battery (dim lights, no cranking sound). Jump-start if necessary.
- **Fuel:** Ensure there is sufficient fuel in the tank.
- **Immobilizer:** Check if the security indicator light is blinking rapidly, indicating an immobilizer issue.

Warning Light On

- **Check Engine Light:** Can indicate various issues from a loose gas cap to engine problems. Have it diagnosed by a professional.
- **Oil Pressure Light:** Stop the vehicle immediately and check oil level. Do not drive with low oil pressure.
- **Brake Warning Light:** May indicate low brake fluid or a problem with the braking system. Have it inspected immediately.

Flat Tire

- **Safety:** Pull over to a safe location away from traffic.
- **Spare Tire:** Refer to your vehicle's manual for instructions on how to access and install the spare tire.
- **Tire Repair Kit:** Some models may come with a tire repair kit instead of a spare. Follow its instructions.

Specifications (General)

Below are general specifications for the 2015 Nissan Rogue. Specific details may vary by trim level and options.

Feature	Detail
Engine Type	2.5L DOHC 16-valve 4-cylinder
Horsepower	Approx. 170 hp
Transmission	Xtronic CVT® (Continuously Variable Transmission)
Drive Type	Front-Wheel Drive (FWD) or Intelligent All-Wheel Drive (AWD)
Fuel Tank Capacity	Approx. 14.5 gallons (55 liters)
Seating Capacity	5 passengers (optional 7-passenger in some trims)

Warranty and Support

Your 2015 Nissan Rogue comes with a manufacturer's warranty. For specific details regarding coverage, terms, and conditions, please refer to your official warranty booklet provided with the vehicle or contact an authorized Nissan dealership.

- **Warranty Coverage:** Typically includes basic limited warranty, powertrain limited warranty, and corrosion perforation limited warranty.
- **Roadside Assistance:** Many new vehicles include a period of roadside assistance. Check your warranty

documents for details.

- **Authorized Service:** For all service and warranty claims, it is recommended to visit an authorized Nissan service center.
- **Contact Nissan:** For further assistance, visit the official Nissan website or contact their customer service line.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07W15Q577

More documents and user manuals: **https://manuals.plus/**