



[Manuals.plus](#) /
› [CubicFun](#) /
› CubicFun Large Saint Paul's Cathedral 3D Puzzle Instruction Manual

CubicFun MC270h

CubicFun Large Saint Paul's Cathedral 3D Puzzle Instruction Manual

Model: MC270h | Brand: CubicFun

Sections

Package

Introduction Contents Setup Assembly Maintenance Troubleshooting Specifications Support

INTRODUCTION

Thank you for choosing the CubicFun Large Saint Paul's Cathedral 3D Puzzle. This instruction manual provides detailed guidance for assembling your 643-piece architectural model. Designed for enthusiasts aged 14 and up, this puzzle offers a challenging and rewarding experience, culminating in a stunning replica with a unique half-opening structure to reveal intricate interior details.



Image: The fully assembled CubicFun Large Saint Paul's Cathedral 3D Puzzle, showcasing its detailed exterior and the half-opening design.

PACKAGE CONTENTS

Before beginning assembly, please verify that all components are present and undamaged. Your package should contain:

- 643 puzzle pieces, pre-cut and numbered on sheets.
- Detailed instruction booklet with step-by-step diagrams.



Image: The product packaging and the various sheets containing the pre-cut puzzle pieces.

SETUP AND PREPARATION

1. **Unpack Components:** Carefully remove all puzzle sheets and the instruction booklet from the box.
2. **Organize Pieces:** Identify the numbered sheets. It is recommended to punch out pieces as needed during assembly to prevent loss or mix-up.
3. **Work Area:** Ensure you have a clean, flat, and well-lit work surface large enough to accommodate the assembled model (Finished Size: 18.59 inches L x 11.18 inches W x 11.74 inches H).
4. **No Tools or Glue Required:** This 3D puzzle is designed for interlocking assembly without the need for additional tools or adhesives.

ASSEMBLY INSTRUCTIONS

Follow the step-by-step diagrams provided in the instruction booklet. Each piece is numbered, and the assembly process


is designed to be intuitive. Refer to the diagrams for correct piece orientation and connection points.

Key Assembly Features:

- **Half-Opening Structure:** The unique design allows the cathedral to open, revealing the detailed interior. Pay close attention to the instructions for these specific sections to ensure proper functionality.
- **Detailed Reproduction:** The puzzle features inside and outside double-color manuscripts, accurately reproducing the millennium church with fine details.



Image: The assembled puzzle demonstrating its removable design, allowing for exploration of the interior structure.



INSIDE DETAILS

SAINT PAUL'S CATHEDRAL




Image: A close-up view highlighting the intricate interior details of the puzzle, including painted ceilings and architectural elements.



EXTERNAL DETAILS

SAINT PAUL'S CATHEDRAL



Image: A close-up view showcasing the detailed exterior architecture of the puzzle, including columns and facade elements.

Assembly Video Guide:

For visual assistance during assembly, please refer to the official product video:

Your browser does not support the video tag.

Video: An official CubicFun video demonstrating the assembly process and key features of the St. Paul's Cathedral 3D Puzzle.

CARE AND MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to gently dust the assembled model. Avoid using liquids or abrasive cleaners, as they may damage the printed surfaces.
- **Storage:** Store the puzzle in a dry environment away from direct sunlight and extreme temperatures to prevent warping or fading.
- **Handling:** Handle the assembled model with care, especially when utilizing the half-opening feature, to avoid

damaging the interlocking pieces.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Pieces do not fit together.	Incorrect piece orientation or sequence.	Double-check the piece numbers and the corresponding diagrams in the instruction booklet. Ensure pieces are oriented correctly.
Assembled structure is unstable.	Pieces not fully interlocked.	Gently press on all connections to ensure each piece is securely seated. Review previous steps for any loose connections.
Missing pieces.	Pieces may be overlooked or accidentally discarded.	Carefully check all puzzle sheets and the work area. If a piece is genuinely missing, contact CubicFun customer support.

SPECIFICATIONS

- Model:** MC270h
- Brand:** CubicFun
- Number of Pieces:** 643
- Finished Dimensions (L x W x H):** 18.59 x 11.18 x 11.74 inches (47.2 x 28.4 x 29.8 cm)
- Item Weight:** 3.47 pounds
- Recommended Age:** 14 years and up
- Estimated Assembly Time:** 16+ hours
- Material:** EPS Foam Board and Paper
- Country of Origin:** China

WARRANTY AND SUPPORT

CubicFun is committed to providing outstanding customer satisfaction. If you have any concerns, inquiries, or require assistance with your puzzle, please contact our dedicated support team.

For further information or to contact support, please visit the official CubicFun store:[CubicFun Store on Amazon](#).

Please retain your purchase receipt as proof of purchase for any warranty claims or support requests.