

[Manuals.plus](#) /

› [COYOTE OUTDOOR LIVING](#) /

› COYOTE OUTDOOR LIVING Portable Propane Gas Grill, 25 Inch Portable Grill with Ceramic Heat Control Grid - C1PORTLP User Manual

COYOTE OUTDOOR LIVING C1PORTLP

COYOTE OUTDOOR LIVING Portable Propane Gas Grill

MODEL C1PORTLP USER MANUAL

Introduction

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your COYOTE OUTDOOR LIVING Portable Propane Gas Grill, Model C1PORTLP. Please read this manual thoroughly before assembly, operation, or maintenance to ensure proper use and to prevent injury or damage.



Figure 1: COYOTE OUTDOOR LIVING Portable Propane Gas Grill, Model C1PORTLP, with lid closed.

Safety Information

WARNING: For outdoor use only. Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.

DANGER: If you smell gas:

1. Shut off gas to the appliance.
2. Extinguish any open flame.
3. Open lid.
4. If odor continues, keep away from the appliance and immediately call your gas supplier or fire department.

Always ensure adequate ventilation when operating the grill. Keep children and pets away from the grill during operation. Always use heat-resistant gloves when handling hot surfaces.

Setup and Assembly

The C1PORTLP grill requires some assembly. Please follow these steps carefully.

1. **Unpacking:** Carefully remove all components from the packaging. Verify all parts are present according to the packing list.
2. **Placement:** Position the grill on a stable, level, non-combustible surface. Ensure there is adequate clearance from combustible materials (minimum 24 inches from sides and back).
3. **Propane Connection:** The grill is designed for use with either a 20lb propane tank or a small propane canister. An adapter hose is included for connecting to a 20lb tank.
 - Connect the adapter hose to the grill's gas inlet.
 - Connect the other end of the adapter hose to your 20lb propane tank.
 - Alternatively, connect a small propane canister directly to the grill's gas inlet if not using the adapter hose.
 - Ensure all connections are tight before opening the propane supply.
4. **Leak Test:** Before first use and after every tank change, perform a leak test. Apply a soapy water solution to all gas connections. Bubbles indicate a leak. Tighten connections or replace parts as necessary. Do not use the grill if a leak is detected.

Propane Powered: Can Be Used With Either a 20lb Propane Tank or a Small Propane Canister

(Adapter Included)



Figure 2: The grill can be powered by a 20lb propane tank using the included adapter, or a small propane canister.

Operating Instructions

Your Coyote Portable Gas Grill features a single Infinity Burner providing up to 20,000 BTUs of cooking power and a maximum temperature of 700°F. The Ceramic Heat Control Grid ensures reliable and even heat distribution.



Figure 3: The grill with its lid open, revealing the 200 sq inch Signature Grate Cooking Surface and Ceramic Heat Control Grid.

1. **Pre-heating:** Open the grill lid. Turn the control knob to the HIGH position. Press and hold the igniter button until the burner lights. Once lit, close the lid and allow the grill to pre-heat for 5-10 minutes. The integrated thermometer on the front panel will indicate the internal temperature.
2. **Temperature Control:** Adjust the control knob to achieve your desired cooking temperature. The Ceramic Heat Control Grid helps maintain consistent heat across the 200 sq inch Signature Grate Cooking Surface.
3. **Cooking:** Place food on the cooking grates. Monitor cooking progress and adjust heat as needed.
4. **Shutting Down:** When finished cooking, turn the control knob to the OFF position. Close the propane tank valve. Allow the grill to cool completely before cleaning or moving.



Figure 4: The 200 sq inch Signature Grate Cooking Surface provides ample space for grilling various foods.

Maintenance and Cleaning

Regular cleaning and maintenance will extend the life of your grill and ensure optimal performance. The non-stick Teflon coating on the cooking surface facilitates easier cleaning.

- **After Each Use:** Once the grill has cooled, brush off any food residue from the cooking grates. The non-stick surface makes this process straightforward.
- **Deep Cleaning:** Periodically, clean the cooking grates with warm, soapy water. The stainless steel exterior can be wiped down with a damp cloth and a mild detergent. Avoid abrasive cleaners or steel wool, which can scratch the surface.
- **Grease Tray:** Empty and clean the grease tray regularly to prevent flare-ups and maintain hygiene.
- **Storage:** Store the grill in a dry, protected area when not in use. If storing outdoors, use a grill cover to protect it from the elements.

Troubleshooting

Problem	Possible Cause	Solution
Burner does not light	No gas flow; Clogged burner ports; Faulty igniter	Check propane tank connection and level; Clean burner ports; Contact customer support for igniter issues.
Low heat output	Low propane level; Regulator issue; Clogged burner	Replace or refill propane tank; Reset regulator (refer to propane tank instructions); Clean burner.
Uneven heating	Clogged burner ports; Improper placement of Ceramic Heat Control Grid	Clean burner ports; Ensure Ceramic Heat Control Grid is correctly seated.

If you encounter issues not listed here or if solutions do not resolve the problem, please contact COYOTE OUTDOOR LIVING customer support.

Specifications

Feature	Detail
Brand	COYOTE OUTDOOR LIVING
Model Name	C1PORTLP
Product Dimensions	16"D x 25"W x 13.5"H
Item Weight	20 Pounds
Fuel Type	Gas (Propane)
Material	Stainless Steel, Ceramic
Main Burner Count	1 (Infinity Burner)
Max BTU Output	20,000 BTUs
Max Temperature	700°F
Cooking Surface Area	200 Square Inches
Special Feature	Portable
Included Components	Adapter Hose
Assembly Required	Yes

Manufacturer Warranty Information

COYOTE OUTDOOR LIVING provides the following limited warranty for the C1PORTLP Portable Propane Gas Grill:

- **Limited Lifetime:** Stainless Steel Frame/Housing
- **5 Year Limited:** Cooking Grids (no rust or burn through)
- **2 Years Limited:** Flavorizer Bars (no rust or burn through)
- **2 Years Limited:** Electric/Plastic Components

- **1 Year Limited:** Ignition Systems/Valves

For detailed warranty terms and conditions, please refer to the official COYOTE OUTDOOR LIVING warranty documentation or contact their customer support.

Manufacturer Warranty Information

5 Year Limited Cooking Grids (No Rust or Burn Through)
2 Years Limited Flavorizer Bars (No Rust or Burn Through)
2 Years Limited Electric/Plastic Components
1 Year Limited Ignition Systems/Valves
Limited Lifetime Stainless Steel Frame/Housing

Figure 5: Summary of Manufacturer Warranty Information for the grill.

Customer Support

For technical assistance, parts, or warranty claims, please contact COYOTE OUTDOOR LIVING directly. Refer to their official website or product packaging for the most current contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07W8M3GFW>

More documents and user manuals: <https://manuals.plus/>