

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [LOVCUBE](#) /

› [LOVCUBE 8-Inch Digital Photo Frame L08X User Manual](#)

LOVCUBE L08X

LOVCUBE 8-Inch Digital Photo Frame L08X User Manual

Model: L08X (WH00002D)

1. INTRODUCTION

Thank you for choosing the LOVCUBE 8-Inch Digital Photo Frame L08X. This manual provides essential information for setting up, operating, and maintaining your digital photo frame. Please read it thoroughly before use to ensure optimal performance and longevity of your device.

1.1 Package Contents

Verify that all items listed below are included in your package:

- LOVCUBE 8-Inch Digital Photo Frame
- Remote Control
- Power Adapter
- User Manual (this document)

PERFECT GIFT

It is a perfect gift for the elderly who are not good at using smart phones to stay connected with the younger generation.
Enhance the connection of the family members that living in different places



Image 1.1: The LOVCUBE 8-Inch Digital Photo Frame L08X and its included accessories: the frame, remote control, power adapter, and user manual.

2. PRODUCT OVERVIEW

Familiarize yourself with the components and controls of your digital photo frame.

2.1 Front View



Image 2.1: Front view of the LOVCUBE 8-Inch Digital Photo Frame L08X, showcasing its 8-inch display.

2.2 Rear View and Ports

The rear of the frame features various ports and control buttons for media input and device operation.



Image 2.2: Rear view of the digital photo frame, highlighting the SD/SDHC Card Slot, Headphone/Speaker Port, and USB Port. These ports allow for external media connection and audio output.

- **SD/SDHC Card Slot:** Insert compatible SD or SDHC memory cards for photo, video, and music playback.
- **Headphone/Speaker Port:** Connect headphones or external speakers for private listening or enhanced audio.
- **USB Port:** Connect USB flash drives for media playback.
- **Power Input:** Connect the provided power adapter.
- **Control Buttons:** Navigate menus and control playback directly on the frame.

3. SETUP

Follow these steps to set up your LOVCUBE Digital Photo Frame.

3.1 Power Connection

1. Connect the power adapter to the DC IN port on the back of the photo frame.

2. Plug the other end of the power adapter into a standard electrical outlet.
3. The frame will automatically power on or enter standby mode.

3.2 Inserting Media (SD Card / USB Drive)

The frame supports SD/SDHC cards and USB flash drives. Ensure your media contains compatible photo (JPEG), video (MP4, MKV, H.264, MPEG4 up to 1080P), or music (MP3) files.

1. Carefully insert your SD/SDHC card into the SD card slot until it clicks into place.
2. Alternatively, insert your USB flash drive into the USB port.
3. The frame should automatically detect the inserted media and prompt you to select a function (e.g., Photo, Music, Video).

4. OPERATING INSTRUCTIONS

This section details how to use the various functions of your digital photo frame.

4.1 Basic Navigation

Use the remote control or the control buttons on the back of the frame to navigate through menus and select options.

- **Arrow Buttons:** Navigate up, down, left, or right.
- **OK/Enter Button:** Confirm a selection.
- **Exit/Return Button:** Go back to the previous menu or exit current function.

4.2 Photo Slideshow

1. From the main menu, select "Photo".
2. Choose the desired storage device (SD card or USB drive).
3. The frame will begin displaying photos in a slideshow format.
4. Adjust slideshow settings (speed, transition effects) in the "Settings" menu.

4.3 Video Playback

1. From the main menu, select "Video".
2. Choose the desired storage device.
3. Select a video file to begin playback.
4. Use the remote control for playback functions (play, pause, fast forward, rewind).

4.4 Music Playback

1. From the main menu, select "Music".
2. Choose the desired storage device.
3. Select an audio file to begin playback.
4. Audio will play through the built-in speaker or connected headphones/external speakers.

4.5 Clock and Calendar Functions

The frame includes built-in clock and calendar displays.




Image 4.1: The digital photo frame displaying the current time and calendar, a useful feature for daily reference.

- Access these functions from the main menu.
- Set the date and time in the "Settings" menu.

4.6 Motion Sensor

The integrated motion sensor can automatically turn the frame on or off to save energy.

- Enable or disable the motion sensor in the "Settings" menu.
- Adjust sensitivity or detection range if available in settings.

5. MAINTENANCE

Proper care ensures the longevity and optimal performance of your digital photo frame.

5.1 Cleaning

- Always unplug the device before cleaning.
- Use a soft, dry, lint-free cloth to gently wipe the screen and frame.
- For stubborn marks on the screen, lightly dampen the cloth with water or a screen-cleaning solution (avoid harsh chemicals).
- Do not spray liquids directly onto the frame.

5.2 Storage

- Store the frame in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, remove any inserted memory cards or USB drives.

6. TROUBLESHOOTING

Refer to this section for solutions to common issues you might encounter.

Problem	Possible Cause	Solution
Frame does not power on.	Power adapter not connected or faulty.	Ensure the power adapter is securely connected to the frame and a working electrical outlet. Try a different outlet.
No images/videos displayed.	No media inserted or incompatible file format.	Insert a compatible SD card or USB drive with supported media files (JPEG, MP4, MKV). Check file formats.
Remote control not working.	Battery depleted or obstructed signal.	Replace the CR2 battery in the remote control. Ensure there are no obstructions between the remote and the frame's sensor.
Images appear distorted or low quality.	Low resolution source images.	Use higher resolution images for best display quality. The frame's native resolution is 1024x768.

7. SPECIFICATIONS

Technical specifications for the LOVCUBE 8-Inch Digital Photo Frame L08X.

Feature	Detail
Model	L08X (WH00002D)
Screen Size	8 Inches
Display Type	LCD
Resolution	1024x768 (XGA)
Image Aspect Ratio	4:3
Supported Image Formats	JPEG
Supported Video Formats	MP4, MKV (H.264, MPEG4 up to 1080P)
Supported Audio Formats	MP3
Memory Card Support	SD, SDHC
USB Support	USB Flash Drives
Audio Output	Built-in speaker, 3.5mm Headphone Jack

Feature	Detail
Special Features	Motion Sensor, Clock, Calendar, Remote Control
Power Source	Corded Electric
Remote Control Battery	1 x CR2 (required)
Product Dimensions	22.5 x 18.3 x 72 cm
Item Weight	549 g

8. WARRANTY AND SUPPORT

LOVCUBE products are manufactured to high-quality standards. For specific warranty details, please refer to the warranty card included with your purchase or contact LOVCUBE customer support.

For technical assistance or customer service inquiries, please visit the official LOVCUBE website or contact your retailer.

© 2023 LOVCUBE. All rights reserved.

Related Documents - L08X

	<p>Lovcube F10W Wi-Fi Digital Photo Frame User Manual</p> <p>Comprehensive user manual for the Lovcube F10W Wi-Fi Digital Photo Frame, covering setup, features, app instructions, web portal usage, and warranty information.</p>
	<p>Lovcube X10 Wi-Fi Digital Photo Frame User Manual</p> <p>Comprehensive user manual for the Lovcube X10 Wi-Fi Digital Photo Frame, covering setup, features, app usage, and troubleshooting.</p>
	<p>LOVCUBE F20W Wi-Fi Digital Photo Frame User Manual</p> <p>User manual for the LOVCUBE F20W Wi-Fi Digital Photo Frame, covering setup, features, operation, settings, safety, and warranty information.</p>

	<p>LOVCUBE F20W Wi-Fi Digital Photo Frame User Manual</p> <p>This user manual provides comprehensive guidance for the LOVCUBE Wi-Fi Digital Photo Frame, model F20W. Learn how to set up your frame, connect via Wi-Fi and the Frameo app, share photos and videos, navigate features, manage settings, and access support and warranty information.</p>
	<p>LOVCUBE W8 Wi-Fi Digital Photo Frame User Manual</p> <p>User manual for the LOVCUBE W8 Wi-Fi Digital Photo Frame, detailing setup, features, settings, safety guidelines, and warranty information.</p>
	<p>LOVCUBE W10 Frameo Digital Picture Frame User Manual</p> <p>Comprehensive user manual for the LOVCUBE W10 Frameo Digital Picture Frame. Learn how to set up, connect, share photos, manage settings, and utilize features like Wi-Fi connectivity and touchscreen interface.</p>