

[Manuals.plus](#) /

› [Orient](#) /

› Orient Neo 70s Revival Automatic Watch User Manual (Model RA-AA0B02R19B)

Orient RA-AA0B02R19B

Orient Neo 70s Revival Automatic Watch User Manual

Model: RA-AA0B02R19B

INTRODUCTION

This manual provides essential information for the proper use, care, and maintenance of your Orient Neo 70s Revival Automatic Watch. Please read these instructions carefully to ensure optimal performance and longevity of your timepiece. This watch features an automatic mechanical movement with manual winding capability.



SETUP

1. Unboxing and Initial Inspection

Carefully remove the watch from its packaging. Inspect the watch for any visible damage. Ensure all components, including the watch and bracelet, are present.



Image: The Orient watch box, designed for secure storage and presentation of the timepiece.

2. Initial Winding

As an automatic watch, it is powered by the motion of your wrist. However, for initial startup or after a period of inactivity, manual winding is recommended to build up a power reserve.

1. Locate the crown on the side of the watch case.
2. Ensure the crown is in the normal (pushed-in) position.
3. Turn the crown clockwise approximately 30-40 times. This will manually wind the mainspring.
4. The watch should begin to run.

3. Setting Time and Date

1. **Setting the Date:** Pull the crown out to the first click position. Turn the crown counter-clockwise to adjust the date.

Avoid setting the date between 9:00 PM and 3:00 AM, as this can damage the movement.

2. **Setting the Day:** Pull the crown out to the first click position. Turn the crown clockwise to adjust the day.
3. **Setting the Time:** Pull the crown out to the second click position. The second hand will stop. Turn the crown to set the hour and minute hands. To ensure accurate time setting, synchronize with a reliable time source. Push the crown back to the normal position once the time is set.



Image: Close-up view of the watch dial, hands, and crown, illustrating the components used for time and date adjustments.

4. Bracelet Adjustment

The stainless steel bracelet can be adjusted by adding or removing links to achieve a comfortable fit. This procedure typically requires specialized tools and is best performed by a qualified watchmaker or jeweler.



Image: Detail of the stainless steel bracelet clasp, showing the Orient logo and securing mechanism.

OPERATING YOUR WATCH

Automatic Movement

Your Orient Neo 70s Revival watch is equipped with an automatic mechanical movement. This means the watch is powered by the natural motion of your arm. As you wear the watch, an oscillating weight inside the movement rotates, winding the mainspring and storing energy. If the watch is not worn for an extended period, the power reserve will deplete, and the watch will stop. Simply wear it again or manually wind it as described in the "Initial Winding" section to restart it.

Water Resistance (WR 50m)

This watch has a water resistance rating of 50 meters (WR 50m). This rating indicates that the watch is suitable for short periods of recreational swimming, showering, or washing hands. It is **not** suitable for diving, snorkeling, or prolonged water immersion. Always ensure the crown is fully pushed in before any contact with water.

- Do not operate the crown while the watch is wet or submerged.
- Avoid exposing the watch to sudden temperature changes, which can compromise water resistance.
- Water resistance is not a permanent condition and may decrease over time due to wear and tear or impact.



Image: The case back of the Orient watch, displaying the "WATER RESISTANT 5bar" marking, indicating its water resistance level.

MAINTENANCE

Cleaning

To maintain the appearance of your watch, wipe the case and bracelet regularly with a soft, dry cloth. For stainless steel, a slightly damp cloth can be used, followed by immediate drying. Avoid using harsh chemicals, solvents, or abrasive cleaners.

Storage

When not wearing your watch, store it in a cool, dry place away from direct sunlight, extreme temperatures, and strong magnetic fields. The original watch box is ideal for storage.

Regular Servicing

Mechanical watches benefit from periodic servicing, typically every 3-5 years, to ensure optimal performance and accuracy. This involves cleaning, lubricating, and adjusting the movement. Consult an authorized Orient service center or a reputable watchmaker for servicing.

TROUBLESHOOTING

- **Watch Not Running:** If the watch has stopped, it likely needs to be wound. Manually wind the watch by turning the crown clockwise 30-40 times while it is in the normal position. If it still does not start, ensure it has not been exposed to a strong magnetic field.
- **Inaccurate Time:** Minor variations in accuracy are normal for mechanical watches. However, if the watch is

consistently gaining or losing significant time, it may require adjustment or servicing. Ensure the watch has sufficient power reserve.

- **Date/Day Not Changing:** Ensure the time is set correctly, passing midnight for the date/day change mechanism to engage. Avoid setting the date/day between 9:00 PM and 3:00 AM. If the issue persists, professional inspection may be needed.
- **Condensation Under Crystal:** If condensation appears under the crystal, it indicates a breach in water resistance. Immediately take the watch to a service center to prevent further damage to the movement.

SPECIFICATIONS

Model Number	RA-AA0B02R19B
Movement Type	Automatic, Manual Winding Mechanical
Case Material	Stainless Steel
Band Material	Stainless Steel
Crystal Type	Mineral
Water Resistance	50 Meters (WR 50m / 5 Bar)
Case Diameter	42 Millimeters
Case Thickness	13 Millimeters
Band Length	19 Centimeters
Dial Color	Bordeaux
Additional Features	Luminescence, Manual winding, Screw Back

WARRANTY AND SUPPORT

Manufacturer's Warranty

Your Orient Neo 70s Revival Automatic Watch is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms, conditions, and duration. Keep your proof of purchase for warranty claims.

Customer Support

For technical assistance, service, or warranty inquiries, please contact Orient customer support or visit their official website. Contact information can typically be found in the warranty booklet or on the brand's official website.

Note: Unauthorized repairs or modifications may void your warranty.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question