

[Manuals.plus](#) /

› [LITFAD](#) /

› LITFAD Feather and Crystal Drum Chandelier Instruction Manual

LITFAD B07WCV3BJR

LITFAD Feather and Crystal Drum Chandelier Instruction Manual

Model: B07WCV3BJR

INTRODUCTION

This manual provides detailed instructions for the safe installation, operation, and maintenance of your LITFAD Feather and Crystal Drum Chandelier. Please read this manual thoroughly before installation and retain it for future reference. This chandelier is designed for indoor lighting in various rooms such as bedrooms, living rooms, dining rooms, and study areas.



Image 1: The LITFAD Feather and Crystal Drum Chandelier, showcasing its design and size in a typical room setting.

SAFETY INFORMATION

Important Safety Instructions:

- **Professional Installation Recommended:** It is strongly suggested that installation be performed by a licensed electrician to ensure safety and proper functionality.
- **Secure Mounting:** For safe and secure installation, ensure that the electrical box to which this fixture will be mounted is properly attached to a structural member of the building.
- **Wiring Precautions:** All wires are connected. When unpacking, exercise caution not to pull on wires, as a poor connection may result.
- **Power Disconnection:** Do not connect electricity until the fixture is fully assembled.
- **Bulb Replacement Safety:** To reduce the risk of fire, electrical shock, or personal injury, always turn off and unplug the fixture and allow it to cool completely prior to replacing light bulbs.
- **Avoid Direct Contact:** Do not touch the bulb when the fixture is turned on or look directly at a lit bulb. Keep flammable materials away from a lit bulb.

PACKAGE CONTENTS

Before beginning assembly, verify that all parts are present and undamaged. If any part is missing or damaged, do not attempt to assemble or install the fixture.

- Chandelier Frame with Feather Shade
- Crystal Pendants and Chains
- Mounting Hardware (Canopy, Mounting Plate, Screws, Wire Nuts)
- Adjustable Chain/Cord
- User Manual

Note: Light bulbs are not included and must be purchased separately.

SETUP AND INSTALLATION

Follow these steps carefully for proper installation. It is recommended to have two people for installation.

1. **Turn Off Power:** Before starting, ensure the power supply to the installation area is turned off at the circuit breaker.
2. **Prepare Mounting:** Securely attach the mounting plate to the electrical junction box in the ceiling. Ensure the junction box is properly supported by a structural member of the building.
3. **Adjust Hanging Height:** The chain/cord length is adjustable up to 31.5 inches (80 cm). Determine the desired hanging height for your chandelier and adjust the chain/cord accordingly.
4. **Wire Connections:** Connect the chandelier's wires to the household electrical wires according to local electrical codes. Typically, connect the black wire from the fixture to the black (live) wire from the ceiling, the white wire from the fixture to the white (neutral) wire from the ceiling, and the ground wire to the ground wire. Use appropriate wire nuts to secure connections.
5. **Secure Canopy:** Carefully lift the chandelier and secure the canopy to the mounting plate, ensuring all wires are tucked safely inside.
6. **Attach Crystal Pendants:** Once the main fixture is securely mounted, carefully attach the crystal pendants to the designated hooks on the chandelier frame. Refer to the provided diagrams for correct placement.
7. **Install Bulbs:** Insert four E14 base bulbs (not included) into the sockets. Do not exceed the maximum wattage specified in the specifications.
8. **Restore Power:** Once installation is complete and all connections are secure, restore power at the circuit breaker.



Image 2: Dimensional diagram of the chandelier, illustrating key measurements for installation planning.



Image 3: Detail of the crystal pendants, which are attached during the final assembly steps.

OPERATING INSTRUCTIONS

This chandelier operates like a standard light fixture. Once properly installed and powered, it can be controlled via a wall switch (not included) connected to its electrical circuit.

- **Turning On/Off:** Use the connected wall switch to turn the chandelier on or off.
- **Bulb Type:** This fixture is compatible with LED, CFL, or Incandescent bulbs with an E14 base.

- **Number of Lights:** The chandelier requires 4 bulbs.
- **Voltage:** Designed for AC110-120V electrical systems.



Image 4: The chandelier in operation, demonstrating its lighting effect.

MAINTENANCE

Regular maintenance ensures the longevity and appearance of your chandelier.

- **Cleaning:**
 - Before cleaning, always turn off the power and allow the fixture to cool.
 - For the feather shade, gently dust with a soft, dry cloth or a feather duster. Avoid using water or harsh cleaning agents.
 - For crystal components, wipe with a soft, damp cloth. A mild glass cleaner can be used sparingly if needed, applied to the cloth first, not directly to the crystals.
 - Do not use abrasive cleaners or solvents on any part of the fixture.
- **Bulb Replacement:**
 - Ensure power is off and the bulb is cool before attempting replacement.
 - Unscrew the old bulb and screw in a new E14 base bulb.
 - Refer to the specifications for compatible bulb types and maximum wattage.



Image 5: Detail of the feather material, highlighting the texture for cleaning reference.

TROUBLESHOOTING

If you encounter issues with your chandelier, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture. Loose wire connection. Faulty bulb.	Check circuit breaker and wall switch. Ensure all wire connections are secure (power off first). Replace bulb with a new one.
Lights flicker.	Loose bulb. Incorrect bulb type. Loose wire connection.	Tighten bulbs. Ensure bulbs are E14 base and compatible. Check wire connections (power off first).
Chandelier hangs unevenly.	Improper mounting. Uneven weight distribution.	Re-check mounting plate and canopy installation. Ensure all crystal pendants are evenly distributed.

If the problem persists after attempting these solutions, please contact customer support.

SPECIFICATIONS

Brand	LITFAD
Model	B07WCV3BJR
Category	Pendant Light / Chandelier
Style	Modern / Creative
Fixture Width	16 inches (40 cm)
Fixture Height	10 inches (25 cm)
Chain/Cord Length	31.5 inches (80 cm) - Adjustable
Material	Feather, Crystal, Metal
Color	White

Bulb Type	LED/CFL/Incandescent
Bulb Base	E14
Number of Lights	4
Bulbs Included	No
Voltage	AC110-120V
Indoor/Outdoor Usage	Indoor
Item Weight	7.7 pounds (3.5 KG)

WARRANTY INFORMATION

This LITFAD chandelier comes with a **2-year warranty** from the date of purchase. This warranty covers manufacturing defects and material flaws under normal use. It does not cover damage caused by improper installation, misuse, accidents, or unauthorized modifications. Please retain your proof of purchase for warranty claims.

CUSTOMER SUPPORT

For any questions regarding your LITFAD Feather and Crystal Drum Chandelier, including installation assistance, troubleshooting, or warranty inquiries, please do not hesitate to contact our customer service team. We are committed to providing assistance. Please refer to the retailer's website or your purchase documentation for specific contact methods.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question