

VOYEE XB-01



VOYEE PC Controller Instruction Manual

MODEL: XB-01

1. Introduction

Thank you for choosing the VOYEE PC Controller, Model XB-01. This wired controller is designed to provide an enhanced gaming experience on Microsoft Xbox 360, Xbox 360 Slim, and PC systems running Windows 11/10/8.1/8/7. Featuring an upgraded joystick, double shock vibration feedback, and an ergonomic design, it ensures responsive control and comfortable extended play sessions. Please read this manual carefully to ensure proper setup and operation.



Image: Front view of the VOYEE PC Controller, Black.

2. Product Features

- **Wide Compatibility:** Compatible with Microsoft Xbox 360 & Slim, and PC (Windows 11/10/8.1/8/7).
- **Enhanced Game Controller:** Features new left and right trigger buttons, and more sensitive joysticks and buttons for quick, delay-free responses.
- **Astonishing Gaming Experience:** Provides rumble control with automatic vibration feedback based on game events, enhancing immersion.
- **Ergonomic Design:** Grips are contoured to fit comfortably in your hands for prolonged gaming.
- **Long Cable:** Equipped with a 7.2ft (2.2m) cord for greater flexibility and range.

Wide Compatibility

Compatible with Microsoft Xb 360 and Slim
Also for Windows 10/8/7



X360



360 Slim



Windows 10/8/7



Image: VOYEE PC Controller highlighting compatibility with Xbox 360, Xbox 360 Slim, and Windows PCs.

3 Levels of Rumble

Provide a more realistic and better gameing experience



Image: VOYEE PC Controller illustrating three levels of rumble intensity: Weak (35%), Moderate (65%), and Strong (95%).

3. Setup

The VOYEE PC Controller is designed for plug-and-play functionality, requiring no additional drivers for most compatible systems.

1. **For Xbox 360/Xbox 360 Slim:** Simply plug the USB connector of the controller into an available USB port on your Xbox 360 console. The console will automatically detect the controller.
2. **For PC (Windows 11/10/8.1/8/7):** Plug the USB connector of the controller into an available USB port on your computer. Your operating system should automatically install the necessary drivers. Once installed, the controller will be ready for use in compatible games.

Note: This controller is not recommended for FPS (First-Person Shooter) games due to specific input characteristics.



Image: The VOYEE PC Controller shown alongside its retail packaging and connected USB cable, illustrating its wired nature.

4. Operating Instructions

Familiarize yourself with the controller's layout and functions for optimal gaming performance.

PRESENTATION OF KEY



Image: Detailed diagram of the VOYEE PC Controller, labeling all buttons and joysticks including RB/LB, RT/LT, Left/Right Joysticks, D-pad, Function Key/Start, Back, and Return buttons.

- **Analog Joysticks:** Use the Left and Right Joysticks for precise 360-degree movement and camera control in games.
- **D-pad:** The directional pad provides accurate input for menu navigation and specific in-game actions.
- **Action Buttons (A, B, X, Y):** These colored buttons correspond to various in-game actions as defined by the game.
- **Shoulder Buttons (LB, RB) & Triggers (LT, RT):** Located on the top of the controller, these are typically used for firing, aiming, or other quick actions.
- **Start & Back Buttons:** Used for pausing games, accessing menus, or specific in-game functions.
- **Function Key (VOYEE Logo Button):** This button typically functions as the 'Guide' or 'Home' button, opening system menus on Xbox 360 or the Game Bar/Steam Overlay on PC.
- **Vibration Feedback:** The controller features dual vibration motors that provide tactile feedback during gameplay, such as impacts, explosions, or other in-game events. This feature is automatically activated by compatible games.

5. Maintenance

Proper care and maintenance will extend the lifespan of your VOYEE PC Controller.

- **Cleaning:** Use a soft, dry cloth to wipe down the controller. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the controller in a cool, dry place away from direct sunlight and extreme temperatures. Avoid tangling the cable.
- **Handling:** Do not drop the controller or subject it to strong impacts. Avoid pulling the cable forcefully when disconnecting.

6. Troubleshooting

If you encounter issues with your VOYEE PC Controller, please refer to the following common solutions:

1. **Controller Not Recognized:**

- Ensure the USB cable is securely plugged into both the controller and the console/PC.
- Try plugging the controller into a different USB port.
- Restart your console or PC.
- On PC, check Device Manager to see if the controller is listed and if there are any driver issues.

2. **No Vibration Feedback:**

- Verify that the game you are playing supports vibration feedback.
- Check in-game settings to ensure vibration is enabled.
- Ensure the controller is properly connected.

3. **Buttons/Joysticks Unresponsive or Inaccurate:**

- Ensure the controller is clean and free of debris around the buttons and joysticks.
- Some users have reported slight dead zones or inaccuracies with analog sticks in certain directions. This may be a characteristic of the controller and might affect performance in games requiring very precise analog input (e.g., racing games, some FPS titles).
- Test the controller on another game or system to determine if the issue is specific to one application.

4. **Cable Damage:**

- Inspect the cable for any visible signs of damage, fraying, or kinks. A damaged cable can lead to intermittent connectivity or complete failure.

If these steps do not resolve your issue, please contact VOYEE Customer Support.

7. Specifications

Feature	Detail
Model Number	XB-01
Compatibility	Microsoft Xbox 360, Xbox 360 Slim, PC (Windows 11/10/8.1/8/7)
Connectivity	Wired USB
Cable Length	7.2 feet (approx. 2.2 meters)
Dimensions	6.69 x 4.33 x 2.36 inches (17 x 11 x 6 cm)

Weight	9.2 ounces (approx. 260 grams)
Color	Black
Manufacturer	VOYEE

8. Warranty and Support





VOYEE stands behind the quality of its products. Your VOYEE PC Controller comes with:

- **45 Days Money Back Guarantee:** If you are not satisfied, you may return the product within 45 days for a full refund.
- **365 Days Guarantee Against Quality Defects:** VOYEE provides a one-year warranty covering manufacturing defects from the date of purchase.
- **24 Hours Friendly Customer Support:** For any inquiries or assistance, please contact VOYEE customer support.

For more information or to contact support, please visit the official [VOYEE Store on Amazon](#).

© 2025 VOYEE. All rights reserved.

Related Documents - XB-01

	<p>VOYEE S03 Wireless Controller Instruction Manual for Nintendo Switch, PC, and Android</p> <p>Comprehensive instruction manual for the VOYEE S03 Wireless Controller, detailing features, connection modes for Nintendo Switch, PC, and Android, adjustable vibration, TURBO function, programmable buttons, charging, and troubleshooting.</p>
	<p>VOYEE Wireless Controller User Manual and Setup Guide</p> <p>Comprehensive user manual for the VOYEE Wireless Controller, detailing setup, connection modes (PC, Android, iOS, Switch), advanced features like M1/M2 key mapping, LED adjustments, vibration control, and TURBO function. Includes safety information and troubleshooting tips for optimal gaming experience.</p>
	<p>VOYEE N-S Wireless Controllers 503 User Manual</p> <p>Discover the VOYEE N-S Wireless Controllers 503 User Manual. Learn how to connect, charge, and customize your gamepad for Nintendo Switch, PC, and Android devices. Includes detailed instructions on button mapping, turbo functions, and troubleshooting for an optimized gaming experience.</p>
	<p>Test Verification of Conformity for Wireless Controller X107</p> <p>This document verifies the conformity of the wireless controller model X107, manufactured by Dongguan Chenhao Electronic Technology Co., LTD., with various European safety, health, EMC, and radio standards.</p>



[XB-003 Wireless Controller User Manual for N-Switch and PC](#)

Discover the XB-003 Wireless Controller, compatible with N-Switch Console and Windows PC (360 mode). This user manual provides detailed instructions on connecting, calibrating sensors, charging, and understanding key functions, ensuring an optimal gaming experience with gyroscope axis and dual motor vibration.



[PowerA Fusion Pro Wireless Controller with Lumetra User Manual](#)

Comprehensive user manual for the PowerA Fusion Pro Wireless Controller with Lumetra, covering setup, features, and troubleshooting for Xbox and PC.