

- Manuals.plus /
- › AquaDance /
- › AquaDance High Pressure 6-Setting Brushed Nickel Handheld Shower Head User Manual

AquaDance 7212

AquaDance High Pressure 6-Setting Brushed Nickel Handheld Shower Head User Manual

Model: 7212

- Overview
- Installation
- Operation
- Maintenance
Support
- Troubleshooting
- Specifications
- Warranty &

1. PRODUCT OVERVIEW

The AquaDance High Pressure 6-Setting Handheld Shower Head is engineered to optimize water pressure and flow efficiency. This product has been independently tested to meet US quality and performance standards, offering a versatile and comfortable showering experience.



Figure 1: AquaDance High Pressure 6-Setting Handheld Shower Head in Brushed Nickel, showcasing its design and water flow.

Key Features:

- **Deluxe 6-Setting 3.5" Face Hand Shower:** Functions as both an overhead and handheld shower.
- **High-Power Click Lever Dial:** For easy switching between spray settings.
- **Ergonomic Grip Handle:** Designed for comfortable use.
- **Rub-Clean Jets:** Facilitates easy cleaning and prevents lime buildup.
- **All-Surface Brushed Nickel Finish:** Consistent finish across the shower head and accessories.
- **Angle-Adjustable Overhead Bracket:** Allows for hands-free operation at a desired angle.
- **Extra-Flexible Reinforced 5-Foot Stainless Steel Hose:** Provides extended reach and mobility.

2. INSTALLATION GUIDE

The AquaDance Handheld Shower Head is designed for easy, tool-free connection to any standard shower arm. Follow these steps for a quick setup.



Figure 2: The AquaDance shower head is designed for quick, tool-free installation, featuring a compact, ergonomic, and angle-adjustable design with a heavy-duty stainless steel hose.

Step-by-Step Installation:

1. **Remove Old Shower Head:** Unscrew your existing shower head from the shower arm. You may need pliers if it's too tight, but often it can be removed by hand. Clean any old plumber's tape or residue from the shower arm threads.
2. **Apply Plumber's Tape:** Wrap the included plumber's tape (PTFE tape) clockwise around the threads of your shower arm 3-4 times. This helps create a watertight seal.

3. **Attach Overhead Bracket:** Screw the angle-adjustable overhead bracket onto the shower arm. Hand-tighten until snug. Ensure the crack-resistant nut is securely fastened.
4. **Connect Shower Hose to Bracket:** Insert a washer into one end of the extra-flexible 5-foot stainless steel hose. Screw this end onto the hose outlet of the overhead bracket. Hand-tighten.
5. **Connect Hand Shower to Hose:** Insert another washer into the conical end of the hose. Screw this end onto the handheld shower head. Hand-tighten.
6. **Place Hand Shower:** Insert the handheld shower into the bracket's holder.

Important: Always ensure washers are properly placed between all connections to prevent leaks.

AquaDance

Tool-Free Connection in 3 Easy Steps!

1
CRACK-RESISTANT NUT
BRACKET

Remove old shower head. Screw Bracket onto Shower Arm and hand tighten Crack-resistant Nut.

2
HOSE OUTLET
HOLDER

Screw Hose with washers in place onto Hose outlets.

3

Screw Hand Shower with Washer in place onto conical Hose end, then insert into Bracket's Holder.

Detailed Instructions Inside

BE SURE
to place washers
(included) between
all connections

Plumber's Tape Included

U.S.-Based Customer Service with American Shower Experts to Help You on the Phone

Figure 3: Visual guide for the tool-free connection process, including plumber's tape and washer placement.

Installation Video:

Your browser does not support the video tag.

Video 1: A demonstration of the AquaDance High Pressure 6-Setting Handheld Shower Head, highlighting its features and ease of use.

3. OPERATING INSTRUCTIONS

Your AquaDance Handheld Shower Head features a high-power click lever dial for easy selection of 6 distinct spray settings, allowing you to customize your showering experience.



Figure 4: Illustration of the six distinct spray settings available on the AquaDance shower head, including Power Rain, Hydro-Massage, Power Rinse, Rain/Massage, Rain/Rinse, and Pause Mode.

Spray Settings:

- **Power Rain:** A full, invigorating spray for a classic shower experience.
- **Hydro-Massage:** Concentrated, pulsating streams designed to relieve muscle tension.
- **Power Rinse:** A strong, focused stream for efficient rinsing.
- **Rain/Massage:** A combination of the Power Rain and Hydro-Massage for a balanced experience.
- **Rain/Rinse:** Blends the Power Rain with the Power Rinse for thorough coverage and cleaning.
- **Pause Mode:** A water-saving setting that reduces water flow to a trickle, ideal for lathering or temporary stops without adjusting temperature.

To switch between settings, simply rotate the click lever dial located on the shower head face.

Super-High Pressure!

6 SETTINGS



With Water-Saving
ON/OFF Pause Mode

Figure 5: The shower head demonstrating its super-high pressure capability and the water-saving ON/OFF Pause Mode.



Figure 6: Close-up of the 3-zone spiral dial and anti-clog nozzles, illustrating the click lever for full and mixed modes.

4. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your AquaDance Handheld Shower Head.

Cleaning the Jets:

The shower head features **Rub-Clean Jets** designed for easy cleaning. To remove mineral deposits and prevent lime buildup, simply rub the rubber nozzles with your finger or a soft brush. This should be done periodically, especially in areas with hard water.

General Cleaning:

Clean the exterior of the shower head and hose with a soft cloth and mild soap or a non-abrasive bathroom cleaner. Avoid

harsh chemicals or abrasive scrubbers, as these can damage the brushed nickel finish.

5. TROUBLESHOOTING TIPS

Here are some common issues and their solutions:

Issue: Leaks at Connection Points

- **Solution:** Ensure all connections are hand-tightened securely. Verify that washers are correctly seated in each connection point (between the shower arm and bracket, and between the hose and both the bracket and handheld shower). Re-apply plumber's tape if necessary.

Issue: Hand Shower Does Not Fit in Bracket

- **Solution:** The shower hose has two different ends: one tapered and one with a bolt-head/nut appearance. The **tapered end** connects to the handheld shower wand, allowing it to rest properly in the bracket. The bolt-head end connects to the bottom of the bracket. Ensure the hose is connected with the correct ends to prevent fitting issues.

Issue: Reduced Water Pressure

- **Solution:** Check the rub-clean jets for any mineral buildup and clear them as described in the Maintenance section. Ensure your main water supply pressure is adequate.

6. PRODUCT SPECIFICATIONS

Brand:	AquaDance
Model Number:	7212
Style:	2.5 Gallon Per Minute
Color:	Brushed Nickel
Finish Type:	Brushed
Material:	Brushed Nickel Plated Premium ABS, Stainless Steel Shower Hose
Shape:	Round
Installation Type:	Wall Mounted
Flow Rate:	2.5 Gallons Per Minute (GPM)
Number of Settings:	6
Hose Length:	5 Feet
Product Dimensions:	9.5"L x 6"W

Item Weight:	1.2 pounds
Included Components:	Brushed Nickel Handheld Shower, Extra-flexible 5 FT Stainless Steel Shower Hose, Overhead Bracket, Washers, Plumber's Tape, Installation Instructions
Certification:	US quality standards

7. WARRANTY & SUPPORT

AquaDance offers a **Lifetime Warranty** on this product. For any questions, assistance, or warranty claims, please contact our customer service representatives.

Customer Service:

Live American customer service representatives are available to assist you by phone or email. Please refer to the product packaging or the AquaDance official website for contact details.

© 2023 AquaDance. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B07WGWHV2G>

More documents and user manuals: <https://manuals.plus/>