Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > Singsation /
- Singsation Professional Karaoke Machine User Manual

Singsation SPKA75

Singsation Professional Karaoke Machine User Manual

Model: SPKA75

1. Introduction

Thank you for purchasing the Singsation Professional Karaoke Machine. This portable Bluetooth karaoke system is designed to provide hours of entertainment with its advanced voice effects, dynamic sound effects, and captivating light show. This manual will guide you through the setup, operation, and maintenance of your new karaoke machine, ensuring you get the most out of its features.

2. SAFETY INFORMATION

- · Read all instructions before using the product.
- Do not expose the unit to water or excessive moisture.
- Ensure proper ventilation; do not block any ventilation openings.
- Use only the power adapter supplied with the unit.
- Keep the unit away from heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Do not attempt to service this product yourself. Refer all servicing to qualified service personnel.
- · Avoid placing heavy objects on top of the unit.

3. PACKAGE CONTENTS

Please check to ensure all items are present in your package:

- · Singsation Professional Karaoke Machine Unit
- 2 x Microphones
- Remote Control
- Power Adapter
- User Manual (this document)

4. PRODUCT FEATURES

The Singsation Professional Karaoke Machine is packed with features to enhance your singing experience:

- 60 Professional-Quality Voice Effects: Transform your voice with various effects like echo, baritone, alien, and more.
- 10 Amazing Sound Effects: Add fun sounds like applause, cheers, and air horn to your performance.
- 25 Room-Filling LED Light Effects: Create a dynamic party atmosphere with multi-color light modes including party, pulse, breathe, and chase.
- Portable Design: Easy to transport for parties anywhere.
- Bluetooth Connectivity: Wirelessly stream music from your smartphone or tablet.
- Dual Microphone Inputs: Includes two microphones for duet singing.



Figure 4.1: Overview of the Singsation Karaoke Machine's control panel highlighting the extensive light, sound, and voice effects available.



Figure 4.2: The Singsation Karaoke Machine supports two microphones, enabling duet performances for enhanced entertainment.

5. SETUP

Follow these steps to set up your Singsation Professional Karaoke Machine:

- 1. **Unpack the Unit:** Carefully remove all components from the packaging. Retain the packaging for future storage or transport.
- 2. **Power Connection:** Connect the supplied power adapter to the DC IN port on the back of the karaoke machine and plug it into a standard electrical outlet. The unit can also operate on its internal battery.
- 3. Microphone Connection: Plug the included microphones into the MIC 1 and MIC 2 XLR ports on the side of the unit.
- 4. **Placement:** Place the karaoke machine on a stable, flat surface. Ensure there is adequate space around the unit for ventilation.



6. OPERATING INSTRUCTIONS

This section details how to operate your karaoke machine's various functions.

6.1. Power On/Off

Press and hold the POWER/PAIR button on the control panel or the remote control to turn the unit ON or OFF.

6.2. Music Playback

The Singsation Karaoke Machine supports Bluetooth audio streaming and auxiliary input.

6.2.1. Bluetooth Pairing

- 1. Turn on the karaoke machine. The Bluetooth indicator will flash, indicating it's in pairing mode.
- 2. On your smartphone or tablet, enable Bluetooth and search for available devices.
- 3. Select "Singsation" from the list of devices. Once paired, the Bluetooth indicator will glow solid.
- 4. Start playing music from your device. Adjust the Music Volume knob on the karaoke machine.

6.2.2. Auxiliary Input

- Connect an external audio device (e.g., MP3 player) to the AUX IN port using a 3.5mm audio cable (not included).
- The unit will automatically switch to AUX mode. Adjust the Music Volume knob.

6.3. Microphone Usage

- Mic Volume: Use the MIC VOLUME knob to adjust the volume of the connected microphones.
- Voice Effects: Press the VOICE EFFECTS button repeatedly to cycle through the 60 available voice effects. Use the VOICE EFFECTS knob to fine-tune the effect level.

6.4. Sound Effects

 Press the SOUND EFFECTS button to activate one of the 10 built-in sound effects. Press again to cycle through them.

6.5. Light Show

- Light Colors: Press the LIGHT COLORS button to switch between different color modes for the main speaker light.
- **Light Effects:** Press the LIGHT EFFECTS button to cycle through the 25 dynamic light effects for the main speaker light and the top disco ball light.
- Front Light FX: Use the FRONT LIGHT FX button to control the front-facing light effects.

6.6. Remote Control Functions

The included remote control provides convenient access to key functions:

- Power/Pair: Turns the unit on/off and initiates Bluetooth pairing.
- Light Colors: Changes the color of the main speaker light.
- Light Effects: Cycles through light show patterns.
- Volume Mode: Switches between adjusting music volume and microphone volume.
- Sound Effects: Activates and cycles through sound effects.
- Voice Effects: Cycles through voice transformation effects.
- Playback Controls: Play/Pause, Skip Forward, Skip Backward.



Power/Pair

Light Colors

Easily switch between different color modes

Light Effects

Multi-color light modes - party, pulse, breathe, chase and more

Volume Mode

Easily switch between music volume and mic volume

Sound Effects

Fun sounds like applause, cheers, air horn and more

Voice Effects

Transform your voice with echo, baritone, alien and more

Figure 6.1: The Singsation remote control, detailing the functions of each button for convenient operation.

7. MAINTENANCE

Proper care will ensure the longevity of your karaoke machine:

- Cleaning: Wipe the unit with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Storage: When not in use, store the unit in a cool, dry place, away from direct sunlight and extreme temperatures.
- Battery Care: If the unit is not used for an extended period, charge the battery periodically to maintain its health.

8. Troubleshooting

If you encounter issues with your Singsation Professional Karaoke Machine, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Unit does not power on.	Battery is depleted or power adapter is not connected properly.	Connect the power adapter and ensure it's plugged into a working outlet. Allow the unit to charge for a few minutes before attempting to power on again.
No sound from speaker.	Music volume is too low, external device volume is low, or incorrect input mode.	Increase the Music Volume knob. Check the volume on your connected Bluetooth device or auxiliary source. Ensure the correct input mode is selected (Bluetooth/AUX).
Microphone not working.	Microphone not plugged in, Mic Volume too low, or microphone is faulty.	Ensure microphones are securely plugged into the MIC ports. Increase the MIC VOLUME knob. Test with another microphone if available.
Bluetooth pairing fails.	Unit is not in pairing mode, or device is too far away.	Press and hold the POWER/PAIR button to enter pairing mode (indicator will flash). Ensure your device is within 30 feet of the karaoke machine. Try unpairing and re-pairing.

9. SPECIFICATIONS

Feature	Detail
Brand	Singsation
Model Number	SPKA75
Item Weight	20.7 pounds
Product Dimensions	12 x 13 x 25 inches
Color	Black
Compatible Devices	Smartphone, Tablet
Connector Type	XLR (for microphones)
Speaker Count	1
Power Source	Battery Powered
Voltage	12 Volts
Special Feature	Portable
Included Components	Microphone (x2), Remote Control, Power Adapter

10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official Singsation website. Keep your purchase receipt as proof of purchase for any warranty claims.

Related Documents - SPKA75

SINGSATION BRAVO ALL-IN-ONE PARTY SYSTEM QUICK START GUIDE	Singsation Bravo Quick Start Guide: All-in-One Party System Get started quickly with the Singsation Bravo all-in-one party system. This guide covers setup, Bluetooth pairing, microphone use, and lighting effects.
SINGSATION AURORA ALL-IN-ONE KARAOKE SYSTEM QUICK START GUIDE	Singsation Aurora All-In-One Karaoke System Quick Start Guide Get started quickly with the Singsation Aurora All-In-One Karaoke System (SPKA28). This guide covers unpacking, charging, Bluetooth pairing, music playback, microphone use, TWS mode, light show, and other audio sources for your karaoke experience.
SINGSATION ARIA ALL-IN-ONE KARAOKE SYSTEM QUICK START GUIDE	Singsation Aria All-In-One Karaoke System Quick Start Guide A quick start guide for the Singsation Aria All-In-One Karaoke System, covering setup, Bluetooth pairing, microphone connection, music playback, and additional features.
SINGSATION CENTER STAGE FREESTYLE ALL-IN-ONE KARAOKE SYSTEM QUICK START GUIDE GRAPH FOR VIdeo Setup FPO Instructions, Scan Herel Minustrant a Turon	Singsation Center Stage Freestyle All-in-One Karaoke System Quick Start Guide Get started quickly with the Singsation Center Stage Freestyle all-in-one karaoke system. This guide covers unpacking, setup, Bluetooth pairing, microphone installation, and basic operation.
SINGSATION' TEMPO ALL-IN-ONE KARAOKE SYSTEM QUICK START GUIDE	Singsation Tempo All-In-One Karaoke System Quick Start Guide A quick start guide for the Singsation Tempo All-In-One Karaoke System, covering setup, Bluetooth pairing, music playback, and features.

SINGSATION CLASSIC KARAOKE SYSTEM + WIRELESS SPEAKER

QUICK START GUIDE

<u>Singsation Classic Karaoke System + Wireless Speaker Quick Start Guide</u>

Get started quickly with your Singsation Classic Karaoke System and Wireless Speaker. This guide covers setup, Bluetooth pairing, singing, EQ, and lighting features.